Canon

Mac Fax Driver Guide

Mac Fax Driver Ver. 1.40



Mac Fax Driver Guide



How This Manual Is Organized

Chapter 1	Before You Start
Chapter 2	Getting Started
Chapter 3	Fax Driver Options
Chapter 4	Special Fax Driver Options
Chapter 5	Troubleshooting
Chapter 6	Appendix

Includes the available paper sizes list, glossary, and index.

Contents

	Dustana
	Prefacevii
	How to Use This Manualvii
	Symbols Used in This Manual
	Buttons Used in This Manual vii
	Displays Used in This Manual viii
	Legal Notices
	Trademarksix
	Copyright
	Disclaimersix
Chapter 1	Before You Start
	Supported Canon Products
	System Requirements
	Where to Find Help1-6
	where to rink help
Chapter 2	Getting Started
	Installing the Software2-2
	Installing the Fax Driver
	Uninstalling the Fax Driver
	Specifying the Fax Settings2-10
	Mac OS X 10.2.8 - 10.3.9
	USB Connection
	TCP/IP Protocol Connection
	Mac OS X 10.4 or later2-14
	USB Connection2-14
	TCP/IP Protocol Connection
	Setting Up the Fax Configuration/Confirming the Printer Status
Chapter 3	Fax Driver Options
	Faving a Resument
	Faxing a Document
	Sending a Document
	Sending to a Remote Memory Box
	Specifying the Paper Orientation
	Scaling a Document3-8
	Specifying the Paper Size

	Specifying the Output Range	3-10
	Faxing Multiple Pages on One Sheet	3-11
	Saving the Fax Settings	3-13
	Specifying Recipients	3-15
	Adding a New Name and Fax Number	
	Adding a Recipient from the Address Book	
	Defining Address Book Entries	
	Person (Single) Entry	
	Group Entry	
	Importing/Exporting Address Book Entries	
	Importing Address Book Entries	
	Attaching a Cover Sheet to a Fax.	
	Registering an Original Cover Sheet as a Template	3-36
Chapter 4	Special Fax Driver Options	
	Setting the Fax Send Time (Mac OS X 10.3 or later)	4-2
	Changing the Order of Pages (Mac OS X 10.3 or later)	4-4
	Specifying the Color Filter (Mac OS X 10.3 or later)	4-6
	Saving a Document in PDF Format	4-7
	Mac OS X 10.2.8 - 10.3.9	4-7
	Mac OS X 10.4 or Later	4-8
	Saving a Document as a File (Mac OS X 10.2.8 - 10.3.9)	4-10
	Specifying the Fax Resolution	4-11
	Specifying the Telephone Number Prefix	4-12
	Selecting a Telephone Line for Fax Transmission	4-14
	Customizing Telephone Line Names	4-16
	Specifying the Sender	4-18
	Using the Sent Fax Notification Option	4-20
	Setting the Fax Send Time	4-22
	Job Accounting Feature	4-24
	Job Accounting Overview	4-24
	Specifying the ID and Password	
	Faxing with Job Accounting	
	With Confirm ID/Password when Sending Fax Selected	
	With Confirm ID/Password when Sending Fax Not Selected	
	Using the Faxmonitor	
	Starting the Faxmonitor	
	Printer Menu	
	Faxmonitor Window	

	Confirming the Printer Status4-33
Chapter 5	Troubleshooting
	Problems and Solutions5-2
Chapter 6	Appendix
	Available Paper Sizes List6-2
	About the Address Book and Cover Sheets
	Maximum Entries for the Address Book6-3
	Maximum Recipients and Cover Sheet Options6-3
	Glossary
	Index

Preface

Thank you for purchasing this Canon product. Please read this manual thoroughly before operating the product in order to familiarize yourself with its capabilities, and to make the most of its many functions. After reading this manual, store it in a safe place for future reference.

How to Use This Manual

Symbols Used in This Manual

The following symbols are used in this manual to explain procedures, restrictions, handling precautions, and instructions that should be observed for safety.



Indicates operational requirements and restrictions. Be sure to read these items carefully in order to operate the product correctly, and to avoid damage to the product.



Indicates a clarification of an operation, or contains additional explanations for a procedure. Reading these notes is highly recommended.

Buttons Used in This Manual

The following button names are a few examples of how buttons to be clicked are expressed in this manual:

Buttons on Computer Operation Screens: [Button Name]

Examples: [OK]


[Print]

Displays Used in This Manual

Screen shots of computer operation screens used in this manual may differ from the ones you actually see, depending on the operating system and the model or options that come with your machine.

The buttons which you should click are marked with a _____, as shown below.

When multiple buttons can be clicked, they are highlighted and mentioned in the order in which they should be clicked.



Legal Notices

Trademarks

Canon, the Canon logo, imageRUNNER, imageCLASS, imagePASS, and iR are trademarks of Canon Inc.

Apple, ColorSync, Mac OS, and Macintosh are trademarks of Apple Computer, Inc.

Other product and company names herein may be the trademarks of their respective owners.

Copyright

Copyright 2005 by Canon Inc. All rights reserved.

No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, or by any information storage or retrieval system without the prior written permission of Canon Inc.

Disclaimers

The information in this document is subject to change without notice.

CANON INC. MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, EITHER EXPRESS OR IMPLIED, EXCEPT AS PROVIDED HEREIN, INCLUDING WITHOUT LIMITATION, THEREOF, WARRANTIES AS TO MARKETABILITY, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OF USE OR AGAINST INFRINGEMENT OF ANY PATENT. CANON INC. SHALL NOT BE LIABLE FOR ANY DIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY NATURE, OR LOSSES OR EXPENSES RESULTING FROM THE USE OF THIS MATERIAL.

Before You Start

This chapter describes the system environments required for using the fax driver. It also explains where to find help and information regarding the installation and use of this driver.

Supported Canon Products	1-2
System Requirements	1-5
Where to Find Help	1-6

Supported Canon Products

The fax driver version 1.40 is available for the following Canon Products. Refer to the following table to select the driver name that corresponds to your printer.

Printer Name	Driver Name
Color imageRUNNER C2620	Canon iR C2620 (FAX)
imagePASS-C1 (Color iR C2620-C1)	Canon iR C2620-C1 (FAX)
imagePASS-C2 (Color iR C2620-C2)	Canon iR C2620-C2 (FAX)
Color imageRUNNER C3200	Canon iR C3200 (FAX)
imagePASS-C1 (Color iR C3200-C1)	Canon iR C3200-C1 (FAX)
Color imageRUNNER C3220	Canon iR C3220 (FAX)
imagePASS-C1 (Color iR C3220-C1)	Canon iR C3220-C1 (FAX)
imagePASS-C2 (Color iR C3220-C2)	Canon iR C3220-C2 (FAX)
imageRUNNER C3100	Canon iR C3100 (FAX)
imagePASS-E1 (iR C3100-E1)	Canon iR C3100-E1 (FAX)
imageRUNNER C3170i	Canon iR C3170 (FAX)
imageRUNNER C3170U	Canon iR C3170 (FAX)
imageRUNNER C5800	Canon iR C5800 (FAX)
imagePASS-D1 (iR C5800-D1)	Canon iR C5800-D1 (FAX)
imageRUNNER C5870U	Canon iR C5870 (FAX)
imagePASS-G1 (iR C5870-G1)	Canon iR C5870-G1 (FAX)
imageRUNNER C6800	Canon iR C6800 (FAX)
imagePASS-D1 (iR C6800-D1)	Canon iR C6800-D1 (FAX)
imageRUNNER C6870U	Canon iR C6870 (FAX)
imagePASS-G1 (iR C6870-G1)	Canon iR C6870-G1 (FAX)
imageRUNNER 2010F	Canon iR1600-2000 (FAX)
imageRUNNER 2016	Canon iR2016 (FAX)

Printer Name	Driver Name
imageRUNNER 2020	Canon iR2020 (FAX)
imageRUNNER 2230	Canon iR2230 (FAX)
imageRUNNER 2830	Canon iR2830 (FAX)
imageRUNNER 2870/2270	Canon iR2270/iR2870 (FAX)
imageRUNNER 3300/2800/2200 imageRUNNER 3300i	Canon iR2200-3300 (FAX)
imageRUNNER 3320G imageRUNNER 3320i/2220i imageRUNNER 3320N/2220N	Canon iR2220/iR3320 (FAX)
imageRUNNER 3530	Canon iR3530 (FAX)
imageRUNNER 4570/3570	Canon iR3570/iR4570 (FAX)
imageRUNNER 5070	Canon iR5070 (FAX)
imageRUNNER 6570/5570	Canon iR5570/iR6570 (FAX)
imagePASS-M3 (iR6570/5570-M3)	Canon iR5570/iR6570-M3 (FAX)
imageCLASS 2300	Canon iC2300 (FAX)
MF7200 Series	Canon MF7200 Series (FAX)

IMPORTANT

- The fax options are available only if a fax board is installed in your printer.
- In this guide, these printer names are hereafter referred to as the following:
 - imagePASS-C1 (Color iR C2620-C1): Color imageRUNNER C2620-C1
 - imagePASS-C1 (Color iR C3200-C1): Color imageRUNNER C3200-C1
 - imagePASS-C1 (Color iR C3220-C1): Color imageRUNNER C3220-C1
 - imagePASS-C2 (Color iR C2620-C2): Color imageRUNNER C2620-C2
 - imagePASS-C2 (Color iR C3220-C2): Color imageRUNNER C3220-C2
- imagePASS-D1 (iR C5800-D1): imageRUNNER C5800-D1
- imagePASS-D1 (iR C6800-D1): imageRUNNER C6800-D1
- imagePASS-E1 (iR C3100-E1): imageRUNNER C3100-E1
- imagePASS-G1 (iR C5870-G1): imageRUNNER C5870-G1
- imagePASS-G1 (iR C6870-G1): imageRUNNER C6870-G1
- imagePASS-M3 (iR6570/5570-M3): imageRUNNER 6570/5570-M3
- imageRUNNER C3170i: imageRUNNER C3170
- imageRUNNER C3170U: imageRUNNER C3170
- imageRUNNER C5870U: imageRUNNER C5870
- imageRUNNER C6870U: imageRUNNER C6870
- imageRUNNER 3320G: imageRUNNER 3320i
- imageRUNNER 3320N/2220N: imageRUNNER 3320i/2220i

System Requirements

The fax driver can be used in the following system environments:

■ Operating System Software Mac OS X (version 10.2.8 or later)

■ Computer

Any computer which runs Mac OS X properly

Where to Find Help

Here's where to get immediate help if you are having problems installing or using the fax driver.

■ ReadMe.rtf file

Any hints, enhancements, limitations, and restrictions you need to be aware of when installing and using your fax driver are included in the ReadMe.rtf file provided with the driver. The ReadMe.rtf file is located in the [MacOSX] folder.

■ Online Help

You can locate additional help for questions you may have regarding your fax in the Online Help file provided with the driver software. In the [Page setup] dialog box or the [Print] dialog box, you can click [?] to display additional information about every feature and option in the fax driver.

■ Canon Authorized Dealers or Service Providers

If the Online Help file does not provide the information you need, contact your local authorized Canon dealer.

Getting Started

This chapter describes instructions for installing the fax driver and setting the system configuration.

Installing the Software	2-2
-	
Installing the Fax Driver	2-2
Uninstalling the Fax Driver	2-5
Specifying the Fax Settings	. 2-10
Mac OS X 10.2.8 - 10.3.9	2-10
Mac OS X 10.4 or later	2-14
Setting Up the Fax Configuration/Confirming the Printer Status	. 2-19

Installing the Software

This section describes instructions for installing the fax driver and uninstalling the fax driver.

Installing the Fax Driver

Before using the fax, you must install the fax driver for it.

- 1 Close all application software.
- **2** Open the [MacOSX] folder.
- **3** Double-click the [Fax Installer] icon.



The [Authenticate] dialog is displayed.

4 Enter the administrator's name and password \rightarrow click [OK].




The installer starts.



Depending on the system environment, the [Authenticate] dialog box may not be displayed. In that case, skip to step 5.

5 Read the Software License Agreement carefully. If you agree to the terms, click [Continue].



6 Click [Agree] in the message box to proceed.



7 Confirm that [Easy Install] is selected → click [Install].



8 Click [Continue] in the message box to proceed.



Installation starts.

Click [Restart] to restart your computer.



The computer is restarted.

Installation is complete.



- The fax utility software "Faxmonitor" is installed simultaneously.
- For details about using the Faxmonitor, see "Using the Faxmonitor," on p. 4-28.

Uninstalling the Fax Driver

It is recommended that you use the Installer to uninstall an unnecessary driver.

- Close all application software.
- Open the [MacOSX] folder.

Double-click the [Fax Installer] icon.



The [Authenticate] dialog box is displayed.

Enter the administrator's name and password → click [OK].




The installer starts.



Depending on the system environment, the [Authenticate] dialog box may not be displayed. In that case, skip to step 5.


5 Read the Software License Agreement carefully. If you agree to the terms, click [Continue].



6 Click [Agree] in the message box to proceed.



7 Select [Uninstall] from the drop-down list → click [Uninstall].



8 Click [Continue] in the message box to proceed.



Uninstallation starts.

9 In the [Fax Installer] dialog box, click [Quit].



Uninstallation is complete.

Specifying the Fax Settings

After installing the fax driver, you need to specify the fax you want to use in the Printer Setup Utility in order to print a document.



NOTE

The Printer Setup Utility is called Print Center on Mac OS X 10.2.8.

Mac OS X 10.2.8 - 10.3.9

USB Connection

1 Select the hard disk drive you are using → click [Applications] → [Utilities] → double-click the [Printer Setup Utility] icon.

The [Printer List] dialog box is displayed.


2 Click the [Add] icon.






The [Printer List] dialog box may vary in appearance depending on the version of Mac OS X you are using.

Select [USB].



Select the printer name.



For Mac OS X 10.2.8, select a printer whose [Type] is [Fax].

For Mac OS X 10.3, select a printer whose [Type] is [Canon] → select [Fax] from [Printer Model].

- Click [Add] in the [Printer List] dialog box.
- Confirm that the printer has been added in the [Printer List] dialog box \rightarrow close the dialog box.




- Confirm that the driver name corresponding to your printer is displayed under [Kind] in the [Printer List] dialog box.
- For the driver name corresponding to your printer, see "Supported Canon Products," on p. 1-2.
- If the driver name for your printer does not exist in the table on p. 1-2, [CanonFax] will be displayed.

TCP/IP Protocol Connection

1 Select the hard disk drive you are using → click [Applications] → [Utilities] → double-click the [Printer Setup Utility] icon.

The [Printer List] dialog box is displayed.


2 Click the [Add] icon.



∧ NOTE

The [Printer List] dialog box may vary in appearance depending on the version of Mac OS X you are using.

Select [Canon IP (Fax)].



Enter your printer's IP address or DNS name in [Printer's Address] → enter a queue name in [Queue Name].



- If you want to use the IP address as the printer name, leave [Queue Name] blank.
- If you are using the Color imageRUNNER C2620-C1, Color imageRUNNER C2620-C2, Color imageRUNNER C3200-C1, Color imageRUNNER C3220-C1, Color imageRUNNER C3220-C2, imageRUNNER C3100-E1, imageRUNNER C5800-D1, imageRUNNER C5870-G1, imageRUNNER C6800-D1, imageRUNNER C6870-G1, or imageRUNNER 6570/5570-M3, do not change the default queue name (<CanonFax>). Otherwise the fax driver may not work properly.
- 5 Click [Add] in the [Printer List] dialog box.
- Confirm that the printer has been added in the [Printer List] dialog box \rightarrow close the dialog box.



- Confirm that the driver name corresponding to your printer is displayed under [Kind] in the [Printer List] dialog box.
- For the driver name corresponding to your printer, see "Supported Canon Products," on p. 1-2.
- If the driver name for your printer does not exist in the table on p. 1-2, [CanonFax] will be displayed.

USB Connection

Select the hard disk drive you are using → click [Applications]
→ [Utilities] → double-click the [Printer Setup Utility] icon.


The [Printer List] dialog box is displayed.

2 Click the [Add] icon.




The [Printer Browser] dialog box is displayed.

Click [Default Browser].



Select the printer → select [Fax] from [Print Using].



Select a printer that has [USB] displayed in its [Connection] column.

- 5 Click [Add] in the [Printer List] dialog box.
- 6 Confirm that the printer has been added in the [Printer List] dialog box → close the dialog box.




- Confirm that the driver name corresponding to your printer is displayed under [Kind] in the [Printer List] dialog box.
- For the driver name corresponding to your printer, see "Supported Canon Products," on p. 1-2.
- If the driver name for your printer does not exist in the table on p. 1-2, [CanonFax] will be displayed.

TCP/IP Protocol Connection

1 Select the hard disk drive you are using → click [Applications]
→ [Utilities] → double-click the [Printer Setup Utility] icon.

The [Printer List] dialog box is displayed.

2 Click the [Add] icon.




The [Printer Browser] dialog box is displayed.

Click [More Printers].



Select [Canon IP (Fax)].



Enter your printer's IP address or DNS name in [Printer's Address] → enter a queue name in [Queue Name].



- If you want to use the IP address as the printer name, leave [Queue Name] blank.
- If you are using the Color imageRUNNER C2620-C1, Color imageRUNNER C2620-C2, Color imageRUNNER C3200-C1, Color imageRUNNER C3220-C1, Color imageRUNNER C3220-C2, imageRUNNER C3100-E1, imageRUNNER C5800-D1, imageRUNNER C5870-G1, imageRUNNER C6800-D1, imageRUNNER C6870-G1, or imageRUNNER 6570/5570-M3, do not change the default queue name (<CanonFax>). Otherwise the fax driver may not work properly.
- Click [Add] in the [Printer List] dialog box.
- 7 Confirm that the printer has been added in the [Printer List] dialog box \rightarrow close the dialog box.



- Confirm that the driver name corresponding to your printer is displayed under [Kind] in the [Printer List] dialog box.
- For the driver name corresponding to your printer, see "Supported Canon Products," on p. 1-2.
- If the driver name for your printer does not exist in the table on p. 1-2, [CanonFax] will be displayed.

Setting Up the Fax Configuration/Confirming the Printer **Status**

Before sending a document, you need to set up the fax configuration in order to use the functions of an optional unit attached to the fax.

You can also check the following fax information: the name of the fax model, the number of telephone lines, and whether Job Accounting is set.



NOTE

If you are using a printer with a USB connection, [Device Settings] may be displayed instead of [Printer Info], depending on the printer model you are using. You cannot obtain fax information from [Device Settings].


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [Special Features] preferences pane.

The [Special Features] preferences pane is displayed.

Click [Printer Info] (or [Device Settings]).




The [Printer Info] (or [Device Settings]) dialog box is displayed.



If the [Printer Info] (or [Device Settings]) dialog box is not displayed, check whether the fax is turned on.

4 Check or set the device information.

- If the [Printer Info] dialog box is displayed:
 - ☐ Check the displayed printer name, whether Job Accounting is active, whether the printer is ISDN compatible, and the number of lines.



- If the [Device Settings] dialog box is displayed:
 - ☐ If the printer is using Job Accounting, select [Use Job Accounting].
- **5** Click [OK].

Fax Driver Options

This chapter describes instructions for specifying the various basic settings for faxing a document.

Faxing a Document	3-2
Sending a Document	
Sending to a Remote Memory Box	
Specifying the Paper Orientation	3-7
Scaling a Document	3-8
Specifying the Paper Size	3-9
Specifying the Output Range	3-10
Faxing Multiple Pages on One Sheet	3-11
Saving the Fax Settings	3-13
Specifying Recipients	3-15
Adding a New Name and Fax Number	3-15
Adding a Recipient from the Address Book	3-17
Defining Address Book Entries	3-19
Person (Single) Entry	
Group Entry	
Importing/Exporting Address Book Entries	3-25
Importing Address Book Entries	3-25
Exporting Address Book Entries	3-27
Attaching a Cover Sheet to a Fax	3-29
Registering an Original Cover Sheet as a Template	3-36

Faxing a Document

This section describes how to fax a document and how to send a document to the memory box of a recipient's fax.



IMPORTANT

No more than 512 recipients can be stored on the printer at any one time for fax sending. If the number of recipients exceeds 512, subsequent recipients will be deleted. Take care when continuously sending faxes to multiple groups.

Sending a Document


To send a document by fax, follow the procedure below.

- Start the application software, and then display the document you want to fax.
- From the [File] menu, select [Page Setup].

The [Page Setup] dialog box is displayed.

3 Select [Page Attributes] from [Settings].

The [Page Attributes] preferences pane is displayed.



- Select the fax to use from [Format for].
- Specify the paper size, scale, and paper orientation.
- Click [OK] in the [Page Setup] dialog box.
- From the [File] menu, select [Print].

The [Print] dialog box is displayed.

8 Verify or select the fax name from [Printer].



- Specify the pages to fax.
- Select the [General Settings] preferences pane → specify the recipients.

For instructions on how to specify the recipients, see "Specifying Recipients," on p. 3-15.

Click [Print] in the [Print] dialog box.

Faxing starts.



- The [Copies] and [Collated] settings are ignored because only one copy is allowed with the fax driver.
- If you cancel faxing before job completion, make sure to reset the fax settings.
- There are additional features available using other panes. See Chapter 3, "Fax Driver Options," Chapter 4, "Special Fax Driver Options," or the Online Help.

Sending to a Remote Memory Box

This mode is useful for sending a confidential document by fax. Documents that are to be sent and stored in the memory box of a recipient's fax require a valid subaddress and password.



NOTE

In order to use this mode, you need to obtain the subaddress and password of the memory box of the recipient's fax in advance.


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

2 Select the [General Settings] preferences pane.


The [General Settings] preferences pane is displayed.

Click [Add Recipient].



The [Add Recipient] dialog box is displayed.

- Enter the recipient's name and fax number.
- Select [Use Subaddress] under [Advanced Function] → enter the subaddress and password of the memory box of the recipient's fax.



- Click [OK].
- Specify the various settings in the [Print] dialog box \rightarrow click [Print].

The document is sent and stored in the memory box of the recipient's fax.

Specifying the Paper Orientation

You can specify the paper orientation.


From the [File] menu of the application software, select [Page Setup].

The [Page Setup] dialog box is displayed.

Select [Page Attributes] from [Settings].

The [Page Attributes] preferences pane is displayed.

Select the paper orientation from [Orientation].



Click [OK].

Scaling a Document

You can enlarge or reduce the size of the document to be sent.


From the [File] menu of the application software, select [Page Setup].

The [Page Setup] dialog box is displayed.

Select [Page Attributes] from [Settings].

The [Page Attributes] preferences pane is displayed.

3 Specify the zoom ratio for [Scale].



Click [OK].

Specifying the Paper Size

The paper size set in the application software is the one usually used for the output. However, you can specify a paper size different from the size set in the application software. In this case, the scaling is automatically set to fit the document onto the selected paper.


From the [File] menu of the application software, select [Page Setup].

The [Page Setup] dialog box is displayed.

Select [Page Attributes] from [Settings].

The [Page Attributes] preferences pane is displayed.

3 Specify the paper size to be printed from [Paper Size].



The paper sizes which can be selected differ according to the printer model you are using. For details, see "Available Paper Sizes List," on p. 6-2.

Click [OK].

Specifying the Output Range

You can specify which pages will be sent.

From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Confirm that the [Copies & Pages] preferences pane is displayed → specify an output range for [Pages].



If you want to send only a part of the document, enter the first and last page numbers.



The settings for [Copies] and [Collated] are ignored because only one copy is allowed with the fax driver.

Click [Print] in the [Print] dialog box.

Faxing Multiple Pages on One Sheet

Multiple pages of the original can be faxed on one sheet of paper by reducing the output size.



NOTE

If a cover sheet is attached to the fax, the layout settings described in this section will not be applied to the cover sheet.


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.


Select the [Layout] preferences pane.

The [Layout] preferences pane is displayed.


Select the number of pages you want to send on one sheet of paper from [Pages per Sheet].



For [Layout Direction], select the page layout direction.



Select the type of the page border for [Border].



Click [Print] in the [Print] dialog box.


Saving the Fax Settings

You can save fax driver settings that you frequently use as a Preset. If you select a Preset when faxing a document, it will be output with the saved settings.

From the [File] menu of the application software, select [Print].


The [Print] dialog box is displayed.

- In each pane, specify the fax driver settings you want to save.
- Select [Save As] from [Presets].



The [Save Preset] dialog box is displayed.

Enter a name for the settings in [Save Preset As] → click [OK].



The current settings are saved as a Preset.



To fax a document with the saved settings, select the Preset from [Presets] in the [Print] dialog box.

Specifying Recipients

You can specify the names and fax numbers of people you want to send a fax to, by adding them to [Recipient List] in the [General Settings] preferences pane. You can add recipients by:

- Entering a new name and a new fax number in [Recipient Name] and [Fax Number] in the [General Settings] preferences pane.
- Selecting a recipient from the Canon Fax Driver Address Book.



NOTE

The maximum number of recipients you can send a fax to at any one time differs depending on whether a cover sheet is attached to the fax. For details, see "Maximum Recipients and Cover Sheet Options," on p. 6-3.

a New Name and Fax Number


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [General Settings] preferences pane.

The [General Settings] preferences pane is displayed.

Click [Add Recipient].



The [Add Recipient] dialog box is displayed.

Enter the name and fax number you want to add in [Recipient Name] and [Fax Number] → click [OK].



The new recipient is displayed in [Recipient List] in the [General Settings] preferences pane.



To change the name and fax number of an added recipient, select the recipient from [Recipient List] → click [Edit Recipient].

Adding a Recipient from the Address Book


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [General Settings] preferences pane.

The [General Settings] preferences pane is displayed.

Click [Address Book].



The [Select Recipient from Address Book] dialog box is displayed.

Select a recipient from the list under [Address Books] → click [] (Below Arrow).



The selected recipient is displayed in [Recipient List].

Click [OK] in the [Select Recipient from Address Book] dialog box.

The new recipient is displayed in [Recipient List] in the [General Settings] preferences pane.



To change the name and fax number of an added recipient, select the recipient from [Recipient List] → click [Edit Recipient].

Defining Address Book Entries

This section describes how to define person and group entries for the Address Book.

Person (Single) Entry

You can create or edit a person entry in the Address Book.

From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.


Select the [General Settings] preferences pane.

The [General Settings] preferences pane is displayed.

Click [Address Book].

The [Select Recipient from Address Book] dialog box is displayed.

Click [Add Person].




The [Add Person] dialog box is displayed.



To edit a person entry in the Address Book, select the entry from the list under [Address Book] → click [Edit].

Enter information about the person, such as [Recipient Name] and [Company].



Enter the fax number.

You can enter two fax numbers: a primary number and a secondary number.

- Enter information about the fax numbers in each [Description].
- Enter any additional information about the person in [Notes].

Click [OK] in the [Add person] dialog box.



⊘ NOTE

- To delete an entry from the Address Book, select the entry from the list under [Address Books] in the [Select Recipient from Address Book] dialog box → click [Delete].
- If you specify two fax numbers for one person, two entries for that person are displayed in the list under [Address Books] in the [Select Recipient from Address Book] dialog box.

You can create or edit a group entry in the Address Book.

From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.


Select the [General Settings] preferences pane.

The [General Settings] preferences pane is displayed.

Click [Address Book].

The [Select Recipient from Address Book] dialog box is displayed.

Click [Add Group].




The [Add Group] dialog box is displayed.



To edit a group entry in the Address Book, select the entry from the list under [Address Book] → click [Edit].

Enter a name for the group in [Group Name].



Select persons or groups you want to add to the group from the list under [Address Book] → click [] (Below Arrow).

The selected persons or groups are displayed in [Current Group Members].



∧ NOTE

To remove an entry from [Current Group Members], select it → click [1] (Above Arrow).

Click [OK] in the [Add Group] dialog box.

Importing/Exporting Address Book Entries

You can import recipients from the address books of other applications and register them in the fax driver address book. You can also export recipients that have been registered in the fax driver address book and save it in a file format that can be used by other applications.



NOTE

The following file formats are supported:

- CSV format (*.csv)
- Entourage X for Mac format
- Entourage 2001 for Mac format
- Outlook Express for Mac format
- LDIF format (*.abk)

Importing Address Book Entries

From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.


Select the [General Settings] preferences pane.

The [General Settings] preferences pane is displayed.


Click [Address Book].

The [Select Recipient from Address Book] dialog box is displayed.

Click [Import].



Select the file you want to import → click [Open].



The data of the selected file is imported and displayed in the list under [Address Books] in the [Select Recipient from Address Book] dialog box.

Exporting Address Book Entries

From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [General Settings] preferences pane.

The [General Settings] preferences pane is displayed.


Click [Address Book].

The [Select Recipient from Address Book] dialog box is displayed.

Click [Export].



Specify [Save As], [Where], and [Format] → click [Save].



The exported file is saved at the specified destination.



If you are saving a file in Outlook Express for Mac format, select [Entourage X for Mac format] in [Format].

Attaching a Cover Sheet to a Fax

This section describes how to attach a cover sheet to an outgoing fax.



NOTE

The maximum number of recipients you can send a fax to at any one time differs depending on whether a cover sheet is attached to the fax. For details, see "Maximum Recipients and Cover Sheet Options," on p. 6-3.


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [Cover Sheet] preferences pane.

The [Cover Sheet] preferences pane is displayed.

Select an option for attaching the cover sheet to the fax from [Cover Sheet Attachment].



Select a cover sheet template from [Style].


Click [Item Settings] to specify the items to include on the cover sheet.

The [Item Settings] dialog box opens.

If you want to add a label or comment to the cover sheet, display the [Labels and Comments] sheet.

If you do not want to use this option, skip to step 9.

To add a label, select [Insert Attention Note] → select a label from the list or enter label text.




You can enter a maximum of 30 characters as label text.

To add a comment, enter the comment in [Comment to Include].



You can enter a maximum of 255 characters.


Click the [Sender] tab → select the information you want to print on the cover sheet → enter the information in the text boxes for the selected items.



You can select the following items:

- Sender
- Company
- Dept./Div.
- Fax Number

10 Click the [Recipient] tab \rightarrow click the check boxes to select the information you want to print on the cover sheet.



You can select the following items:

- Recipient Name
- Company
- Dept./Div.
- Fax Number




NOTE

The recipient information specified in the Address Book will be printed on the cover sheet.

11 If you want to print a logo or signature, click the [Logo] or [Signature] tab.

If you do not want use this option, skip to step 15.

12 Select [Print with Logo] or [Print with Signature] to include a logo or signature on the cover sheet.



13 Click [Browse] \rightarrow specify a bitmap logo or signature file name.




The supported file format is bitmap only.

14 Specify the magnification and position of the selected logo or signature.

15 If you want to print the number of faxed pages, click the [Sheets to Send] tab → select [Include Number of Sheets to Send] → specify the number of pages.



You can specify the number of pages from 1 to 9999.




If you do not want to use this option, skip to step 16.



- **⊘** NOTE
 - The number of pages sent is not calculated automatically. The number of pages displayed on the cover sheet must be entered by hand.
 - For the number of pages to be sent, specify a number from 1 to 9999.
- 16 Click [OK] in the [Item Settings] dialog box.

17 If you want to check a preview image of the cover sheet, click [Sheet Preview].



18 Click [Print].

The specified cover sheet is attached to the fax when it is sent.

Registering an Original Cover Sheet as a Template

You can register a cover sheet file created with the Canon Cover Sheet Editor in Windows as a template for the fax driver.



IMPORTANT


- You can register up to 30 additional templates with the fax driver, not including the three templates supplied by default.
- You cannot create a cover sheet template with the Canon Cover Sheet Editor on the Mac OS, as it is a Windows program.
- From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [Cover Sheet] preferences pane.

The [Cover Sheet] preferences pane is displayed.

Click [Register].



Select a cover sheet file created with the Canon Cover Sheet Editor → click [Open].

The selected cover sheet file is registered as a template.

Special Fax Driver Options

This chapter describes instructions for specifying the various special settings for printing a document.

Setting the Fax Send Time (Mac OS X 10.3 or later)
Changing the Order of Pages (Mac OS X 10.3 or later)
Specifying the Color Filter (Mac OS X 10.3 or later)
Saving a Document in PDF Format 4-7 Mac OS X 10.2.8 - 10.3.9 4-7 Mac OS X 10.4 or Later 4-8
Saving a Document as a File (Mac OS X 10.2.8 - 10.3.9)
Specifying the Fax Resolution
Specifying the Telephone Number Prefix
Selecting a Telephone Line for Fax Transmission
Customizing Telephone Line Names4-16
Specifying the Sender
Using the Sent Fax Notification Option
Setting the Fax Send Time
Job Accounting Feature4-24Job Accounting Overview4-24Specifying the ID and Password4-24Faxing with Job Accounting4-26
Using the Faxmonitor 4-28 Starting the Faxmonitor 4-28 File Menu 4-29 Printer Menu 4-30 Faxmonitor Window 4-31
Confirming the Printer Status 4-33

Setting the Fax Send Time (Mac OS X 10.3 or later)

You can specify the time to send a document, as well as the sending priority.


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [Scheduler] preferences pane.


The [Scheduler] preferences pane is displayed.

3 Specify when to send the document.



If you select [At], specify the time to send the document.

Select the sending priority from [Urgent], [High], [Medium], and [Low].



Changing the Order of Pages (Mac OS X 10.3 or later)

You can change the print order of the pages.

From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [Paper Handling] preferences pane.

The [Paper Handling] preferences pane is displayed.


Specify the page order.



If you are using Mac OS X version 10.4 or later, select the page order from [Page Order].

If you are using Mac OS X version 10.3 to 10.3.9, to send in reverse page order, select [Reverse page order].

Select which pages to send from among [All pages], [Odd numbered pages], and [Even numbered pages].



Specifying the Color Filter (Mac OS X 10.3 or later)

You can apply a color filter to an outgoing fax.


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [ColorSync] preferences pane.

The [ColorSync] preferences pane is displayed.

Specify a color filter you want to output with from [Quartz Filter].



Saving a Document in PDF Format

As an alternative to faxing a document, you can save your document as a PDF file.

Mac OS X 10.2.8 - 10.3.9


- From the application software, open the document you want to save as a PDF (Portable Document Format) file.
- From the [File] menu, select [Print].

The [Print] dialog box is displayed.

In any of the panes under the [Print] dialog box, click [Save as PDF].

The [Save to File] dialog box is displayed.

Specify the file name and the save location in the [Save to File] dialog box.



Click [Save].


The document is saved as a PDF file.

- From the application software, open the document you want to save as a PDF (Portable Document Format) file.
- From the [File] menu, select [Print].

The [Print] dialog box is displayed.


In any of the panes under the [Print] dialog box, select [Save as PDF] from [PDF].

You can select other options for handling the file as a PDF.



The [Save] dialog box is displayed.

Specify the file name and save location in the [Save] dialog box.



Click [Save].

The document is saved as a PDF file.

Saving a Document as a File (Mac OS X 10.2.8 - 10.3.9)

As an alternative to faxing a document, you can save it as a file.


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [Output Options] preferences pane.

The [Output Options] preferences pane is displayed.

3 Select [Save as File] → select the file format from [Format].



Click [Save] in the [Print] dialog box.

Specifying the Fax Resolution

This section describes how to specify the resolution that the fax will be sent at.


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [Special Features] preferences pane.

The [Special Features] preferences pane is displayed.

Select the resolution from [Resolution].



Available options are:

- [Ultra Fine]
- [Fine]

Specifying the Telephone Number Prefix

This section describes how to specify the outside dialing prefix, needed by some business telephone systems to make external calls.


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [Special Features] preferences pane.

The [Special Features] preferences pane is displayed.

Select [Outside Dialing Prefix] → click [Settings].



The [Outside Dialing Prefix Settings] dialog box is displayed.

Enter the outside dialing prefix → click [OK].





You can enter a maximum of five numeric characters.

Selecting a Telephone Line for Fax Transmission

This section describes how to specify the telephone line used for fax transmission.



NOTE

This option is available for the imageRUNNER C3170, imageRUNNER C5870, imageRUNNER C5870-G1, imageRUNNER C6870, imageRUNNER C6870-G1, imageRUNNER 2010F, imageRUNNER 2870/2270, imageRUNNER 3300/2800/2200, imageRUNNER 3300i, imageRUNNER 3320i/2220i, imageRUNNER 4570/3570, and imageRUNNER 6570/5570.

From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [Special Features] preferences pane.

The [Special Features] preferences pane is displayed.

Select the telephone line for fax transmission from [Line Selection].





If the optional fax board is not installed in your fax, this setting is fixed at [Auto].

Customizing Telephone Line Names

This section describes how to edit the name of the telephone line used for fax transmission.



NOTE

This option is available for the imageRUNNER C3170, imageRUNNER C5870, imageRUNNER C5870-G1, imageRUNNER C6870, imageRUNNER C6870-G1, imageRUNNER 2010F, imageRUNNER 2870/2270, imageRUNNER 3300/2800/2200, imageRUNNER 3300i, imageRUNNER 3320i/2220i, imageRUNNER 4570/3570, and imageRUNNER 6570/5570.

From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [Special Features] preferences pane.


The [Special Features] preferences pane is displayed.

3 Click [Customize Name of Line].



The [Customize Name of Line] dialog box is displayed.

Enter a name for each line → click [OK].





You can enter a maximum of 12 characters for each line name.

Specifying the Sender

You can specify the sender name, which is recorded in the fax headers.



NOTE

This option is not available for the imageRUNNER 2010F and imageCLASS 2300.


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [Special Features] preferences pane.

The [Special Features] preferences pane is displayed.

3 Click [Settings].



The [Sender Settings] dialog box is displayed.

Enter the sender name → click [OK].





You can enter a maximum of 24 characters.

Using the Sent Fax Notification Option

You can receive notification with a message box when a fax has been sent.


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [Special Features] preferences pane.

The [Special Features] preferences pane is displayed.

3 Select [Display Dialog] from [Method of Notification].



Click [Print] in the [Print] dialog box.

The fax is sent, and the message box below is displayed.



Setting the Fax Send Time

By temporarily storing data in the printer, you can set the time at which a fax will be sent.

From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [General Settings] preferences pane.


The [General Settings] preferences pane is displayed.

Specify the name and fax number of the fax recipient.



For instructions on how to specify the name and fax number of the fax recipient, see "Specifying Recipients," on p. 3-15.

Select [Set the Time to Send] → click [Settings].



The [Send Time Settings] dialog box is displayed.

Specify the time to fax the document \rightarrow click [OK].



The specified time is shown on the right of [Set the Time to Send] in the [General Settings] preferences pane.

Click [Print] in the [Print] dialog box.

The data is stored temporarily in the printer, and the fax is sent at the specified time.

Job Accounting Feature

This section describes an overview of the Job Accounting feature, how to specify the ID and password for the Job Accounting feature, and how to fax with the Job Accounting feature.



IMPORTANT

In order to use the Job Accounting feature, the ID and password need to be registered on the printer beforehand.

Job Accounting Overview

This feature enables you to sum fax totals for each department or user for management purposes by assigning an ID and password to each department or user.

A document will be faxed only if the specified ID and password are verified as valid.

Specifying the ID and Password


1 From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

2 Select the [Special Features] preferences pane.

The [Special Features] preferences pane is displayed.

Click [Job Accounting].



The [ID/Password Settings] dialog box is displayed.

Specify the ID and password in the [ID/Password Settings] dialog box → click [OK].



If you want to display a dialog box prompting users to enter the ID and password when faxing a document, select [Confirm ID/Password when Sending Fax].



- You can verify the ID and password that are registered in the printer by clicking [Verify].
- Enter the numbers registered as the ID and password in the printer (seven digits maximum).

Faxing with Job Accounting

The procedure for faxing with Job Accounting differs depending on whether [Confirm ID/Password when Sending Fax] is selected in the [ID/Password Settings] dialog box. The [ID/Password Settings] dialog box is displayed by clicking [Job Accounting] in the [Special Features] preferences pane.

With Confirm ID/Password when Sending Fax Selected

If [Confirm ID/Password when Sending Fax] is selected in the [ID/Password Settings] dialog box, you need to enter the password each time you send a fax.

- Start the application software, and then display the document you want to fax.
- Specify the various settings in the [Page Setup] dialog box and the [Print] dialog box.

For instructions, see steps 2 to 10 of "Faxing a Document," on p. 3-2.

Click [Print] in the [Print] dialog box.

The [Confirm ID/Password] dialog box is displayed.

- Enter the password → change the ID, if necessary.
- ∅ NOTE

You can leave the password blank.

Click [OK].

The document is faxed with the specified ID and password.

With Confirm ID/Password when Sending Fax Not Selected

To fax with Job Accounting when [Confirm ID/Password when Sending Fax] is not selected in the [ID/Password Settings] dialog box, follow the procedure below.

- Start the application software, and then display the document you want to fax.
- Specify the various settings in the [Page Setup] dialog box and the [Print] dialog box.

For instructions, see steps 2 to 10 of "Faxing a Document," on p. 3-2.

Click [Print] in the [Print] dialog box.

The document is faxed with the specified ID and password.

Using the Faxmonitor

The Canon Faxmonitor is application software that interfaces with the printer software.

With the Faxmonitor, you can check the printer status, such as "ready" or "offline," on your computer.


Starting the Faxmonitor

To start the Faxmonitor, follow the procedure below.

- Open the following Mac OS folders: [Library] \rightarrow [Printers] \rightarrow [Canon] → [Fax] \rightarrow [Utilities].
- Double-click the [Canon Faxmonitor] icon.



The [Faxmonitor] window is displayed.





- You can create a Faxmonitor alias on the desktop to enable you to start the Faxmonitor merely by double-clicking its icon on the desktop.
- To select a different printer, see "Printer Menu," on p. 4-30.
- You can start the Faxmonitor by clicking the [Configure] button while the printer you want to use is selected in the Printer List of Printer Setup Utility.

File Menu

The following commands are available on the [File] menu of the Faxmonitor.




[Open]: Opens the [Faxmonitor] window. [Close]: Closes the [Faxmonitor] window.

Displays the [Preferences] dialog box. In this dialog box, you can specify the [Preferences]: polling interval (interval between printer status acquisitions).

Printer Menu

The following commands are available on the [Printer] menu of the Faxmonitor.



Displays the printers whose status you can monitor. If more than

[Printer Name]: one is available, select the printer whose status you want to

monitor.

If the printer you want is not displayed on the [Printer] menu, it [Search for Printer]:

can be searched by selecting [Search for Printer].

[Get Printer Information]: Displays the [Printer Info] dialog box.

Registers the currently selected printer the next time the [Make Default]:

Faxmonitor starts.




NOTE

- After changing the printer configuration, for example by adding an optional fax board, make sure that you select [Get Printer Information] from the [Printer] menu, or click [Printer Info] or [Device Settings], in the [Print] dialog box accessed from the application software in which you created a document, to configure the fax settings. Failing to follow this procedure may result in unacceptable printout.
- To monitor the printer status using the Faxmonitor, you need to register the printers with the Printer Setup Utility (for Mac OS X 10.3 or later) or the Print Center (for Mac OS X 10.2.8). Then, select the printers in the [Print] dialog box accessed from application software in which you created documents.
- Depending on the printer model you are using, [Get Printer Information] may not be available when connected via USB.

Faxmonitor Window

The Faxmonitor window displays the printer status and the status of the documents being printed. If a problem occurs on the printer, the error status is displayed on this window.



Status Message: Displays the printer status (ready, offline, error, etc).

Displays a detailed explanation of the Status Message or remedies for Details:

error conditions.

Status Graphic: Displays an illustration for the printer status.

Displays the job list, including user name, job status, data size, etc. for Job Status:

each job.

Selecting this button pauses data transmission from your Macintosh to [Pause]:

the printer or print server.

Selecting this button resumes sending of paused jobs. [Resume]:

Selecting this button cancels the selected print job and deletes its data [Clear Print Jobs]:

from the printer.

[Remote UI]: Selecting this button starts the Remote UI.



- To start the Remote UI, the web browser must be set up beforehand. For instructions on how to set up the Remote UI, see the Remote UI Guide.
- After changing the printer configuration, for example by adding an optional fax board, make sure that you select [Get Printer Information] from the [Printer] menu, or click [Printer Info] or [Device Settings], in the [Print] dialog box accessed from the application software in which you created a document, to configure the fax settings. Failing to follow this procedure may result in unacceptable printout.

Confirming the Printer Status

You can detect the current printer configuration, including the number of telephone lines and whether Job Accounting is set.



NOTE

If you are using a printer with a USB connection, [Device Settings] may be displayed instead of [Printer Info], depending on the printer model you are using. You cannot obtain fax information from [Device Settings].


From the [File] menu of the application software, select [Print].

The [Print] dialog box is displayed.

Select the [Special Features] preferences pane.

The [Special Features] preferences pane is displayed.

Click [Printer Info].



The [Printer Info] dialog box is displayed.

Troubleshooting



This chapter describes how to resolve printing problems.

Problems and Solutions			E (
FIODIEUIS AUG SOUMOUS			::-/

Problems and Solutions

This section describes corrective procedures, in the event that trouble occurs.

The data lamp is not lit even when sending data to the printer.

Cause 1 The printer is not connected to the Macintosh computer correctly.

Remedy Correctly connect the printer with the Macintosh computer.

Cause 2 The printer is not ON.

Remedy Turn the printer ON.

The printer name is not displayed on the Print Center (Mac OS X 10.2 or earlier) or the Printer Setup utility (Mac OS X 10.3 or later).

Cause 1 The printer is not connected to the Macintosh computer correctly.

Remedy Correctly connect the printer with the Macintosh computer.

Cause 2 The printer is not ON.

Remedy Turn the printer ON.

Cause 3 The printer driver is not installed correctly.

Remedy Reinstall the printer driver correctly.

Faxing is slow.

Cause 1 If a large data object, such as a color photo, is pasted into the document to be sent, more time is required for faxing.

Remedy Please wait, so long as the data lamp is on.

Cause 2 If a large data object, such as a color photo, is pasted into the document to be sent, more time may be required due to insufficient memory.

Remedy Expand memory.

The edge of the document is not output.					
Cause 1	The paper size set in application software may be different from the size of the paper output from the printer.				
Remedy	Shrink the output to fit the paper in the printer by specifying the desired reduction ratio for [Scale] in the [Page Setup] dialog box.				
Cause 2	The width or height of the page margins specified in the application software exceeds the printable range of the printer.				
Remedy	Adjust the page margin settings.				

Appendix

This chapter includes the available paper sizes list, information about the Address Book and cover sheets, glossary, and index.

Available Paper Sizes List	3-2
About the Address Book and Cover Sheets	3-3
Maximum Entries for the Address Book6	3-3
Maximum Recipients and Cover Sheet Options	3-3
Glossary	i-4
Index	i-5

Available Paper Sizes List

The paper sizes which can be selected differ depending on the fax model you are using. Available paper sizes are listed below.

- A3
- B4
- A4
- B5
- A5
- 11x17
- Legal
- Letter

About the Address Book and Cover Sheets

This section describes additional information about the Address Book and cover sheets.

Maximum Entries for the Address Book

The number of entries you can create in the Canon Fax Driver Address Book is as follows:

 Person entries: 3000 destinations. Group entries: 3000 destinations.

Maximum Recipients and Cover Sheet Options

The maximum of number of recipients you can send a fax to at a time differs if a cover sheet is attached, in the following way:

■ Printers other than the imageRUNNER 2010F and imageCLASS 2300

Cover sheet attachment:

- None: 256 recipients
- Different sheet to each recipient: 32 recipients
- Same sheet to all recipients: 256 recipients

■ The imageRUNNER 2010F and imageCLASS 2300

Cover sheet attachment:

- None: 90 recipients
- Different sheet to each recipient: 10 recipients
- Same sheet to all recipients: 90 recipients

IMPORTANT

- Where the destination is a group, the number of recipients corresponds to the number of registered group members, not the number of groups.
- Faxes may be sent as multiple jobs even if the number of recipients is within the above limits. One fax may therefore be displayed as separate sent fax files in the job send history list.
- No more than 512 recipients can be stored on the printer at any one time for fax sending. If the number of recipients exceeds 512, subsequent recipients will be deleted. Take care when continuously sending faxes to multiple groups.

Glossary

P

PDF

Portable Document Format. The page description language used in the Adobe Systems' Acrobat document exchange system, which is restricted neither by device nor resolution. PDF displays documents in a way that is independent of the original application software, hardware, and operating system used to create those documents. A PDF document can contain any combination of text, graphics, and images.

Protocol

A set of rules that govern the transmission of data across a network.

PS

PostScript. Developed by Adobe, this is a representative page descriptive language that provides flexible font capability and high-quality graphics, especially for high resolution printing.

R

Remote UI

Remote User Interface. The Remote UI is software that enables you to perform operations which are usually executed on the machine's control panel, using a Web browser (such as Netscape Navigator/Communicator or Microsoft Internet Explorer) over a network.

u

UFR II

Ultra Fast Rendering II. A printing algorithm for realizing high speed rendering. UFR II enables processing tasks to be executed and divided appropriately between the host PC and the printer to greatly reduce overall printing time.

Index

A

Adding new name and fax number, 3-15 Adding recipient from Address Book, 3-17 Address Book and cover sheets, 6-3 Address Book, importing/exporting, 3-25 Attaching cover sheet to a fax, 3-29 Available paper sizes list, 6-2

C

Changing order of pages (Mac OS X 10.3 or later), 4-4
Cover sheet, 3-29, 3-36, 6-3
Customizing telephone line names, 4-16

D

Defining Address Book entries, 3-19 Group entry, 3-22 Person (single) entry, 3-19

E

Exporting Address Book entries, 3-27

F

Fax driver, installing, 2-2
Fax driver, uninstalling, 2-5
Faxing document, 3-2
Sending document, 3-2
Sending to remote memory box, 3-4
Faxing multiple pages on one sheet, 3-11

Faxmonitor, 4-28
Faxmonitor window, 4-31
File menu, 4-29
Printer menu, 4-30
Starting Faxmonitor, 4-28
File format, 4-10
File menu, 4-29

G

Group entry, 3-22

Н

Help, 1-6

ı

Importing Address Book entries, 3-25 Installing Fax driver, 2-2 Installing software, 2-2 Fax driver, 2-2 Uninstalling fax driver, 2-5

J

Job Accounting feature, 4-24
Faxing with Job Accounting, 4-26
Overview, 4-24
Specifying ID and password, 4-24

0

Online Help, 1-6 Operating system software, 1-5 Output range, 3-10

Ρ

Paper orientation, specifying, 3-7
Paper size, specifying, 3-9
PDF, 4-7, 6-4
Person (single) entry, 3-19
PostScript, 6-4
Preset, 3-13
Printer menu, 4-30, 4-31
Problems and solutions, 5-2
Protocol, 6-4

R

ReadMe.rtf file, 1-6
Registering original cover sheet as template, 3-36
Remote UI, 4-31, 6-4

S

Saving a Document as a File, 4-10
Saving document in PDF Format, 4-7
Scaling document, 3-8
Selecting telephone line for fax transmission,
4-14
Sending document, 3-2
Sending to remote memory box, 3-4
Setting fax send time, 4-22
Setting the Fax Send Time (Mac OS X 10.3 or later), 4-2
Setting up fax configuration/Confirming printer status, 2-19
Software, installing, 2-2
Specifying color filter (Mac OS X 10.3 or later),
4-6

Specifying fax resolution, 4-11
Specifying fax settings, 2-10
Specifying output range, 3-10
Specifying paper orientation, 3-7
Specifying paper size, 3-9
Specifying recipients, 3-15
Adding new name and fax number, 3-15
Adding recipient from Address Book, 3-17
Specifying sender, 4-18
Specifying telephone number prefix, 4-12
Starting Faxmonitor, 4-28
Supported Canon products, 1-2
System requirements, 1-5
Computer, 1-5
Operating system software, 1-5

T

Troubleshooting, 5-1

U

UFR II, 6-4
Uninstalling fax driver, 2-5
Using Faxmonitor, 4-28
File menu, 4-29
Printer menu, 4-30
Starting Faxmonitor, 4-28
Using sent fax notification option, 4-20

W

Where to find Help, 1-6
Canon authorized dealers, 1-6
Online Help, 1-6
ReadMe.rtf file, 1-6

Canon

CANON INC.

30-2, Shimomaruko 3-chome, Ohta-ku, Tokyo 146-8501, Japan

CANON U.S.A., INC.

One Canon Plaza, Lake Success, NY 11042, U.S.A.

CANON CANADA INC.

6390 Dixie Road Mississauga, Ontario L5T 1P7, Canada

CANON EUROPA N.V.

Bovenkerkerweg 59-61 1185 XB Amstelveen, The Netherlands

CANON FRANCE S.A.S.

17, quai du Président Paul Doumer 92414 Courbevoie Cedex, France

CANON COMMUNICATION & IMAGE FRANCE S.A.S. (Pour les utilisateurs de l'imprimante laser uniquement)

12, rue de l'Industrie 92414 Courbevoie Cedex, France

CANON (U.K.) LTD.

Woodhatch, Reigate, Surrey, RH2 8BF, United Kingdom

CANON DEUTSCHLAND GmbH

Europark Fichtenhain A10, 47807 Krefeld, Germany

CANON ITALIA S.p.A.

Via Milano, 8 20097 San Donato Milanese (MI) Italy

CANON LATIN AMERICA, INC.

703 Waterford Way Suite 400 Miami, Florida 33126 U.S.A.

CANON AUSTRALIA PTY. LTD

1 Thomas Holt Drive, North Ryde, Sydney, N.S.W. 2113, Australia

CANON CHINA CO., LTD

15F, North Tower, Beijing Kerry Centre, 1 Guang Hua Road, Chao Yang District, 100020, Beijing, China

CANON SINGAPORE PTE. LTD.

1 HarbourFront Avenue #04-01 Keppel Bay Tower, Singapore 098632

CANON HONGKONG CO., LTD

19/F., The Metropolis Tower, 10 Metropolis Drive, Hunghom, Kowloon, Hong Kong