





Next



ENG

Before Using the

Document and Paper

Copying

Sending and Receiving

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Canon

Reference Guide

imageCLASS M F 4 2 7 0






Table of Contents

Index

Please read this guide before operating this product. After you finish reading this guide, store it in a safe place for future reference.

How to Use This Guide



ck Previ

Previous

Next

ТОР

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting


Annondix

11

9

Manuals for the Machine








Reference Guide (This Document) (Located on User software CD)



Scanner Driver
Guide
(Located on
User software CD)



- To view the manuals in PDF format, Adobe Reader/Acrobat Reader/Acrobat is required. If Adobe Reader/Acrobat Reader/Acrobat is not installed on your system, please download it from the Adobe Systems Incorporated website (http://www.adobe.com).
- Considerable effort has been made to make sure that the manuals for the machine are free of inaccuracies and omissions. However, as we are constantly improving our products, if you need an exact specification, please contact Canon.
- The machine illustration on the cover may differ slightly from your machine.


Table of Contents











Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

9

Table of Contents

Index

Things You Can Do

Select a scan mode depending on the type of image





Image Quality
→ p. 3-3

Adjust the density level of scanned images




Density
→ p. 3-3

Enlarge or reduce copied images




Zoom Ratio → p. 3-4

Sort copies by page order



Collate Copying
→ p. 3-6


Make two-sided copies



Two-Sided Copy → p. 3-8


key

Specify a recipient with a single




One-Touch Speed Dialing Keys
→ p. 4-12

Specify a recipient with a two-digit code




Coded Speed Dialing Codes
→ p. 4-13

Copy two documents on one sheet



2 on 1 Combination → p. 3-7

Specify multiple recipients as a group



Group Dialing
→ p. 4-14









Next

Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Remote UI


System Manager Settings

Maintenance


Troubleshooting

9

Look up a particular recipient




Receive faxes in memory without printing out



Memory Reception → p. 4-26

Print a document from a PC




Printing → p. 5-2

Redial when the line is busy




Reject faxes without their numbers



Reception Restriction → p. 4-30


→ Online Help

Sort printouts by page order




Collate Printing → p. 5-3

Send documents to multiple recipients




Broadcasting → p. 4-17

Send a fax from a PC



Print two pages on one sheet



2 on 1 Combination → p. 5-4

Table of Contents







TOP



Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Remote UI

System Manager Settings

Maintenance

9


Troubleshooting

____10


Appendix

11


Make two-sided printouts



Restrict the use of the machine with a password



Specify detailed scanning options to suit various images



Access and manage the machine from a PC




Table of Contents

Inde<u>x</u>

iv







Copying

Sending and Receiving

3

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

11

9

Table of Contents

	Manuals for the Ma	chine	i
	Things You Can Do		ii
	How to Use This Gu	ıide	xx
		Using the Top Page	XX
		Using the Chapter Topic List	xxi
	Legal Notices		xxiii
Before Usin	g the Machine	••••••	1-1
	Machine Compone	nts	1-3
	Operation Panel		1-6
		Main Operation Panel	
		Fax Operation Panel	1-9

Table of Contents









Before Using the Machine	1
Document and Pa	per 2
Copying	3
Sending and Receiving	4
Printing and Scanning	5
Network	6
Remote UI	7
System Manager Settings	8
Maintenance	9
Maintenance Troubleshooting	9
	9 0 1
Troubleshooting	9 0 1
Troubleshooting	1

	LCD (Standby Mod	de)	1-10
	,	de) Copy Mode Fax Mode	1-10
		Fax Mode	1-10
		Scan Mode	1-10
	Toner Cartridge		1-1
	_	Maintaining the Toner Cartridge	1-1
		Checking the Toner Level	1-1
	Telephone Line Se	tting	1-14
		Setting the Telephone Line Type	1-14
	Timer Settings		1-15
		Setting the Sleep Mode	1-1
		Setting the Daylight Saving Time	1-10
2 Document	and Paper	••••••	2-1
	Document Require	ements	2-2









Before Using the Machine	1 1
Document and Pa	per 2
Copying	3
Sending and Receiving	4
Printing and Scanning	5
Network	6
Remote UI	7
System Manager Settings	8
Maintenance	9
Troubleshooting	0
Appendix	1

	Scanning Area		2-3
	Loading Documents		2-4
		On the Platen Glass	2-4
		In the ADF	2-5
	Paper Requirements		2-7
	Printable Area		2-9
	Loading Paper		2-10
	3 1	Into the Multi-Purpose Tray	2-10
	Setting Paper Size and	l Type	2-13
3 Copying	•••••	••••••	3-1
		J	









Before Using the Machine 1 Document and Paper 2 Copying 3 Sending and	
Copying Sending and	
Sending and	
Receiving 4) ノ
Printing and Scanning 5	
Network 6	う ノ
Remote UI	
System Manager Settings	
Maintenance 9	
Troubleshooting 10	
	1
Appendix 11	
Appendix 11	

Scan Settings	3-3
Image Qualit	y3-3
Density	3-3
Zoom Ratio	3-4
Advanced Copy Features	3-6
	3-6
	ination3-7
Two-Sided Co	эру3-8
Printing a Sample Page	3-10
Canceling Copy Jobs	3-11
4 Sending and Receiving	4-1
Basic Sending Method	4-4







Before Using the Machine	
Machine	1
Document and Pa	per
	<u>2</u>
Copying	
	3
Sending and	
Receiving	4

Remote UI

System Manager Settings

Maintenance

Troubleshooting

10

Appendix

11

9

Scan Settings		4-5
	Image Quality	4-5
	Density	4-5
Storing/Editing Addre	ss Book	4-6
	Storing/Editing One-Touch Speed Dialing Keys/ Coded Speed Dialing Codes	4-7
	Storing/Editing Recipients for Group Dialing	4-9
Specifying Recipients .		4-12
	Using One-Touch Speed Dialing Keys	4-12
	Using Coded Speed Dialing Codes	4-13
	Group Dialing	4-14
	Using Address Book Key	4-14
Manual Sending		4-16
Advanced Sending Fea	atures	4-17
	Broadcasting	4-17

Table of Contents







Before Using the Machine	1
Document and Pa	per 2
Copying	3
Sending and Receiving	4
Printing and Scanning	5
Network	6
Remote UI	7
System Manager Settings	8
Maintenance	9
Troubleshooting	0

PC Faxing		4-18
Fax Dialing Features		4-19
_	Switching Temporarily to Tone Dialing	4-19
	Redialing	4-20
	Checking Dialing Line	4-21
	Dialing an Overseas Number (With Pauses)	4-22
Basic Receiving Metho	d	4-23
Receiving Features		4-24
_	FAX/TEL: Optional Settings	4-24
	DRPD: Optional Settings	4-25
	Manual Reception	4-25
	Memory Reception	4-26
	Memory Lock Reception	4-26
	Remote Reception	4-28
	Selecting the Receive Mode for Printing	4-29
	Reception Restriction	4-30
	Printing Received Documents	4-30

Table of Contents









Before Using the Machine	1
Document and Pa	per 2
Copying	3
Sending and Receiving	4
Printing and Scanning	5
Network	6
Remote UI	7
System Manager Settings	8
Maintenance	9
Troubleshooting	0
Appendix	1
Table of Contents	5

	Canceling TX/RX Jobs.	4-32
	Checking and Deleting	g Jobs 4-33
		Checking Transmission/Reception Results4-33
		Checking and Deleting Sending Documents Stored in Memory4-33
5 Printing and	Scanning	5-1
	Printing Documents	5-2
	Advanced Printing Fea	stures5-3
		Collate Printing5-3
		2 on 1 Combination5-4
		Two-Sided Printing5-5
	Scanning to a Comput	er (USB connection only)5-6
	Canceling Scan Jobs	5-7
		Canceling Scan Jobs to a Computer5-7









	_
Before Using the Machine	1
Document and Pa	per
Copying	2
	رد
Sending and Receiving	4
Printing and	
Scanning	5
Network	
	6
Remote UI	
	7
System Manager	
Settings	8
Maintenance	
	9
Troubleshooting	
	0
Appendix 1	1
Table of Content	-

	Checking and Deleting Jobs	5-8
	Checking and Deleting Print Jobs	5-8
	Checking Print and Scan Counts	5-8
6 Network	•••••••••••••••••••••••••••••••••••••••	6-1
	System Requirements	6-3
	Printing or Sending a Fax from a Computer	
	Basic Network Settings	
	IP Address Setting	6-4
	Interface Settings	6-6
	Communication Environment Setup	6-7
	Setting Up a Computer for Printing/Sending a Fax	6-10
	Settings from the Operation Panel	6-10
	Machine Connection Method (LPD/Raw)	6-11
	Print Server Settings	6-14









Before Using the Machine	1
Document and Pa	per 2
Copying	3
Sending and Receiving	4
Printing and Scanning	5
Network	6
Remote UI	7
System Manager Settings	8
Maintenance	9
Troubleshooting	0
Appendix 1	
Table of Content	s

	Additional Naturals Co	ttings	6 15
	Additional Network Se	TCP/IP Settings	
		Startup Time Settings	6.17
		Startup Time Settings	0-1/
	Checking Network Set	tings	6-18
	Machine Management		6-19
		Machine Management Using Web Browser (Remote UI)	6-19
		Machine Management Using NetSpot Device Installer	6-19
7 Remote UI	•••••	••••••	7-1
	System Requirements.		7-3
	Using the Remote UI		7-4
		Starting the Remote UI	7-4
	Displaying Device Stat	us and Information	7-6









Before Using the Machine	1
Document and Pap	oer 2
Copying	3
Sending and Receiving	4
Printing and Scanning	5
Network	6
Remote UI	7
System Manager Settings	8
Maintenance	9
Troubleshooting	0
Appendix 1	1
Table of Contents	
TILL (C	

	Job Management		7-7
		lanaging Print Jobs	
	Vi	iewing the Activity Log	7-8
	Managing the Address B	ook	7-9
	Customizing System Sett	ings	7-13
		ustomizing System Information	
	Import/Export Function		7-16
	Sa	aving the Address Book	7-16
	Lo	oading an Address Book	7-17
	Device Custom Settings		7-19
8 System Ma	nager Settings		8-1
	Specifying the System M	anager Settings	8-2
	Restricting Access to Des	tinations	8-3
	C	onfirming Entered Fax Numbers	8-3
		estricting Redial	









Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

1

9

10

9 Maintenance	9-
	Cleaning the Machine9-2
	Exterior9-
	Interior9-
	Fuser Roller9-
	Scanning area9-
	Replacing the Toner Cartridge
	Redistributing Toner9-1
	Replacing the Toner Cartridge with a New One9-1
	Recycling Used Cartridges9-19
	The Clean Earth Campaign9-1
	U.S.A. PROGRAM9-2
	CANADA PROGRAM-CANADA PROGRAMME9-2
	Transporting the Machine

Table of Contents









Before Using	the
Machine	

Document and Paper

3

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

10

9

Troubleshooting1	0-1
Clearing Jams1	10-3
Document Jams	.10-4
Paper Jams	.10-6
LCD Messages10)-14
Error Codes10)-20
If <load correct="" paper=""> is displayed10</load>)-22
Re-loading the Paper1	10-22
Changing the Paper Size Setting1	10-22
General Problems10)-24
Paper Feeding Problems10)-26
Fax Problems10	
Sending Problems1	10-27
Receiving Problems1	10-31

Table of Contents







Before Using the Machine	1
Document and Pap	er 2
Copying	3
Sending and Receiving	4
Printing and Scanning	5
Network	6
Remote UI	7
System Manager Settings	8
Maintenance	9
Troubleshooting	0
Appendix	1
Table of Contents	
Index	

	Copying Problems			10-37
	Printing Problems			10-40
	Telephone Problems			10-43
	Network Problems			10-44
	If a Power Failure Occu	urs		10-46
	If You Cannot Solve a	Problem		10-47
		Customer Support (U.S.A.)		10-47
		Customer Support (Canada).		10-47
I Appendix	••••••	•••••	•••••	11-1
	Machine Settings			11-3
		Printing USER DATA LIST		11-3







Before Using the	
Machine	

Document and Paper

3

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

10

Appendix

11

9

Setting Menu		11-5
	PAPER SETTINGS	11-5
	VOLUME CONTROL	
	BROADCAST	11-7
	COMMON SETTINGS	
	COPY SETTINGS	11-8
	FAX SETTINGS	
	ADDRESS BOOK SET	11-14
	PRINTER SETTINGS	
	TIMER SETTINGS	
	ADJUST./CLEANING	
	REPORT SETTINGS	11-18
	SYSTEM SETTINGS	11-20
Summary of Reports a	nd Lists	

Table of Contents







Before Using the

Document and Paper

3

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

10

Appendix

11

9

Printing Reports Automatically		11-26
	TX REPORT	11-26
	RX REPORT	
	ACTIVITY REPORT	11-28
Printing Reports and Lists Manually		11-29
Checking Remain	ning Memory	11-30
Glossary		11-31
Index		11-41

Table of Contents











Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

How to Use This Guide

Using the Top Page




Table of Contents







Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI


System Manager Settings

Maintenance

Troubleshooting

9

Using the Chapter Topic List



Returns to the last page opened. Displays the previous or next page. Returns to the top page.

Quick links to the list of things you can do, topics for each chapter, table of contents, and the index.

Table of Contents









Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

The following symbols are used throughout the manuals for the machine and indicate the warnings, cautions and notes you should keep in mind when using the machine.



WARNING

Indicates a warning that may lead to death or serious injury if not observed.



CAUTION

Explains how to avoid actions that could injure you or damage your machine.




Explains operating restrictions and how to avoid minor difficulties.

In addition, this guide uses distinctive notations to identify keys and information in the LCD:

- The keys you press appear in square brackets: [Stop/Reset].
- Information in the LCD appears in angle brackets: <LOAD PAPER>.
- The items on the PC (Menus, Menu commands, buttons etc.) appear in square brackets: [Save].

Table of Contents





Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

Legal Notices

Trademarks

Canon, the Canon logo, imageCLASS, and NetSpot are trademarks of Canon Inc.

Microsoft, Windows, Windows Server and Windows Vista are trademarks or registered trademarks of Microsoft Corporation in the U.S. and/or other countries.

All other product and brand names are registered trademarks, trademarks or service marks of their respective owners.

Copyright

Copyright © 2007 by Canon Inc. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of Canon Inc.

Disclaimer

The information in this document is subject to change without notice.

CANON INC. MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, EITHER EXPRESS OR IMPLIED, EXCEPT AS PROVIDED HEREIN, INCLUDING WITHOUT LIMITATION, THEREOF, WARRANTIES AS TO MARKETABILITY, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OF USE OR NON-INFRINGEMENT. CANON INC. SHALL NOT BE LIABLE FOR ANY DIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY NATURE, OR LOSSES OR EXPENSES RESULTING FROM THE USE OF THIS MATERIAL.

Table of Contents









Before Using the Machine

Document and Paper

3

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appondix

11

9

1 Before Using the Machine

Machine Components		1-3	
Operation Panel	••••••	1-6	
	Main Operation Panel	1-6	
	Fax Operation Panel	1-9	
LCD (Standby Mo	ode)	1-10	
	Copy Mode	1-10	
	Fax Mode	1-10	
	Scan Mode	1-10	
Toner Cartridge	••••••	1-11	
	Maintaining the Toner Cartridge	1-12	
	Checking the Toner Level	1-13	

Table of Contents







Before Using the Machine

Document and Paper

3

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

1

Telephone Line Sett	ing	.1-14
•	Setting the Telephone Line Type	. 1-14
Timer Settings	••••••	.1-15
	Setting the Sleep Mode	. 1-15
	Setting the Daylight Saving Time	. 1-16

Table of Contents









Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

10

Appendix

11

9

Machine Components



- A ADF (Automatic Document Feeder)
 Holds documents and feeds them automatically into the scanning area.
- B Slide guides Adjust to the width of the document.
- C Document feeder tray Holds documents.
- D Document delivery tray Receives documents.
- E Operation panel Controls the machine.
- Output tray

 Receives copies, prints and faxes.
- G Paper cassette Loads the paper supply.

Table of Contents









Document and Paper

Copying

Sending and Receiving


Remote UI

System Manager Settings

Maintenance

9

Troubleshooting



Scanning area Н

Scans documents from the ADF.

Platen glass

Place documents.

Output tray extension Extends for the output tray.

Paper stopper

Prevents the paper from falling off the output tray. Open the paper stopper from its original position for LTR/A4 paper. For LGL paper, pull out the output tray extension first, and then open the paper stopper.

- Slide guides for multi-purpose tray L Adjust to the width of the paper.
- Paper guide rail Holds the paper supply.
- Ν Dust cover Protects the paper supply in the paper cassette from the dirt and dust.
- Multi-purpose tray Ω Feeds paper when you insert one by one manually.
- Scanning platform Open this platform when replacing the toner cartridge or clearing paper jams.
- Main power switch Turns the power on or off.

Table of Contents








Previous





Document and Paper

Copying

Sending and

Receiving


Remote UI

System Manager Settings

Maintenance

9

Troubleshooting



- R Ethernet port Connect the network cable.
- S **USB** port Connect the USB (Universal Serial Bus) cable.
- Rear cover Τ Open this cover when clearing paper jams.
- Power socket U Connect the power cord.
- Telephone line jack Connect the telephone cable.
- External device jack Connect an external device.

Table of Contents







Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting


10

Appendix

11

Operation Panel

Main Operation Panel



- A [System Monitor] key
 Press to check fax transmission, print, copy, or report output
 status.
- B [View Settings] key
 Press to confirm settings of the copy function.
- C [COPY] key
 Press to switch to the Copy mode.

- Press to switch to the Fax mode.
- E [SCAN] key
 Press to switch to the Scan mode.
- F [Additional Functions] key
 Press to select or cancel the modes in Additional Functions.
- G [2-Sided] key
 Press to set two-sided copying.

Table of Contents







Next



Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance


9

Troubleshooting

<u> 10</u>

Appendix

11



H [Enlarge/Reduce] key

Press to enlarge or reduce copy ratio.

I [Density] key

Press to adjust the density for copy or documents you send.

J [Image Quality] key

Press to select image quality for copy or fax.

K [Collate/2 on 1] key

Press to collate copies, or press to set 2 on 1 copying.

L [Energy Saver] key

Press to set or cancel the Sleep mode manually. The key lights green when the Sleep mode is set, and goes off when the mode is canceled.

M [Stop/Reset] key

Press to stop a current job. Also, press to return the machine to the standby mode.

N Error indicator

Flashes when an error has occurred.

O Processing/Data indicator

Flashes while sending or receiving faxes. Lights when the machine has waiting jobs and stores the data in memory.



Any fax documents that have been received and are stored in the memory will be deleted if you turn off the main power switch when the Processing/Data indicator is lit.

P [Start] key

Press to start copying, scanning and sending faxes.

Q Numeric keys

Enter letters and numbers.

Table of Contents







TOP



Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance


9

Troubleshooting

10

Appendix

11



R [Tone] key
Press to switch from rotary pulse to tone dialing.

S [Clear] key
Press to clear entered alphanumeric characters.

T [+►] key
Press to increase the value for various settings. Also press to
see the next item in the menu.

U [OK] key

Press to accept a set function or mode.

Also press and hold to print a sample page when you are in the copy mode. For details, see "Printing a Sample Page," on p. 3-10. V [**◄–**] key

Press to decrease the value for various settings. Also press to see the previous item in the menu.

W LCD display

Displays messages and prompts during operation. Displays selection, text, and numbers when adjusting the settings.

X [Toner Gauge] key

Press to check the toner remaining in the toner cartridge.

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings


Maintenance

Troubleshooting

11

9

■ Fax Operation Panel



- A [Hook] key
 Press when you want to dial without lifting up the handset of the external telephone.
- B [Redial/Pause] key
 Press to redial the last dialed number when fax is standing
 by, or press to insert a pause when entering a fax number.
- C [Coded Dial] key
 Press to specify recipients registered under coded speed dialing codes.

- D [Address Book] key
 Press to search pre-registered recipients under one-touch
 speed dialing keys, coded speed dialing codes by name.
- E One-Touch Speed Dialing keys
 Press to specify recipients registered under one-touch speed
 dialing keys.

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting


Annondix

11

9


LCD (Standby Mode)

Copy Mode



- A Zoom ratio
- B Paper size
- C Quantity
- D Density
- E Image quality

Fax Mode



- A Date & Time
- B Receive mode
- C Image quality

Table of Contents

Index

Scan Mode

SCANNING MODE



- Depending on your needs, you can change the standby display which appears when the main power switch is turned on. For details, see "Setting Menu," on p. 11-5.
- When the main power switch is turned on, the LCD displays <PLEASE WAIT> until the standby display appears.
- If the machine remains idle for one minute, the display returns to the standby mode (Auto Clear Function).







TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix


11

Toner Cartridge

The lifetime of the Canon genuine starter toner cartridge which comes with the machine is approximately 1,000 pages, the Canon genuine replacement toner cartridge is approximately 2,000 pages. The page counts are on the basis of "ISO/ IEC 19752"* when printing A4 size paper with the default print density setting. The level of toner consumption varies depending on the type of documents printed. If your average document contains a lot of graphics, tables, or charts, the life of the toner cartridge will be shorter as they consume more toner. When you are replacing a toner cartridge, be sure to use a toner cartridge designed for this product. To purchase the Canon genuine replacement toner cartridge, contact your local Canon dealer or Canon Customer Care Center (U.S.A.:1-800-828-4040, Canada:1-800-652-2666).

* "ISO/IEC 19752" is the global standard related to "Method for the determination of toner cartridge yield for monochromatic electrophotographic printers and multi-function devices that may contain printer components" issued by ISO (International Organization for Standardization).

Toner Cartridge name: Canon Cartridge 104



Model Name	Туре	Supported Canon Genuine Cartridge	Print Yield
MF4270	Bundled	Canon Cartridge 104 Starter	Approx. 1,000 pages
	Replacement	Canon Cartridge 104	Approx. 2,000 pages

Table of Contents









Next

Before Using the Machine

Document and Paper

Copying

Receiving Printing and

Sending and

5

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendi

11

Maintaining the Toner Cartridge

- Keep the toner cartridge away from computer screens, disk drives, and floppy disks. The magnet inside the toner cartridge may harm these items.
- Avoid locations subject to high temperature, high humidity, or rapid changes in temperature.
- Do not expose the toner cartridge to direct sunlight or bright light for more than five minutes.
- Store the toner cartridge in its protective bag. Do not open the bag until you are ready to install the toner cartridge in the machine.
- Save the toner cartridge's protective bag in case you need to repack and transport the toner cartridge at a later date.
- Do not store the toner cartridge in a salty atmosphere or where there are corrosive gases such as from aerosol sprays.
- Do not remove the toner cartridge from the machine unnecessarily.
- Do not open the drum protective shutter on the toner cartridge. Print quality may deteriorate if the drum surface is exposed to light or is damaged.

- Always hold the toner cartridge by its handle to avoid touching the drum protective shutter.
- Do not stand the toner cartridge on end, and do not turn it upside down. If toner becomes caked in the toner cartridge, it may become impossible to free it even by shaking the toner cartridge.
- If there is a toner powder leakage, make sure not to inhale or touch the toner powder. If it comes in contact with your skin, rinse with cold water using soap. If you feel an irritation on your skin or inhale the powder, consult a doctor immediately.
- When removing the toner cartridge from the machine, make sure to remove it carefully. If not removed with care, the toner powder may scatter and come in contact with your eyes and mouth. If this happens, rinse with water and consult a doctor immediately.
- Keep the toner cartridge away from small children. If they ingest the toner powder, consult a doctor immediately.
- Do not disassemble the toner cartridge. The toner powder may scatter and come in contact with your eyes and mouth. If this happens, rinse with water and consult a doctor immediately.



CAUTION

Do not place the toner cartridge in fire. Toner powder is flammable.

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

.

Appendix

11

9

Checking the Toner Level

You can check the amount of toner remaining in the toner cartridge by pressing the [Toner Gauge] key. The toner level is displayed in the LCD at four levels.

If the toner gauge indicates that the toner is empty, it is recommended that the toner cartridge be replaced. (See "Replacing the Toner Cartridge," on p. 9-11.)

Toner full



Toner high

TONER	GAUGE	
0 % ■		100%

Toner low

TONER GAUGE
0% •••• 100%

Toner empty





To return to the standby mode, press [Stop/Reset].

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Telephone Line Setting

Setting the Telephone Line Type

The default setting is <TOUCH TONE>.

- 1. Press [Additional Functions].
- Press [◄–] or [+►] to select <FAX SETTINGS>, then press [OK].
- Press [◄–] or [+►] to select <USER SETTINGS>, then press [OK].
- **4.** Press [◄–] or [+►] to select <TEL LINE TYPE>, then press [OK].

5. Press [◄-] or [+►] to select the telephone line type, then press [OK].

<TOUCH TONE>: Tone dialing <ROTARY PULSE>: Pulse dialing



If you do not know the type of telephone line you use, contact your local telephone company.

6. Press [Stop/Reset] to return to the standby mode.

Table of Contents



k Previous

Next

TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Remote UI

Network

System Manager

Maintenance

Settings

Troubleshooting

Appendix

11

9

Timer Settings

Setting the Sleep Mode

When the machine remains idle for a certain period of time, it automatically enters the Sleep mode.
The default settings are <ON> and <5MIN.>.

- 1. Press [Additional Functions].
- Press [◄-] or [+►] to select <TIMER SETTINGS>, then press [OK].
- Press [◄–] or [+►] to select <AUTO SLEEP>, then press [OK].
- **4.** Press [◄–] or [+►] to select <ON>, then press [OK].
- Press [◄–] or [+►] to select the desired interval, then press [OK].

You can set the interval from 3 to 30 minutes (in one-minute increments).

You can also enter values using numeric keys.



The default setting is 5 minutes.

6. Press [Stop/Reset] to return to the standby mode.



- [Energy Saver] lights green when the machine enters the Sleep mode.
- To enter the Sleep mode manually, press [Energy Saver] on the operation panel.
- The machine will not enter the Sleep mode when:
 - the machine is in operation
 - the Processing/Data indicator lights or flashes
 - a message appears on the display and the Error indicator flashes
 - paper is loaded in the multi-purpose tray
 - a paper jam occurs in the machine
 - the optional handset or the handset of the external telephone is off the hook
- The machine will leave the Sleep mode when:
- you press [Energy Saver] on the operation panel
- a fax is received
- the optional handset or the handset of the external telephone is off the hook
- a print job is sent from a computer, and the print is started

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Setting the Daylight Saving Time

In some countries or areas, time is advanced throughout the summer season. This is called "Daylight Saving Time." The default setting is <OFF>.

- 1. Press [Additional Functions].
- Press [◄-] or [+►] to select <TIMER SETTINGS>, then press [OK].
- 3. Press [◄-] or [+►] to select <DAYLIGHT SV.TIME>, then press [OK].
- **4.** Press [◄–] or [+►] to select <ON>, then press [OK].
- 5. Press [◄-] or [+►] to select <START DATE/ TIME>, then press [OK].

- 6. Press [◄–] or [+►] to select <MONTH>, then press [OK].
- 7. Press [◄–] or [+►] to select the month, then press [OK].
- 8. Press [◄–] or [+►] to select <WEEK>, then press [OK].
- Press [◄–] or [+►] to select the week, then press [OK].
- **10.** Press [◄–] or [+►] to select <DAY>, then press [OK].
- **11.** Press [◄–] or [+►] to select the day, then press [OK].
- 12. Press [Additional Functions].
- **13.** Press [◄–] or [+►] to select <END DATE/TIME>, then press [OK].

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

11

9

- **14.** Press [◄–] or [+►] to select <MONTH>, then press [OK].
- **15.** Press [◄–] or [+►] to select the month, then press [OK].
- **16.** Press [◄–] or [+►] to select <WEEK>, then press [OK].
- **17.** Press [◄–] or [+►] to select the week, then press [OK].
- **18.** Press [◄–] or [+►] to select <DAY>, then press [OK].
- **19.** Press [◄–] or [+►] to select the day, then press [OK].
- **20.** Press [Stop/Reset] to return to the standby mode.

Table of Contents









Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

1'

9

2 Document and Paper

Document Rec	quirements	2-2
Scanning Area	1	2-3
Loading Docu	ments	2-4
	On the Platen Glass	2-4
	In the ADF	2-5
Paper Require	ments	2-7
Printable Area	l	2-9
Loading Pape	r	2-10
	Into the Multi-Purpose Tray	2-10
Setting Paper	Size and Type	2-13

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

ррених

Document Requirements

	Platen Glass	ADF
Туре	 Plain paper Thick documents Photographs Small documents (e.g., index cards) Special types of paper (e.g., tracing paper*1, transparencies*1, etc.) Book (Height: max. 1" (24 mm)) 	Plain paper (Multi-page documents of the same size, thickness and weight or one page documents.)
Size (W x L)	Max. 8 1/2" x 11 5/8" (Max. 216 x 297 mm)	Max. 8 1/2" x 14" (Max. 216 x 356 mm) Min. 4 1/8" x 5 7/8" (Min. 105 x 148.5 mm)
Weight	Max. 4.4 lb (2 kg)	11 to 28 lb bond (40 to 105 g/m²)
Quantity	1 sheet	Max. 35 sheets*2 (Max. 10 sheets for LGL documents)

- When copying a transparent document such as tracing paper or transparencies, use a piece of plain white paper to cover the document after placing it face-down on the platen glass.
- *2 21 lb bond (80 g/m²) paper

- Do not place the document on the platen glass or in the ADF until the glue, ink or correction fluid on the document is completely dry.
- To prevent document jams in the ADF, do not use any of the following:
- Wrinkled or creased paper
- Carbon paper or carbon-backed paper
- Curled or rolled paper
- Coated paper
- Torn paper
- Onion skin or thin paper
- Documents with staples or paper clips attached
- Paper printed with a thermal transfer printer
- Transparencies

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10.

Appendix

11

Scanning Area

Make sure your document's text and graphics fall within the shaded area in the following diagram. Note that the margin widths listed are approximate and there may be slight variations in actual use.




Table of Contents







Next

TOP

Before Using the

Document and Paper

Copying

Sending and Receiving

Remote UI

System Manager Settings


Maintenance

9


Troubleshooting

Loading Documents


- On the Platen Glass
- 1. Lift up the ADF.



Place your document face down.



3. Align the document with the appropriate paper size marks.



If your document does not match any of the paper size marks, align the center of your document with the arrow mark.

Table of Contents









Next



Document and Paper

Copying

Sending and Receiving

Printing and

Remote UI


System Manager Settings

Maintenance

9

Troubleshooting

4. Gently close the ADF.



The document is ready for scanning.

CAUTION


- When closing the ADF, be careful not to get your fingers caught, as this may result in personal injury.
- Do not press down the ADF forcefully, as this may damage the platen glass and cause personal injury.



Remove the document from the platen glass when scanning is complete.

In the ADF

1. Fan the document stack and even the edges.



2. Adjust the slide guides to the width of the documents.




Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9


Troubleshooting

10

Appendix

11

3. Neatly place the documents face up in the document feeder tray.



The document is ready for scanning.



- Do not add or remove documents while they are being scanned.
- When scanning is complete, remove the documents from the document delivery tray to avoid paper jams.
- Avoid using ADF to scan the same document more than 30 times. When scanned repeatedly, documents can become folded or torn, which may cause paper jams.
- If the feeder rollers are soiled from scanning a document written in pencil, clean them. (See "Cleaning the Machine," on p. 9-2.)

Table of Contents







Next

TOP

Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Paper Requirements

	Paper cassette	Multi-purpose tray		
Size	LTR, LGL, A4, B5, A5, E	xecutive, Envelope (COM10 (#10),		
(W x L)	Monarch, DL, ISO-C5 (Monarch, DL, ISO-C5 (6 3/8" x 9" (162 x 229 mm))), Oficio,		
	Brazil-Oficio, Mexico-C	Brazil-Oficio, Mexico-Oficio, Folio, Government-LTR,		
	Government-LGL, Foo	Government-LGL, Foolscap (3" x 5" to 8 1/2" x 14" (76 x		
	127 to 216 x 356 mm))		
Weight	16 to 43 l	16 to 43 lb bond (60 to 163 g/m²)		
Quantity	Max. 250 sheets	Max. 1 sheet		
	(Height: max. 1" (25 m	m))		
Туре	Plain Paper, Plain Pape	er L, Heavy Paper, Heavy Paper H,		
	Transparency			



The default paper size is LTR. If you use a different paper size, you must change the paper size settings. (See "Setting Paper Size and Type," on p. 2-13.)

• To prevent paper jams, do not use any of the following:

- Wrinkled or creased paper
- Curled or rolled paper
- Coated paper
- Torn paper
- Damp paper
- Very thin paper
- Paper which has been printed on using a thermal transfer printer (Do not copy on the reverse side.)

• The following types of paper do not print well:

- Highly textured paper
- Very smooth paper
- Shiny paper

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

- Make sure the paper is free from dust, lint, and oil stains.
- Be sure to test paper before purchasing large quantities.
- Store all paper wrapped and on a flat surface until ready for use. Keep opened packs in their original packaging in a cool, dry location.
- Store paper at 64.4°F-75.2°F (18°C-24°C), 40%-60% relative humidity.
- Use only the transparencies designed for laser printers.
 Canon recommends you to use Canon type transparencies with this machine.

Table of Contents









TOP

Before Using the

Document and Paper

Copying

3

Sending and Receiving

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Printable Area

The shaded area indicates the approximate printable area of LTR paper and envelope. Note that the margin widths listed are approximate and there may be slight variations in actual use.




Table of Contents







Before Using the Machine

Document and Paper

Copying

_

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Loading Paper

To load paper in the paper cassette, see "Set Up the Machine," in the Starter Guide.

Into the Multi-Purpose Tray

Use the multi-purpose tray when you want to copy or print on the different paper which is in the paper cassette. Load paper one by one in the multi-purpose tray.



- The paper in the multi-purpose tray is fed prior to the paper in the paper cassette.
- The recommended envelopes are COM10 (#10), MONARCH, DL, and ISO-C5. Using other envelopes may affect the quality of the printout.
- Make sure to set the correct paper size in the printer driver. (See <u>Online</u> Help.)
- When printing received documents or reports, paper can be fed only from the paper cassette. If paper is loaded into the multi-purpose tray, <REMOVE MP PAPER> appears.

1. Spread the paper guides a little wider than the actual paper width.




Table of Contents









Next

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9


Troubleshooting

10

Appendix


11

2. When setting paper, gently insert the paper into the multi-purpose tray with the print side up.





When you load paper with a logo on, position the paper with the print side up (logo side) and insert it so that the top of the paper feeds first in the multi-purpose tray.



When setting an envelope, gently insert the envelope into the multi-purpose tray with the print side up and the right edge (i.e., closer to the stamp) first.




Table of Contents







ТОР



Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9


Troubleshooting

10

Appendix

11

3. Slide the paper guides so that they fit to both sides of the paper.





If the paper guides do not fit the size of the paper, the print quality may be deteriorated.

4. Specify the size and the type of the paper you load.

For details on how to specify the paper size and type, see "Setting Paper Size and Type," on p. 2-13.

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

1

Setting Paper Size and Type

The default setting is <LTR> and <PLAIN PAPER>. When you place other sizes and/or types of paper, follow this procedure to change the settings.

The procedure is same for the paper cassette and multipurpose tray except for selecting the paper cassette or multipurpose tray in step 3 and 6.

- Press [Additional Functions].
- 2. Press [◄—] or [+▶] to select <PAPER SETTINGS>, then press [OK].
- Press [◄–] or [+►] to select <CASSETTE> or <MP TRAY>, then press [OK].
- **4.** Press [◄–] or [+►] to select <PAPER SIZE>, then press [OK].

Press [◄–] or [+►] to select the paper size, then press [OK].

You can select from the following paper sizes: <LTR>, <LGL>, <A4>, <B5>, <A5>, <EXECUTIVE>, <COM10>, <MONARCH>, <DL>, <ISO-C5>, <OFICIO>, <BRAZIL-OFICIO>, <MEXICO-OFICIO>, <FOLIO>, <GOVERNMENT-LETTER>, <GOVERNMENT-LEGAL>, <FOOLSCAP>



The available paper sizes will vary depending on the country where the unit was purchased.

- 6. Press [◄–] or [+►] to select <CASSETTE> or <MP TRAY>, then press [OK].
- Press [◄–] or [+►] to select <PAPER TYPE>, then press [OK].



If you have selected <B5>, <A5>, <EXECUTIVE>, <COM10>, <MONARCH>, <DL> or <ISO-C5> for the paper size in step 5, <PAPER TYPE> is not displayed. Skip to step 8.

Table of Contents









TOP

Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

8. Press [◄–] or [+►] to select the paper type, then press [OK].

You can select from the following paper types: <PLAIN PAPER> or <PLAIN PAPER L>*1 for Plain paper (17 lb to 24 lb $(64 \text{ g/m}^2 \text{ to } 90 \text{ g/m}^2))$

<HEAVY PAPER> or <HEAVY PAPER H>*2 for Heavy paper (Paper cassette: 28 lb to 34 lb (105 g/m² to 128 g/m²), Multi-purpose tray: 28 lb to 43 lb (105 g/m² to 163 g/m²)) or Envelope <TRANSPARENCY> for Transparency

- *1 If paper curls excessively when printed with <PLAIN PAPER> selected, select < PLAIN PAPER L>.
- *2 If print fixing is not sufficient when printed with <HEAVY PAPER> selected, select < HEAVY PAPER H>.
- 9. Press [Stop/Reset] to return to the standby mode.

Table of Contents









Before Using the

Document and Paper

3

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

10

Appendix

11

9

3 Copying

Basic Copying Method	3-2
Scan Settings	3-3
Image Quality	
Density	
Zoom Ratio	3-4
Advanced Copy Features	3-6
Collate Copy	3-6
2 on 1 Combination	3-7
Two-Sided Copy	3-8
Printing a Sample Page	3-10
Canceling Copy Jobs	3-11

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Basic Copying Method

Follow this procedure to make a copy.

1. Set documents.

Place the document on the platen glass or load it in the ADF. For documents you can copy, see "Document Requirements," on p. 2-2.

2. Press [COPY].



When you are in the copy mode and press and hold [OK], a sample page will be printed. For details, see "Printing a Sample Page," on p. 3-10.

- 3. Use the numeric keys to enter the desired copy quantity (1 to 99).
- 4. Press [Start].

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Appendix

11

Scan Settings

Before pressing [Start] to begin copying, you can adjust the settings to better suit the document to be scanned. These settings return to the default values if the machine remains idle for a certain period of time or if you press [Stop/Reset].

Image Quality

The default setting is <TEXT/PHOTO>.

- 1. Press [COPY].
- 2. Press [Image Quality] repeatedly to select the document type.
 - <TEXT/PHOTO>: For documents that contain text and photos.
 - <TEXT>: For text documents.
 - <PHOTO>: For documents that contain fine text or photos.
 - <TEXT/PHOTO+>: For documents that contain fine text and photos.



Copy density automatically changes to the manual mode when <TEXT/PHOTO>, <PHOTO> or <TEXT/PHOTO+> is set.

Density

You can adjust the density to the most appropriate level for the document either automatically or manually. The default setting is <MANUAL> (5).

Adjusting Automatically

- 1. Press [COPY].
- 2. Press [Density] repeatedly to select <AUTO>, then press [OK].



The image quality is automatically set to <TEXT>.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting


Appendix

11

9

Adjusting Manually

- 1. Press [COPY].
- 2. Press [Density] repeatedly to select the manual mode.
- 3. Press [◄–] or [+►] to adjust the copy density, then press [OK].



[◄━]: to make dark documents lighter

 $[+ \triangleright]$: to make light documents darker

⊘ NOTE

- To cancel all settings, press [Stop/Reset].
- When you switch the mode by pressing the mode keys such as [FAX], all settings will be also canceled. If you want to keep the settings, set the density as follows:

[Additional Functions] \rightarrow <COPY SETTINGS> \rightarrow <STANDARD SETTINGS> \rightarrow <DENSITY> \rightarrow <MANUAL> (See "STANDARD SETTINGS," on p. 11-8.)

Zoom Ratio

The default setting is <100%>.

Preset Zoom

You can enlarge or reduce documents from one standard paper size to another.

- 1. Press [COPY].
- 2. Press [Enlarge/Reduce].
- 3. Press [◄–] or [+►] to select the copy ratio, then press [OK].
 - 200% MAX.
 - 129% STMT → LTR
 - 100%
 - 78% LGL → LTR
 - 64%
 - 50% MIN.

⊘ NOTE

When <PAPER SIZE GROUP> in the <COPY SETTINGS> menu is set to <A> or <AB>, the preset copy ratios change as follows: A: 50%, 70%, 100%, 141%, 200%

AB: 50%, 70%, 81%, 86%, 100%, 115%, 122%, 141%, 200%

Table of Contents









TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Zoom Designation

You can reduce or enlarge images by any copy ratio, in 1% increments. The available copy ratios are from 50% to 200%.

- 1. Press [COPY].
- 2. Press [Enlarge/Reduce] twice.
- **3.** Enter the copy ratio with the numeric keys, then press [OK].

You can also use $[\blacktriangleleft -]$ or $[+ \blacktriangleright]$ to adjust the zoom ratio. To increase the zoom ratio, press $[+ \blacktriangleright]$. To decrease the zoom ratio, press $[\blacktriangleleft -]$.



To return the copy ratio to 100%, press [Enlarge/Reduce] repeatedly to display <100%>, then press [OK].

Table of Contents







TOP

Before Using the Machine **Document and Paper**

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Advanced Copy Features

Collate Copy

You can copy documents collated into sets arranged in page order. This feature can be used together with both "Two-Sided Copy" (see p. 3-8) and "2 on 1 Combination" (see p. 3-7).

1. Set documents.

Place the first page on the platen glass if you are not using the ADF.

2. Press [COPY].



If <AUTO COLLATE> is set to <ON> in <STANDARD SETTINGS> in <COPY SETTINGS>, skip to step 4.

3. Press [Collate/2 on 1] repeatedly to select <COLLATE>, then press [OK].

If you want to use <COLLATE> with "2 on 1 Combination" (see p. 3-7) at the same time, select <COLLATE+2 ON 1>, then press [OK]. If you want to use with "Two-Sided Copy" at the same time, go to step 3 on p. 3-8.

4. Use the numeric keys to enter the desired copy quantity (1 to 99).

5. Press [Start].

When the documents are loaded in the ADF, collate copying starts and no further operation is required.

6. Place the next page of the document on the platen glass, then press [Start].

Repeat this step to scan all pages.

7. Press [OK].

The machine prints the remaining sets of copies.



- To cancel all settings, press [Stop/Reset].
- When you switch the mode by pressing the mode keys such as [FAX], all settings will be also canceled. If you want to keep the settings, store the settings in <STANDARD SETTINGS> in <COPY SETTINGS>, see "STANDARD SETTINGS," on p. 11-8.
- When scanning multiple page documents, <MEMORY FULL> may appear in the LCD and scanning may be canceled. If this happens, press [OK] to return to standby mode, and print, send, or delete any documents stored in memory.



Back Previous

Next

TOP



Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance


9

Troubleshooting

2 on 1 Combination

2 on 1 combination automatically reduces two-page document to fit on the selected paper size. This feature can be used together with both "Collate Copy" (see p. 3-6) and "Two-Sided Copy" (see p. 3-8).

Originals



Set documents.

Place the first page on the platen glass if you are not using the ADF.

- Press [COPY].
- 3. Press [Collate/2 on 1] repeatedly to select <2 ON 1>, then press [OK].

If you want to use <2 ON 1> with "Collate Copy" (see p. 3-6) at the same time, select <COLLATE+2 ON 1>, then press [OK]. If you want to use with "Two-Sided Copy" at the same time, go to step 3 on p. 3-8.

4. Use the numeric keys to enter the desired copy quantity (1 to 99).

5. Press [Start].

When you set the document on the platen glass, press [Start] for each page. When scanning is complete, press [OK].



- If you press [OK] without scanning the second page, only the first page will be printed on the left side of the paper.
- A maximum of 1/8" (4 mm) margin will be produced between the two reduced documents in 2 on 1 combination copying.
- To cancel all settings, press [Stop/Reset].
- When you switch the mode by pressing the mode keys such as [FAX], all settings will be also canceled. If you want to keep the settings, store the settings in <STANDARD SETTINGS> in <COPY SETTINGS>, see "STANDARD SETTINGS," on p. 11-8.

Table of Contents



Back Previous

Ne



TOP



Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11


9

■ Two-Sided Copy

Two-sided copying enables you to make two-sided copies from one-sided documents. This feature can be used together with both "Collate Copy" (see p. 3-6) and "2 on 1 Combination" (see p. 3-7).

Copy

Portrait Oriented Documents Book Type selected Copy Calendar Type selected





Paper used to make two-sided copies must conform to the following specifications:

- Paper size: LTR and A4
- Paper weight: 17 to 21 lb (64 to 80 g/m²)
- 1. Set documents.

Place the first page on the platen glass if you are not using the ADF.

- 2. Press [COPY].
- 3. Press [2-Sided] repeatedly to select <ON>, then press [OK].
- 4. Press [◄—] or [+▶] to select <BOOK TYPE> or <CALENDAR TYPE>, then press [OK].

<BOOK TYPE>: The front and back sides of the copy will have the same top-bottom orientation.

<CALENDAR TYPE>: The front and back sides of the copy will have opposite top-bottom orientations.



For the landscape oriented documents, the front and back sides of the copy will have the opposite top-bottom orientation when <BOOK TYPE> is selected.

When <CALENDAR TYPE> is selected, the front and back sides of the copy will have the same top-bottom orientation.

Table of Contents









TOP

Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

5. Use the numeric keys to enter the desired copy quantity (1 to 99).

6. Press [Start].

When you set the document on the platen glass, press [Start] for each page. When scanning is complete, press [OK].



- To cancel all settings, press [Stop/Reset].
- When you switch the mode by pressing the mode keys such as [FAX], all settings will be also canceled. If you want to keep the settings, store the settings in <STANDARD SETTINGS> in <COPY SETTINGS>, see "STANDARD SETTINGS," on p. 11-8.
- Instead of performing step 4, you can just press [OK]. In this case, the machine makes <BOOK TYPE> copies.

Table of Contents









TOP

Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Printing a Sample Page

This machine provides you to print a sample page. You can use this function to test how the printouts will look with current settings.



- The paper size must be LTR.
- The paper type must be Plain Paper (17 to 21 lb (64 to 80 g/m²)).
- If the paper setting is not appropriate or the paper is not loaded correctly, printing does not start without any error massages.
- You cannot cancel printing a sample page once printing has started.
- You cannot use this function while making copies, scanning documents, or printing reports or lists.
- Press [COPY].
- Press and hold [OK].

The sample page will be printed on the both sides of the paper.

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

1

Appendix

11

9

Canceling Copy Jobs

Follow this procedure to cancel an outgoing job.

- 1. Press [Stop/Reset].
- 2. When the <CANCEL COPYING?> message appears, press [◄-] to select <YES>.

CANCEL COPYING?

The job is canceled, and the copy quantity is reset.

Table of Contents









Before Using the Machine

Document and Paper

3

9

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

1

4 Sending and Receiving

Basic Sending Metho	d	4-4
Scan Settings	••••••	4-5
	Image Quality	4-5
	Density	4-5
Storing/Editing Address Book		4-6
	Storing/Editing One-Touch Speed Dialing Keys/ Coded Speed Dialing Codes	4-7
	Storing/Editing Recipients for Group Dialing	4-9
Specifying Recipients	5	4-12
	Using One-Touch Speed Dialing Keys	4-12
	Using Coded Speed Dialing Codes	4-13
	Group Dialing	4-14
	Using Address Book Key	4-14

Table of Contents









Before Using the Machine	1
Document and Pa	per 2
Copying	3
Sending and Receiving	4
Printing and Scanning	5
Network	6
Remote UI	7
System Manager Settings	8
Maintenance	9

Manual Sending	•••••••••••	4-16
Advanced Sending Features		4-17
	Broadcasting	4-17
PC Faxing	••••••	4-18
Fax Dialing Features	••••••••	4-19
	Switching Temporarily to Tone Dialing	4-19
	Redialing	4-20
	Checking Dialing Line	4-21
	Dialing an Overseas Number (With Pauses)	4-22
Basic Receiving Metho	od	4-23

Table of Contents

Troubleshooting









Before Using the Machine	1
Document and Pa	per 2
Copying	3
Sending and Receiving	4
Printing and Scanning	5
Network	6
Remote UI	7
System Manager Settings	8
Maintenance	9
Troubleshooting	0

eceiving Features4-	-24
FAX/TEL: Optional Settings4-	-24
DRPD: Optional Settings 4-	
Manual Reception4-	-25
Memory Reception4-	
Memory Lock Reception4	-26
Remote Reception4	
Selecting the Receive Mode for Printing4	-29
Reception Restriction4-	-30
Printing Received Documents4-	-30
anceling TX/RX Jobs4-	-32
necking and Deleting Jobs4-	-33
Checking Transmission/Reception Results 4-	
Checking and Deleting Sending Documents Stored in Memory4-	

Table of Contents

Index

Appendix







TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

rinting and canning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Basic Sending Method

Follow this procedure to send faxes.

1. Set documents.

Place the first page on the platen glass if you are not using the ADF.

2. Press [FAX].

If you want to adjust the image quality and density, see "Scan Settings," on p. 4-5.

3. Enter the fax number with the numeric keys.

You can also specify the fax number with one-touch speed dialing keys, coded speed dialing codes or [Address Book] key. (See "Specifying Recipients," on p. 4-12.)

4. Press [Start].

When you set the documents on the platen glass, press [Start] for each document. When scanning is complete, press [OK] to start dialing.

Table of Contents





Previous

Next

Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Scan Settings

You can adjust the image quality and density of the document you send. The higher image quality you set, the better the output will be, but the longer the transmission will take.

■ Image Quality


The default setting is <STANDARD>.

- Press [FAX].
- 2. Press [Image Quality] repeatedly to select the resolution, then press [OK].
 - <STANDARD>: for most text-only documents. (200 x 100 dpi)
 - <FINE>: for fine-print documents (the resolution is twice that of
 - <STANDARD>). (200 x 200 dpi)
 - <PHOTO>: for documents that contain photographs (the resolution is twice that of <STANDARD>). (200 x 200 dpi)
 - <SUPER FINE>: for documents that contain fine print and images (the resolution is four times that of <STANDARD>). (200 x 400 dpi)

Density

The default setting is (5).

- 1. Press [FAX].
- 2. Press [Density].
- 3. Press [◄–] or [+►] to adjust the density, then press [OK].



[<-]: to make dark documents lighter.

[+▶]: to make light documents darker.

M NOTE

These settings return to the default values after all documents are scanned. If you want to keep the settings, set the image quality and/or density as follows:

[Additional Functions] \rightarrow <FAX SETTINGS> \rightarrow <USER SETTINGS> \rightarrow <STANDARD SETTINGS> → <Image Quality> or <DENSITY> (See "STANDARD SETTINGS," on p. 11-9.)

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Storing/Editing Address Book

This machine provides you with various ways to specify the fax/telephone numbers besides using the numeric keys. You can register fax/telephone numbers to the Address Book. Once you have registered fax/telephone numbers using these functions, you can specify the fax/telephone numbers by simply pressing one or a combination of keys:

• Using One-Touch Speed Dialing Key (p. 4-12)

You can specify fax/telephone numbers by pressing one-touch speed dialing keys. You can register up to 8 one-touch speed dialing keys, including group dialing.

Using Coded Speed Dialing (p. 4-13)

You can specify fax/telephone numbers by pressing [Coded Dial] followed by two-digit code. You can register up to 100 coded speed dialing codes.

• Using Group Dialing (p. 4-14)

You can specify groups of fax/telephone numbers registered in one-touch speed dialing keys. You can register up to 50 fax/telephone numbers in a group dialing.

● Using Address Book Key (p. 4-14)

You can specify fax/telephone numbers by pressing [Address Book] and searching a fax/telephone number from Address Book.



- Recipients stored in the Address Book can be exported to your computer as a file, which can be imported into the machine. For information on exporting the Address Book, see Chapter 7, "Remote UI."
- For easy reference, print out the list of recipients registered in onetouch speed dialing keys or coded speed dialing codes. (See "REPORT SETTINGS," on p. 11-18.)

Table of Contents







Next

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Storing/Editing One-Touch Speed Dialing Keys/Coded Speed Dialing Codes

Registering One-Touch Speed Dialing Keys/Coded Speed Dialing Codes

- 1. Press [Additional Functions].
- Press [◄–] or [+►] to select <ADDRESS BOOK SET.>, then press [OK].
- 3. Press [◄–] or [+►] to select <1-TOUCH SPD DIAL> or <CODED DIAL>, then press [OK].
- 4. Press [◄—] or [+▶] to select a one-touch speed dialing key (01 to 08) or coded speed dialing code (00 to 99) for which you want to register the fax/telephone number, then press [OK].

You can also select a one-touch speed dialing key or coded speed dialing code by pressing the corresponding one-touch speed dialing key, or [Coded Dial] followed by the desired two-digit code.

Enter the recipient name (max. 20 letters, including spaces) with the numeric keys, then press [OK].

Ex.

NAME

[A]

Can

6. Enter the fax/telephone number you register (max. 50 digits, including spaces and pauses) with the numeric keys, then press [OK].

TEL NUMBER ENTRY
012XXXXXXX

To register another one-touch speed dialing key or coded speed dialing code, repeat the procedure from step 4.

7. Press [Stop/Reset] to return to the standby mode.

Editing One-Touch Speed Dialing Keys/Coded Speed Dialing Codes

- 1. Press [Additional Functions].
- 2. Press [◄—] or [+▶] to select <ADDRESS BOOK SET.>, then press [OK].

Table of Contents









Next

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

- 3. Press [◄–] or [+►] to select <1-TOUCH SPD DIAL> or <CODED DIAL>, then press [OK].
- 4. Press [◄–] or [+ ►] to select the one-touch speed dialing key (01 to 08) or coded speed dialing code (00 to 99) you want to edit, then press [OK].

You can also select a one-touch speed dialing key or coded speed dialing code by pressing the corresponding one-touch speed dialing key, or [Coded Dial] followed by the two-digit code.

Press [+▶] repeatedly to go to the character you want to change, then press [Clear].

To delete the entire entry, press and hold [Clear].

- 6. Enter a new character with the numeric keys, then press [OK].
- 7. Press $[+ \triangleright]$ repeatedly to go to the wrong digit, then press [Clear] to delete it.

To delete the entire entry, press and hold [Clear].

- 8. Enter a new number with the numeric keys, then press [OK].
- 9. Press [Stop/Reset] to return to the standby mode.

Deleting One-Touch Speed Dialing Keys/Coded Speed Dialing Codes

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <ADDRESS BOOK SET.>, then press [OK].
- 3. Press [◄–] or [+►] to select <1-TOUCH SPD DIAL> or <CODED DIAL>, then press [OK].
- **4.** Press [◄–] or [+►] to select the one-touch speed dialing key (01 to 08) or coded speed dialing code (00 to 99) you want to delete, then press [OK].

You can also select a one-touch speed dialing key or coded speed dialing code by pressing the corresponding one-touch speed dialing key, or [Coded Dial] followed by the two-digit code.

5. Press [OK].



le.

Previous

Next

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

6. Press and hold [Clear] to delete the entire entry, then press [OK].



If you delete the fax/telephone number, the registered name is cleared automatically.

- 7. Press [Stop/Reset] to return to the standby mode.
- Storing/Editing Recipients for Group Dialing



The recipients must be registered in one-touch speed dialing keys or coded speed dialing codes beforehand.

Registering Recipients for Group Dialing

- 1. Press [Additional Functions].
- Press [◄–] or [+►] to select <ADDRESS BOOK SET.>, then press [OK].
- 3. Press [◄–] or [+►] to select <GROUP DIAL>, then press [OK].

4. Press [◄–] or [+►] to select an empty one-touch speed dialing key that you want to set as the group dialing, then press [OK].

You can also select a one-touch speed dialing key by pressing the corresponding one-touch speed dialing key.

5. Enter the group name (max. 20 letters, including spaces) with the numeric keys, then press [OK].

To register another group, repeat the procedure from step 4.



6. Select the recipients you want to register in the group (max. 50 recipients) until all recipients are registered, then press [OK].

To enter a recipient stored under a one-touch speed dialing key, press the desired one-touch speed dialing key.

To enter a recipient stored under a coded speed dialing code, press [Coded Dial], then enter the two-digit code with the numeric keys.

For multiple entries, press [Coded Dial] between each entry.



You can review the recipients which have been already entered with $[\blacktriangleleft -]$ or $[+ \blacktriangleright -]$.









Next

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

7. Press [Stop/Reset] to return to the standby mode.

Adding New Recipients to Group

- 1. Press [Additional Functions].
- Press [◄-] or [+►] to select <ADDRESS BOOK SET.>, then press [OK].
- Press [◄–] or [+►] to select <GROUP DIAL>, then press [OK].
- **4.** Press [◄–] or [+►] to select a group to edit, then press [OK].

You can specify a group to edit by pressing the corresponding one-touch speed dialing key.

- **5.** Press [OK].
- **6.** Select the recipient you want to add to the group, then press [OK].

For details on specifying a recipient from Address Book, see "Registering Recipients for Group Dialing," on p. 4-9.

7. Press [Stop/Reset] to return to the standby mode.

Deleting Recipients from Group

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <ADDRESS BOOK SET.>, then press [OK].
- Press [◄-] or [+►] to select <GROUP DIAL>, then press [OK].
- 4. Press [◄–] or [+►] to select a group to edit, then press [OK].

You can specify a group to edit by pressing the corresponding one-touch speed dialing key.

- **5.** Press [OK].
- 6. Press [◄-] or [+►] to display the recipient you want to delete from the group, then press [Clear].

Repeat this step if you want to delete another recipient.

- **7.** Press [OK].
- 8. Press [Stop/Reset] to return to the standby mode.

Table of Contents











Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Changing Group Name

- Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <ADDRESS BOOK SET.>, then press [OK].
- 3. Press [◄–] or [+►] to select <GROUP DIAL>, then press [OK].
- **4.** Press [◄–] or [+►] to select a group to edit, then press [OK].

You can specify a group to edit by pressing the corresponding onetouch speed dialing key.

5. Press [+▶] repeatedly to go to the character you want to change, then press [Clear].

To delete the entire name, press and hold [Clear].

- **6.** Enter a new character with the numeric keys, then press [OK].
- **7.** Press [OK].
- **8.** Press [Stop/Reset] to return to the standby mode.

Deleting Group Dialing

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <ADDRESS BOOK SET.>, then press [OK].
- 3. Press [◄–] or [+►] to select <GROUP DIAL>, then press [OK].
- **4.** Press [◄–] or [+►] to select a group to delete, then press [OK].

You can specify a group to delete by pressing the corresponding one-touch speed dialing key.

- 5. Press [OK].
- 6. Press [Clear] repeatedly until all recipients are deleted, then press [OK].



When you delete all recipients, the registered name is cleared automatically.

7. Press [Stop/Reset] to return to the standby mode.







Before Using the Machine

Document and Paper

Copying

_

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Specifying Recipients

Follow the procedure below to send documents to registered recipients.

■ Using One-Touch Speed Dialing Keys



To use this feature, you must register recipients in one touch speed dialing keys beforehand. (See "Storing/Editing Address Book," on p. 4-6.)

1. Set documents.

Place the first page on the platen glass if you are not using the ADF.

2. Press [FAX].

If you want to adjust the image quality and density, see "Scan Settings," on p. 4-5.

3. Press the desired one-touch speed dialing keys (01 to 08).

If you pressed a wrong key, press [Stop/Reset] and try again.

4. Press [Start].

When you set the documents on the platen glass, press [Start] for each document. When scanning is complete, press [OK] to start sending.

Table of Contents







Next

TOP

Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Using Coded Speed Dialing Codes

You can specify up to 100 recipients using coded speed dialing codes.



To use this feature, you must register recipients in coded speed dialing codes beforehand. (See "Storing/Editing Address Book," on p. 4-6.)

1. Set documents.

Place the first page on the platen glass if you are not using the ADF.

Press [FAX].

If you want to adjust the image quality and density, see "Scan Settings," on p. 4-5.

Press [Coded Dial].

4. Enter the desired two-digit code (00 to 99) with the numeric keys.

> **=** 0 1 2 X X X X X X X [* 0 1] CANON

If you entered a wrong code, press [Stop/Reset], then try again from step 3.

5. Press [Start].

When you set the documents on the platen glass, press [Start] for each document. When scanning is complete, press [OK] to start sendina.

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Group Dialing



To use this feature, you must register recipients in a group dialing beforehand. (See "Storing/Editing Address Book," on p. 4-6.)

1. Set documents.

Place the first page on the platen glass if you are not using the ADF.

2. Press [FAX].

If you want to adjust the image quality and density, see "Scan Settings," on p. 4-5.

3. Press the one-touch speed dialing key under which the desired group dialing is registered.

If you pressed a wrong key, press [Stop/Reset], and perform step 3 again.

4. Press [Start].

When you set the documents on the platen glass, press [Start] for each document. When scanning is complete, press [OK] to start sending.

Using Address Book Key

Address book dialing enables you to search for a particular recipient registered in the machine. This is useful when you forget which one-touch speed dialing key or coded speed dialing code the recipient you want is registered under.

You can either go through all the recipients registered in the machine (LIST), or look up a particular one by their name (SEARCH).

Listing All Recipients

1. Set documents.

Place the first page on the platen glass if you are not using the ADF.

2. Press [FAX].

If you want to adjust the image quality and density, see "Scan Settings," on p. 4-5.

3. Press [Address Book].

If no recipient is registered for speed dialing, <NOT REGISTERED> is displayed.

4. Press [◄–] or [+►] to select <LIST>, then press [OK].

Table of Contents







Previous

Next

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

5. Press [◄–] or [+►] to find the required recipient.

- The recipients are listed in the order of one-touch speed dialing keys (01 to 08), and coded speed dialing codes (00 to 99).
- For a one-touch speed dialing key or coded speed dialing code with no recipient name registered, their fax number is displayed.

6. Press [Start].

When you set the documents on the platen glass, press [Start] for each document. When scanning is complete, press [OK] to start dialing.

Looking Up a Recipient

1. Set documents.

Place the first page on the platen glass if you are not using the ADF.

2. Press [FAX].

If you want to adjust the image quality and density, see "Scan Settings," on p. 4-5.

3. Press [Address Book].

If no recipient is registered for speed dialing, <NOT REGISTERED> is displayed.

- **4.** Press [◄–] or [+►] to select <SEARCH>, then press [OK].
- 5. Use the numeric keys to enter up to 10 first characters of the recipient's name, then press [OK].



- Enter uppercase letters for a recipient registered in uppercase letters and enter lowercase letters for a recipient registered in lowercase letters.
- When the search is complete, the number of recipients that match the characters you entered is displayed in parentheses.
- Press [Clear] to run a new search.
- 6. Press [◄–] or [+►] to find the required recipient.

7. Press [Start].

When you set the documents on the platen glass, press [Start] for each document. When scanning is complete, press [OK] to start dialing.

Table of Contents









Next



Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Manual Sending

Use manual sending when you want to talk to the recipient before sending a document, or if the recipient does not have a fax machine that can receive automatically.



- You cannot use the platen glass for manual sending.
- You cannot use group dialing for manual sending.
- Connect an external telephone to the machine if you want to talk to the recipient before sending a document.

For details on how to connect an external telephone to the machine, see "Before FAX Setting," in the Starter Guide.

- Load the document in the ADF.
- Press [FAX].

If you want to adjust the image quality and density, see "Scan Settings," on p. 4-5.

4. Press [Hook] or pick up the handset of your external telephone.

If you press [Hook], you can temporarily adjust the monitor tone volume with $[\blacktriangleleft -]$ and $[+ \vdash]$.

Dial the recipient's fax/telephone number.



Make sure to confirm the dial tone before entering a fax/telephone number. If you enter the number before the dial tone can be heard, the call may not connect, or the wrong number may be dialed.

6. Talk through the handset to the recipient.

If you press [Hook] in step 4, you can pick up the handset when you hear the recipient's voice.

If you hear a high-pitched signal instead of the recipient's voice, go to step 8.

- 7. Ask the recipient to set their fax machine to receive faxes.
- **8.** When you hear a high-pitched signal, press [Start], then hang up the handset.

Table of Contents





Previous

Next

Before Using the Machine

Document and Paper

Copying

Receiving

Sending and

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Advanced Sending Features

The machine provides the broadcasting feature as an additional fax mode.

Broadcasting

Broadcasting enables you to send the same document to multiple recipients.



- A maximum of 124 recipients can be specified at the same time. (Out of the 124 recipients, 16 numbers can be specified with the numeric keys.) If you specify a group, which is made up of several recipients, each recipient in the group is counted as a separate recipient.
- If you frequently send documents to multiple recipients, it is recommended that you store those recipients as a group.

Set documents.

Place the first page on the platen glass if you are not using the ADF.

Press [Additional Functions].

- 3. Press [◄–] or [+►] to select <BROADCAST>, then press [OK].
- **4.** Specify the recipient(s), then press [OK].

Use the numeric keys, one touch speed dialing keys, coded speed dialing codes or [Address Book] key to specify recipients. Be sure to press [OK] after entering the recipient's number if you use the numeric keys. You can enter up to 16 different fax numbers using the numeric keys.

5. Repeat step 4 to enter all required recipients.

To check all the specified recipients, press [◄–] or [+►] to scroll the display.

6. Press [Start].

When you set the documents on the platen glass, press [Start] for each document. When scanning is complete, press [OK] to start dialing.

Table of Contents









Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

11

PC Faxing

Follow this procedure to send a fax from your computer.

Make sure that the fax driver is installed. To check if the driver is installed, see "Software Settings with Computer," in the Starter Guide.

For details on the fax driver settings, see Online Help.




How to display the print screen or items on the screen may vary depending on your application and/or OS.

- 1. From an open document on an application, click [File] > [Print].
- 2. Select the fax icon ([Canon MF4200 Series (FAX)]), then click [Print] or [OK].
- 3. Specify the name and fax number in [Sending Settings], then click [Add to Recipient List].
- 4. Click [OK] in the Fax Sending Settings.

Table of Contents







Next

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Fax Dialing Features

Switching Temporarily to Tone Dialing

If your machine is set for pulse dialing, use the procedure below to switch to tone dialing to use information services (e.g., banks, airline reservations, and hotel reservations).



To talk to the other party, you will need to connect an external telephone to the machine.

- Press [FAX].
- Press [Hook].



Make sure to confirm the dial tone before entering a fax number. If you enter the number before the dial tone can be heard, the call may not be connected, or the wrong number may be dialed.

- 3. Use the numeric keys to dial the required information service.
- 4. When the recorded message of the information service answers, press [Tone] to switch to tone dialing.
- 5. Use the numeric keys to enter the numbers requested by the information service.
- **6.** If you want to receive faxes, press [Start]. If you are using the external telephone, hang up the handset after pressing [Start].

Table of Contents





Previous



TOP

Before Using the Machine

Document and Paper

Copying

Sending and

Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Redialing

Redialing can be done manually or automatically. For automatic redialing, you can set how many times the machine redials and the time between redials.

Redialing Manually

1. Set documents.

Place the first page on the platen glass if you are not using the ADF.

- 2. Press [FAX].
- 3. Press [Redial/Pause].
- 4. Press [Start].

When you set the documents on the platen glass, press [Start] for each document. When scanning is complete, press [OK] to start dialing.



When <RESTRICT REDIAL> is set to <ON> in the <ACCESS TO DEST.> of the <SYSTEM SETTINGS> menu, redialing is not available.

Redialing Automatically

The default settings are as follows:

- AUTO REDIAL: <ON>
- REDIAL TIMES: <2TIMES>
- REDIAL INTERVAL: <2MIN.>
- 1. Press [Additional Functions].
- 2. Press [◄—] or [+▶] to select <FAX SETTINGS>, then press [OK].
- 3. Press [◄–] or [+►] to select <TX SETTINGS>, then press [OK].
- **4.** Press [◄–] or [+►] to select <AUTO REDIAL>, then press [OK].
- Press [◄–] or [+►] to select <ON>, then press [OK].

Table of Contents







Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

6. Press [◄–] or [+►] to select the number of redials the machine will make, then press [OK].



You can also enter values with the numeric keys.



Regardless of the number you entered, the machine makes only one redialing attempt if it does not detect a busy signal.

7. Press [◄–] or [+►] to select the time (in minutes) between redials, then press [OK].

You can also enter values with the numeric keys.

8. Press [Stop/Reset] to return to the standby mode.

Checking Dialing Line

Checking dialing line function enables you to configure the setting on whether to check for a dial tone.

The default setting is <OFF>.

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <FAX SETTINGS>, then press [OK].
- 3. Press [◄–] or [+►] to select <TX SETTINGS>, then press [OK].
- 4. Press [◄–] or [+►] to select <DIALING LINE CHCK>, then press [OK].
- Press [◄–] or [+►] to select <ON>, then press [OK].
- **6.** Press [Stop/Reset] to return to the standby mode.

Table of Contents



Before Using the Machine

Document and Paper

Copying

1

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Dialing an Overseas Number (With Pauses)

When you dial or register an overseas number, you may need to insert a pause within the number.

1. Set documents.

Place the first page on the platen glass if you are not using the ADF.

- 2. Press [FAX].
- 3. Use the numeric keys to dial the international access code.

For details on international access codes, contact your local telephone company.

4. If necessary, press [Redial/Pause] to insert a pause.

- The letter <P> is displayed between the numbers.
- <P> in the fax/telephone number represents 2.5-second pause.
- For a longer pause, press [Redial/Pause] again.

- 5. Use the numeric keys to dial the country code, the area code, and the fax/telephone number of the recipient.
- **6.** If necessary, press [Redial/Pause] to enter a pause at the end of the number.

The letter <P> appears at the end of the fax number.

7. Press [Start].

When you set the documents on the platen glass, press [Start] for each document. When scanning is complete, press [OK] to start sending.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Basic Receiving Method

Follow this procedure to set the machine for receiving faxes. The default setting is <FaxOnly>.



Any data stored in the memory, including received fax documents, will be deleted if you turn off the main power switch of the machine.

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <FAX SETTINGS>, then press [OK].
- 3. Press [◄–] or [+►] to select <RX MODE>, then press [OK].

4. Press [◄–] or [+►] to select the receive mode. then press [OK].

<FaxOnly>: Answers all calls as faxes.

<AnsMode>: Receives faxes automatically and records voice messages.

<DRPD> (Distinctive Ring Pattern Detection): Distinguishes between fax and voice calls using distinctive ring patterns. Select the ring pattern assigned by your telephone company. For optional settings, see "DRPD: Optional Settings," on p. 4-25.

<FAX/TEL>: Switches between fax and voice calls automatically if an external telephone is connected to the machine. For optional settings, see "FAX/TEL: Optional Settings," on p. 4-24.

<MANUAL>: Does not answer any calls. You have to manually receive faxes. See "Manual Reception," on p. 4-25.



- For <FAX/TEL> or <MANUAL>, make sure an external telephone is connected to the machine.
- For <AnsMode>, make sure an external telephone with built in answering machine is connected to the machine.
- For <DRPD>, subscription to a DRPD service is required. Contact your telephone company for availability.
- 5. Press [Stop/Reset] to return to the standby mode.

Table of Contents

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

ppendix

Receiving Features

You can set the fax receive mode to suit your needs, set the machine to receive fax documents into memory (memory lock), and use the external telephone connected to the machine to receive faxes manually (remote reception). You can also set how the received documents are printed.

■ FAX/TEL: Optional Settings

When you select <FAX/TEL> in <RX MODE>, you can specify optional settings as follows:

- 1. Press [Additional Functions].
- Press [◄–] or [+►] to select <FAX SETTINGS>, then press [OK].
- Press [◄–] or [+►] to select <RX SETTINGS>, then press [OK].
- **4.** Press [◄—] or [+▶] to select <FAX/TEL OPT. SET>, then press [OK].

For <RING START TIME>, use [◄-], [+►], or the numeric keys to specify the duration (4 to 30 seconds) for which the machine attempts to detect the fax tone before it starts ringing, then press [OK].

If the machine receives a fax, the machine does not ring and switches to the receive mode automatically.

The default setting is <6SEC>.

6. For <F/T RING TIME>, use [◄–], [+►], or the numeric keys to specify the duration (10 to 45 seconds) of ringing, then press [OK].

The default setting is <22SEC>.

7. For <F/T SWITCH ACTION>, press [◄—] or [+▶] to select the action the machine will take after the ringing ends, then press [OK].

The default setting is <RECEIVE>.
<RECEIVE>: Receives a fax.
<DISCONNECT>: Disconnects the call.

8. Press [Stop/Reset] to return to the standby mode.

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

1

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Appendix

11

DRPD: Optional Settings

When you select <DRPD> in <RX MODE>, select the ring pattern assigned by your telephone company.

- The default setting is <NORMAL RING>.
- 1. Press [Additional Functions].
- Press [◄–] or [+►] to select <FAX SETTINGS>, then press [OK].
- Press [◄–] or [+►] to select <RX SETTINGS>, then press [OK].
- **4.** Press [◄-] or [+►] to select <DRPD:SELECT FAX>, then press [OK].
- 5. Press [◄–] or [+►] to select a ring pattern, then press [OK].
 - <NORMAL RING>
 - <DOUBLE RING>
 - <SHORT-SHORT-LONG>
 - <SHORT-LONG-SHORT>
 - <OTHER RING TYPE>
- **6.** Press [Stop/Reset] to return to the standby mode.



For <DRPD>, subscription to a DRPD (Distinctive Ring Pattern Detection) service is required. Contact your telephone company for availability.

Manual Reception

When you select <MANUAL> in <RX MODE>, follow the procedure below to receive a fax.

- 1. When the telephone rings, pick up the external telephone.
- 2. Press [FAX].
- 3. Confirm that the modem's connecting sound is heard, then press [Start].
- 4. Hang up the external telephone.

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Memory Reception

The machine automatically receives faxes in memory when printing is disabled under certain conditions (e.g., toner or paper has run out).

Load paper and press [OK] to start printing faxes stored in memory. For toner empty, the machine automatically starts printing when the error is cleared.

NOTE

- The machine memory can store up to 256 fax jobs or approximately 256 pages.*
- * Based on the condition that the other party sends the fax by the imageCLASS MF4270 with ITU-T Standard Chart No. 1, standard mode. The maximum number of pages that the machine's memory can store differs depending on the other party's machine.
- Once the pages are printed, they are deleted from the memory.
- If the memory becomes full, you will not be able to receive the remaining pages. Contact the other party and ask them to resend the remaining pages of the fax.

■ Memory Lock Reception

You can set the machine to store all documents in memory without automatically printing them.

The default setting is <OFF>.

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <SYSTEM SETTINGS>, then press [OK].

If the System Password has been set, enter the System Password using the numeric keys, then press [OK].

- 3. Press [◄–] or [+►] to select <COMMUNICATIONS>, then press [OK].
- 4. Confirm that <MEMORY LOCK> is displayed, then press [OK].

If the memory lock password has already been set, enter the password, then press [OK].

Table of Contents









| '`

Before Using the Machine

Document and Paper

Copying

ر **3**

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Press [◄–] or [+►] to select <ON>, then press [OK].



When you select <OFF>, the machine starts to print the received documents in memory.

If you want to set a password, press [◄–] or [+►] to select <PASSWORD>, then press [OK].

If you need not set a password, skip to step 8.

7. Use the numeric keys to enter the memory lock reception password (up to seven digits), then press [OK].

Ex.

PASSWORD
1234567

8. If you want to specify <MEMORY RX TIME>, press [◄—] or [+▶] to select <MEMORY RX TIME>, then press [OK].

If you need not set the timer for memory lock, skip to step 12.

- Press [◄–] or [+►] to select <ON>, then press [OK].
- 10. For <MEM. RX START TIME>, use the numeric keys to enter the start time (in 24-hour format), then press [OK].

- 11. For <MEM. RX END TIME>, use the numeric keys to enter the end time, then press [OK].
- 12. Press [Stop/Reset] to return to the standby mode.

Printing All Documents Stored in Memory

1. Perform step 1 to 3 in "Memory Lock Reception," on p. 4-26.







ТОР

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

- 2. Confirm that <MEMORY LOCK> is displayed, then press [OK].
- 3. Use the numeric keys to enter the memory lock reception password, then press [OK].
- **4.** Press [◄–] or [+►] to select <OFF>, then press [OK].

The received documents are printed.

5. Press [Stop/Reset] to return to the standby mode.

■ Remote Reception

Remote reception enables you to use an external telephone connected to the machine to receive faxes manually. This can be useful when the machine is not nearby or is being used by someone else.

The default settings are as follows:

- REMOTE RX: <ON>
- REMOTE RX ID: <25>

Registering Remote Reception ID

Follow this procedure if you want to change the default remote reception ID of 25.

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <FAX SETTINGS>, then press [OK].
- 3. Press [◄—] or [+▶] to select <RX SETTINGS>, then press [OK].
- **4.** Press [◄–] or [+►] to select <REMOTE RX>, then press [OK].
- Press [◄–] or [+►] to select <ON>, then press [OK].
- 6. Use the numeric keys to enter a new remote reception ID (a combination of two characters using 0 to 9), then press [OK].
- 7. Press [Stop/Reset] to return to the standby mode.







Next

Before Using the Machine

Document and Paper

Copying

Sending and

Printing and

Receiving

Remote UI

Network

System Manager

Maintenance

Settings

Troubleshooting

9

Receiving a Fax Remotely

- 1. When you receive a call, pick up the external telephone.
- 2. Use the numeric keys to enter the two-digit remote reception ID to start reception.



If the machine is set for pulse dialing, press [Tone] to switch to tone dialing before pressing the remote reception ID.

When the reception is complete, hang up the telephone.

Selecting the Receive Mode for Printing

You can select whether the machine stores all received pages in the memory before printing them out or prints each page as it is received.

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <FAX SETTINGS>, then press [OK].
- 3. Press [◄–] or [+►] to select <RX SETTINGS>, then press [OK].
- **4.** Press [◄–] or [+►] to select <RX PRINT>, then press [OK].
- 5. Press [◄–] or [+►] to select desired printing method, then press [OK].

<MEMORY RX>: Prints after all the pages of the document are received.

- <PRINT RX>: Prints each page as it is received.
- **6.** Press [Stop/Reset] to return to the standby mode.

Table of Contents









Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Reception Restriction

You can reject incoming faxes from the senders who do not transmit their fax numbers to your machine. The default setting is <OFF>.

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <FAX SETTINGS>, then press [OK].
- 3. Press [◄–] or [+►] to select <RX SETTINGS>, then press [OK].
- **4.** Press [◄-] or [+►] to select <RX RESTRICTION>, then press [OK].
- Press [◄–] or [+►] to select <ON>, then press [OK].
- **6.** Press [Stop/Reset] to return to the standby mode.

Printing Received Documents

The machine provides the following printing features: two-sided printing and received image reduction.

Two-Sided Printing

You can print received documents on both sides of the paper. The default setting is <OFF>.



You can print the received documents on both sides of the paper only when <PAPER SIZE> is set to <LTR> or <A4>. The received documents are printed on one side of the paper when <PAPER SIZE> is not set to <LTR> or <A4>. (See "Setting Paper Size and Type," on p. 2-13.)

- 1. Press [Additional Functions].
- Press [◄–] or [+►] to select <FAX SETTINGS>, then press [OK].
- 3. Press [◄–] or [+►] to select <PRINTER SETTINGS>, then press [OK].
- **4.** Press [◄–] or [+►] to select <2-SIDED PRINT>, then press [OK].
- Press [◄–] or [+►] to select <ON>, then press [OK].
- **6.** Press [Stop/Reset] to return to the standby mode.

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Received Image Reduction

You can print received documents in a reduced size. The default setting is <ON>.

- 1. Press [Additional Functions].
- Press [◄–] or [+►] to select <FAX SETTINGS>, then press [OK].
- 3. Press [◄-] or [+►] to select <PRINTER SETTINGS>, then press [OK].
- **4.** Press [◄–] or [+►] to select <RX REDUCTION>, then press [OK].

5. Press [◄-] or [+►] to select desired setting, then press [OK].

<ON>: Reduces the documents automatically depending on the length of the documents.

<OFF>: Prints documents on a paper without reducing the size. <CUT>: Cuts off the end of a document that does not fit on one page up to 24 mm. When the height of the area to be cut off is more than 24 mm, the document will be printed on the following page without being cut off.

6. Press [Stop/Reset] to return to the standby mode.

Table of Contents







Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Canceling TX/RX Jobs

Follow the procedure below to cancel an ongoing job (sending or receiving).

- Press [Stop/Reset].
- 2. When the <CANCEL DURING TX/RX?> message appears, press [◄-] to select <YES>.

CANCEL DURING TX/RX? < YES NO >



- For sending jobs, remove any unscanned documents from the
- If you are in the copy or scan standby mode and want to cancel a fax job, press [FAX] to return to the fax mode first.

Table of Contents





Previous



Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Checking and Deleting Jobs

System monitor enables you to view the transmission and reception results, monitor the status of the send jobs currently being processed.

- **Checking Transmission/Reception Results**
- **Press** [System Monitor].
- Press [◄–] or [+►] to select <TX/RX LOG>, then press [OK].
- 3. Press [◄–] or [+►] to view the required transmission/reception result.
- Press [Stop/Reset] to return to the standby mode.

- Checking and Deleting Sending **Documents Stored in Memory**
- 1. Press [System Monitor].
- 2. Press [◄–] or [+►] to select <TX STATUS>, then press [OK].
- 3. Press [◄–] or [+►] to scroll through the job list. If you want to delete the job, go to step 4. Otherwise, press [Stop/ Reset] to return to the standby mode.
- **4.** Press [◄–] or [+▶] to select the desired job, then press [OK].



For <BROADCAST>, all recipients entered for a broadcasting job will be canceled.

- **5.** Press [◄–] to select <YES>. If you do not want to cancel the job, press [+▶] to select <NO>.
- **6.** Press [Stop/Reset] to return to the standby mode.

Table of Contents









Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

ppendix 1

5 Printing and Scanning

Printing Docum	nents	5-2
Advanced Print	ring Features	5-3
	Collate Printing	
	2 on 1 Combination	
	Two-Sided Printing	5-5
Scanning to a C	Computer (USB connection only)	5-6
Canceling Scan	Jobs	5-7
-	Canceling Scan Jobs to a Computer	
Checking and D	Deleting Jobs	5-8
_	Checking and Deleting Print Jobs	5-8
	Checking Print and Scan Counts	5-8

Table of Contents







Before Using the

Document and Paper

Copying

Sending and Receiving

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Printing Documents

Follow this procedure to print a document from your computer. Make sure that the printer driver is installed. To check if the driver is installed, see "Software Settings with Computer," in the Starter Guide.

For details on the printer driver settings, see Online Help.



How to display the print screen or items on the screen may vary depending on your application and/or OS.

- 1. From an open document on an application, click [File] \rightarrow [Print].
- 2. Select the printer icon for the machine ([Canon MF4200 Series UFRII LT]), then click [Preferences] or [Properties] to open the dialog box.
- After finished setting, click [OK].
- Click [Print] or [OK].

Table of Contents









Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Advanced Printing Features

Collate Printing

You can print documents collated into sets arranged in page order. For example, when printing multiple copies of a 3-page document, the print order is 1, 2, 3, 1, 2, 3, and so on.

- 1. From an open document on an application, click [File] > [Print].
- 2. Select the printer icon for the machine ([Canon MF4200 Series UFRII LT]), then click [Preferences] or [Properties] to open the dialog box.

- 3. Click the [Finishing] tab.
- For [Finishing], select [Collate], then click [OK].
- **5.** On the [Print] dialog box, click [Print] or [OK].

Table of Contents









Next

TOP



Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10


Appendix

11

2 on 1 Combination

2 on 1 combination automatically reduces two-page document to fit on the selected paper size.

Documents



- 1. From an open document on an application, click [File] > [Print].
- 2. Select the printer icon for the machine ([Canon MF4200 Series UFRII LT]), then click [Preferences] or [Properties] to open the dialog box.

3. Click the [Page Setup] tab.

Back

- **4.** For [Page Layout], select [2 Pages per Sheet], then click [OK].
- 5. On the [Print] dialog box, click [Print] or [OK].



- Other than [2 Pages per Sheet], you can also select [4 Pages per Sheet], [6 Pages per Sheet], [8 Pages per Sheet], [9 Pages per Sheet], or [16 Pages per Sheet]. If you select [Poster [2 x 2]], [Poster [3 x 3]], or [Poster [4 x 4]], you can print out a poster that consists of multiple sheets of paper.
- When reducing multiple pages to fit on a sheet, you can also select the page order from the [Page Order] pull-down menu.

Table of Contents









TOP



Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Two-Sided Printing

Two-sided printing enables you to make two-sided printouts.

Printout

Portrait Oriented Documents














Short Edge (Top)



- 1. From an open document on an application, click [File] > [Print].
- 2. Select the printer icon for the machine ([Canon MF4200 Series UFRII LT]), then click [Preferences] or [Properties] to open the dialog box.
- 3. Click the [Finishing] tab.
- 4. For [Print Style], select [2-sided Printing], then click [OK].
- 5. On the [Print] dialog box, click [Print] or [OK].

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Appendix

11

Scanning to a Computer (USB connection only)

Follow this procedure to scan a document to your computer. Make sure that the scanner driver is installed. To check if the driver is installed, see "Software Settings with Computer," in the Starter Guide.

For details on the scanner driver settings, see the Scanner Driver Guide (in the User Software CD).

- 1. Set documents.
- 2. Press [SCAN].

The mark will be displayed above the button you select.

4. Press [Start].

Table of Contents







Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

<u>10</u>

Appendix

11

Canceling Scan Jobs

Follow the procedure below to cancel an ongoing scan job.

- Canceling Scan Jobs to a Computer
- 1. Press [Stop/Reset].
- 2. Click [OK] on the computer screen.

Table of Contents









Next

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager

Maintenance

Settings

9

Troubleshooting

Appendix

11

Checking and Deleting Jobs

System monitor enables you to monitor the status of the print jobs currently being processed.



Make sure that the Processing/Data indicator is turned on. When the Processing/Data indicator is turned off, all print jobs are erased from the memory.

- Checking and Deleting Print Jobs
- 1. Press [System Monitor].
- 2. Press [◄–] or [+►] to select <PRINT STATUS>, then press [OK].
- 3. Press [◄–] or [+►] to scroll through the job list, and check the status of the print jobs.

If you want to delete the job, go to step 4. Otherwise, press [Stop/Reset] to return to the standby mode.

4. Press [◄–] or [+►] to select the desired job, then press [OK].

- 5. Press [◄-] to select <YES>.
 If you do not want to cancel the job, press [+►] to select <NO>.
- **6.** Press [Stop/Reset] to return to the standby mode.
- Checking Print and Scan Counts
- 1. Press [System Monitor].
- 2. Press [◄—] or [+▶] to select <VIEW PAGE TOTALS>, then press [OK].
- 3. Press [◄–] or [+►] to view the print or scan counts.
- 4. Press [Stop/Reset] to return to the standby mode.

Table of Contents









Before Using the Machine

Document and Paper

3

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

10

Appendix

11

9

6 Network

Svstem Requireme	ents	. 6- 3
-,	Printing or Sending a Fax from a Computer	
Basic Network Set	tings	6-4
	IP Address Setting	6-4
	Interface Settings	
	Communication Environment Setup	6-7
Setting Up a Comp	outer for Printing/Sending a Fax	6-10
	Settings from the Operation Panel	6-10
	Machine Connection Method (LPD/Raw)	6-11
	Print Server Settings	6-14

Table of Contents







Before Using the Machine

Document and Paper

3

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

10

Appendix

11

9

Additional Network Settings		6-15
	TCP/IP Settings	6-15
	Startup Time Settings	6-17
Checking Network	k Settings	6-18
Machine Management		6-19
	Machine Management Using Web Browser (Remote UI)	6-19
	Machine Management Using NetSpot Device Installer	6-19

Table of Contents







Before Using the Machine

Document and Paper

Copying

3

9

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appenaix

System Requirements

This section describes the system environments with which the machine is compatible.

Printing or Sending a Fax from a Computer

The following system environments are compatible when printing or sending a fax from a computer:

- OS
- Microsoft Windows 2000 Server
- Microsoft Windows 2000 Professional
- Microsoft Windows XP Professional
- Microsoft Windows XP Home Edition
- Microsoft Windows Server 2003
- Microsoft Windows Vista

- Computers
- Windows; IBM PC/compatibles
- Protocol
- TCP/IP



If you are using Windows 2000, you need to install Service Pack 4 or later.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Receiving **Printing and**

Sending and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Basic Network Settings

Basic Network Settings are required in order to use the following functions of the machine.

Printing or sending a fax from a computer

Before making basic network settings, confirm that the following procedures are performed.



It is recommended that the network administrator perform the following procedures.

1. Network Cable Connection (See "Software Settings with Computer," in the Starter Guide.) Connect the machine to your network using the network cables.

2. Preparation for Protocol Settings (See "Software" Settings with Computer," in the Starter Guide.)

Specify the machine's IP address so that the machine and the network computer can communicate before making protocol settings. Any of the following can be used to specify the settings.

- Machine's operation panel (Additional Functions menu)
- NetSpot Device Installer (Canon utility software included in the User Software CD)

IP Address Setting

By default, the IP address is assigned to the machine automatically by the DHCP server.

To confirm the assigned IP address, "Software Settings with Computer," in the Starter Guide.

If the IP address is not assigned automatically, or you want to specify the IP address manually, follow the procedure below to specify the IP address.



This machine also supports automatic IP addresses using BOOTP and RARP protocols. If you use these protocols, select <ON> in step 6 of the following procedures, then specify the <BOOTP> or <RARP> settings.

- Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <SYSTEM SETTINGS>, then press [OK].
- 3. Press [◄–] or [+►] to select <NETWORK SETTINGS>, then press [OK].

Table of Contents









Next

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

- 4. Press [◄-] or [+►] to select <TCP/IP SETTINGS>, then press [OK].
- Press [◄-] or [+►] to select <IP ADDRESS AUTO.>, then press [OK].
- **6.** Press [◄–] or [+►] to select <OFF>, then press [OK].
- 7. Press [◄—] or [+▶] to select <IP ADDRESS>, then press [OK].
- 8. Use the numeric keys to enter the IP address, then press [OK].

IP ADDRESS 00<u>0</u>.000.000.000

 Press [◄–] or [+►] to select <SUBNET MASK>, then press [OK]. 10. Use the numeric keys to enter the subnet mask, then press [OK].

SUBNET MASK
000.000.000.000

- **11.** Press [◄–] or [+►] to select <GATEWAY ADDRESS>, then press [OK].
- 12. Use the numeric keys to enter the gateway address number, then press [OK].

Ex.

GATEWAY ADDRESS
000.000.000.000

13. Turn off the main power on the left side of the machine, then turn on the power to restart the machine.



Previous

Next

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

<u> 10</u>

9

Appendix

11

Interface Settings

Ethernet Driver

You can specify the communication method and Ethernet connection type.

The default setting is <AUTO>.

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <SYSTEM SETTINGS>, then press [OK].

If the System Password has been set, enter the System Password using the numeric keys, then press [OK].

- 3. Press [◄–] or [+►] to select <NETWORK SETTINGS>, then press [OK].
- 4. Press [◄-] or [+►] to select <ETHERNET DRIVER>, then press [OK].
- Press [◄–] or [+►] to select <AUTO DETECT>, then press [OK].

6. Press [◄–] or [+►] to select the desired detection method, then press [OK].

<AUTO>: Automatically determines the communication mode (Half duplex/Full duplex) and Ethernet type (10Base-T/100BaseTX). Skip to step 11.

<MANUAL>: You have to manually specify the communication mode and Ethernet type.



If you reconnect the network cable (for example, reconnect the cable to a different Ethernet hub) with the power on, the Auto Detect function will not work even if you set <AUTO DETECT> to <AUTO>. (Connect the cable with the power off.)

- 7. If you have selected <MANUAL> in step 6, press [◄—] or [+▶] to select <COMMUNICATION MODE>, then press [OK].
- 8. Press [◄–] or [+►] to select the desired communication method, then press [OK].

<FULL DUPLEX>: Sends and receives simultaneously. <HALF DUPLEX>: Sends and receives alternately.

 Press [◄–] or [+►] to select <ETHERNET TYPE>, then press [OK].

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10.

Appendix

11

- **10.** Press [◄–] or [+►] to select the desired Ethernet connection type, then press [OK].
 - <100 BASE-TX>: Establishes a 100Base-TX network connection. <10 BASE-T>: Establishes a 10Base-T network connection.
- 11. Press [Stop/Reset] to return to the standby mode.
- 12. Restart the machine.

Communication Environment Setup

To set up a configuration for communication between the machine and computers on your network, use the following procedure.

SNMP

SNMP helps monitor the state of the machine and collects information on it. The default setting is <ON>.

The following two items can be set:

<COMMUNITY NAME>:

Sets the SNMP community name. You can specify up to two community names.

The default setting is <public> for COMMUNITY NAME 1.

<SNMP WRITABLE>:

Enables the computers on the network to access the machine and modify its settings if this item is activated. You can specify this setting for each community separately.

The default setting is <ON> for SNMP WRITABLE 1 and <OFF> for SNMP WRITABLE 2.

- 1. Press [Additional Functions].
- 2. Press [◄—] or [+▶] to select <SYSTEM SETTINGS>, then press [OK].

If the System Password has been set, enter the System Password using the numeric keys, then press [OK].

Table of Contents









Next

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

- 3. Press [◄-] or [+►] to select <NETWORK SETTINGS>, then press [OK].
- **4.** Press [◄-] or [+►] to select <SNMP SETTINGS>, then press [OK].
- Press [◄–] or [+►] to select <USE SNMP>, then press [OK].
- 6. Press [◄-] or [+►] to select <ON> or <OFF>, then press [OK].

 $<\!$ ON>: When you set or browse each item of the machine with utility that uses SNMP to obtain information.

<OFF>: When you do not use an SNMP utility.



If you want to use a Canon printer driver or utility, select <ON> for <USE SNMP>.

- Press [◄–] or [+►] to select <SNMP SETTINGS>, then press [OK].
- 8. Press [◄-] or [+▶] to select <COMMUNITY NAME 1>, then press [OK].

- 9. Use the numeric keys to enter the desired community name other than "public," then press [OK].
- **10.** Press [◄–] or [+►] to select <SNMP SETTINGS>, then press [OK].
- 11. If you need to specify <COMMUNITY NAME</p>
 2>, press [◄-] or [+►] to select <COMMUNITY</p>
 NAME 2>, then press [OK].
 If you need not specify <COMMUNITY NAME 2>, skip to step 14.
- 12. Use the numeric keys to enter the desired community name, then press [OK].
- **13.** Press [◄–] or [+►] to select <SNMP SETTINGS>, then press [OK].
- **14.** Press [◄–] or [+►] to select <SNMP WRITABLE 1>, then press [OK].

Table of Contents







TOP

Before Using the

Document and Paper

Copying

ر 3

Sending and Receiving

Printing and Scanning

Maturaula

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

- **15.** Press [◄–] or [+►] to select <ON>, then press [OK].
- **16.** If you need to specify <SNMP WRITABLE 2>, press [◄—] or [+►] to select <SNMP SETTINGS>, then press [OK].

If you need not specify <SNMP WRITABLE 2>, skip to step 19.

- 17. Press [◄-] or [+►] to select <SNMP WRITABLE 2>, then press [OK].
- **18.** Press [◄–] or [+►] to select <ON>, then press [OK].
- 19. Press [Stop/Reset] to return to the standby mode.
- 20. Restart the machine.

Table of Contents







Next

TOP

Before Using the Machine

Document and Paper

Copying

Printing and

Sending and

Receiving

Network

Remote UI

System Manager Settinas

Maintenance

9

Troubleshooting

Setting Up a Computer for Printing/Sending a Fax

This section describes procedures for Setting Up a computer for printing/sending a fax.

Before setting up a computer for printing/sending a fax, it is necessary to perform the following setup procedures.



It is recommended that the network administrator perform the following procedures.

Network Cable Connection (See "Software Settings with Computer," in the Starter Guide.)

Connect the machine to your network using the network cables.

2. Preparation for Protocol Settings (See "Software Settings with Computer," in the Starter Guide.)

Specify the machine's IP address so that the machine and the network computer can communicate before making protocol settings. Any of the following can be used to specify the settings.

- Machine's operation panel (Additional Functions menu)
- NetSpot Device Installer (Canon utility software included in the User Software CD)

Basic Network Settings

Set up the basic network settings between the machine and computers on your network. To specify the settings, use:

- Machine's operation panel
- Web browser (Remote UI)

Settings from the Operation Panel

You can select the printing method over a TCP/IP network. The default setting is <ON> for both LPD PRINT and RAW PRINT.

- Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <SYSTEM SETTINGS>, then press [OK].

If the System Password has been set, enter the System Password using the numeric keys, then press [OK].

- 3. Press [◄–] or [+►] to select <NETWORK SETTINGS>, then press [OK].
- **4.** Press [◄–] or [+ ▶] to select <TCP/IP SETTINGS>, then press [OK].

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

- Press [◄-] or [+►] to select <LPD PRINT>, then press [OK].
- 6. Press [◄–] or [+►] to select <ON> or <OFF>, then press [OK].

<ON>: Uses LPD as the print application. <OFF>: Does not use LPD.

- 7. Press [◄—] or [+▶] to select <TCP/IP SETTINGS>, then press [OK].
- 8. Press [◄–] or [+►] to select <RAW PRINT>, then press [OK].
- Press [◄–] or [+►] to select <ON> or <OFF>, then press [OK].

<ON>: Uses Raw as the print application.

<OFF>: Does not use Raw.

10. Press [Stop/Reset] to return to the standby mode, then restart the machine.

Machine Connection Method (LPD/Raw)

● Connecting to a TCP/IP Network:

All computers that use the machine must have TCP/IP client software installed and must be enabled for TCP/IP network use. For details, see the manuals provided with the operating system.

Installing the Printer Driver and Specifying the Machine Destination Setting:

To print from a computer, you must install a printer driver and specify a setting for the machine destination. The machine destination setting differs depending on the print application used for printing. Use the following information as a guide to determine the print application you are using, and then perform the necessary operations.

- LPD: This is the print application generally used with TCP/IP.
- Raw: This is a print application used with Windows 2000/XP/
 Server 2003/Vista. It can print at higher speeds than LPD.



In the following procedures, items displayed on the screen for Windows XP are used; items might differ depending on your operating system.

Table of Contents









Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI


System Manager Settings

Maintenance

9

Troubleshooting


- 1. Open the printer properties dialog box.
 - For Windows Vista, click [Start] on the Windows task bar →
 [Control Panel] → [Printer] under [Hardware and Sound].
 - For Windows 2000, click [Start] on the Windows task bar →
 [Settings] → [Printers].
 - For Windows XP Professional/Server 2003, click [start] on the Windows task bar → [Printers and Faxes].
 - For Windows XP Home Edition, click [start] on the Windows task bar → [Control Panel] → [Printers and Other Hardware] → [Printers and Faxes].
- 2. Right-click the icon of the printer you installed → select [Properties].
- 3. Display the [Ports] sheet by clicking the [Ports] tab.



- **4.** Open the [Printer Ports] dialog box by clicking [Add Port].
- **5.** From [Available ports types], select [Standard TCP/IP Port] → click [New Port].

The Add Standard TCP/IP Printer Port Wizard starts.

- 6. Click [Next].
- 7. In [Printer Name or IP Address], enter the machine IP address or machine host name → click [Next].



After the computer has confirmed that there is a machine in which the entered IP address is assigned, the [Completing the Add Standard TCP/IP Printer Port Wizard] window appears.

Table of Contents



Previous

Next



Network

Printing and

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

. .


11



If the dialog box displays [Additional Port Information Required], follow the instructions on the screen to search again, or click [Standard] \rightarrow click [Canon Network Printing Device with P9100] from the pull-down list \rightarrow click [Next].

- 9. Click [Close] to close the [Printer Ports] dialog box.
- 10. In the printer properties dialog box, click [Configure Port] → Click [LPR] under [Protocol] → enter a print queue in [Queue Name] under [LPR Settings].

If you want to use Raw, confirm [Raw] under [Protocol] is selected, and proceed to step 11.





You can specify a print queue in [Queue Name]. The following three print queues are available:

LP: The machine prints according to its spool settings. Normally select this option.

SPOOL: The machine prints only after spooling a print job on the hard disk, regardless of its spool settings.

DIRECT: The machine prints without spooling a print job on the hard disk, regardless of its spool settings.

- 11. Click [OK].
- 12. Click [Close].



Previous

ous

Next

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Print Server Settings

If Windows 2000/XP/Server 2003/Vista is on your network, the following procedure enables you to set up a print server for more efficient management of network printers. Once a print server is set up, print jobs can be managed by the print server. Also, by setting up an alternate driver for the print server, printer drivers can be installed in each computer via the network.

1. Open the printer properties dialog box.

- For Windows Vista, click [Start] on the Windows task bar →
 [Control Panel] → [Hardware and Sound] → [Printers]
- For Windows 2000, click [Start] on the Windows task bar →
 [Settings] → [Printers].
- For Windows XP Professional/Server 2003, click [start] on the Windows task bar → [Printers and Faxes].
- For Windows XP Home Edition, click [start] on the Windows task bar → [Control Panel] → [Printers and Other Hardware] → Printers and Faxes].
- 2. Right-click the icon of the printer you installed → select [Sharing].
- For Windows Vista, click [Change sharing options]

For other operating systems, skip to step 4.



Click [Continue] to proceed if the [User Account Control] dialog box appears.

- **4.** Select [Share this printer] (Windows 2000: [Shared as]) and enter a share name.
- 5. If this machine is shared with users running different versions of Windows, click [Additional drivers].

When the alternate driver is installed, additional windows will open for entering the location of the file containing the printer driver. Follow the instructions in these windows.



To install the printer driver on another computer, use the [Printer Wizard] window for selecting the printer destination \rightarrow select [Network printer] \rightarrow select the shared printer for the computer selected in the print server.

6. Click [OK].

The shared printer settings are complete.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and

Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Additional Network Settings

Depending on your network environment, additional network settings may be required.



It is recommended that the network administrator perform the following procedures.

TCP/IP Settings

HTTP Settings

You can select whether or not to use HTTP for Remote UI. The default setting is <ON>.

- **Press [Additional Functions].**
- 2. Press [◄–] or [+►] to select <SYSTEM **SETTINGS>**, then press [OK].

If the System Password has been set, enter the System Password using the numeric keys, then press [OK].

- 3. Press [◄–] or [+►] to select < NETWORK SETTINGS>, then press [OK].
- **4.** Press [◄–] or [+▶] to select <TCP/IP SETTINGS>, then press [OK].
- 5. Press [◄–] or [+►] to select <USE HTTP>, then press [OK].
- 6. Press [◄–] or [+►] to select <ON> or <OFF>, then press [OK].

<ON>: Uses the Remote UI. <OFF>: Does not use the Remote UI.

- 7. Press [Stop/Reset] to return to the standby mode.
- Restart the machine.

Table of Contents









Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Port Number Settings

Depending on your network environment, you can change the port number for each protocol.

- **Press [Additional Functions].**
- Press [◄–] or [+►] to select <SYSTEM **SETTINGS>**, then press [OK].

If the System Password has been set, enter the System Password using the numeric keys, then press [OK].

- 3. Press [◄–] or [+►] to select < NETWORK **SETTINGS>**, then press [OK].
- Press [◄–] or [+►] to select <TCP/IP SETTINGS>, then press [OK].
- 5. Press [◄–] or [+►] to select < PORT NO. SET.>, then press [OK].
- **6.** Press [◄–] or [+►] to select the protocol of which you want to change the port number (LPD, RAW, HTTP, or SNMP), then press [OK].

- 7. Use the numeric keys to enter the port number, then press [OK].
- 8. Press [Stop/Reset] to return to the standby mode.
- Restart the machine.

Table of Contents









Next

Before Using the Machine

Document and Paper

Copying

Printing and

Sending and

Receiving

canning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Startup Time Settings

If you connect the machine to a switching hub, it may not be able to connect to a network even though your network settings are set correctly.

This occurs because the spanning tree process performed between switching hubs prevents them from communicating with each other immediately after the machine connects to a switching hub. In this case, use the following procedure to delay the startup of network communication.

The default setting is <60SEC>.

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <SYSTEM SETTINGS>, then press [OK].

If the System Password has been set, enter the System Password using the numeric keys, then press [OK].

- 3. Press [◄—] or [+▶] to select <NETWORK SETTINGS>, then press [OK].
- 4. Press [◄-] or [+►] to select <STARTUP TIME SET.>, then press [OK].

 Use [◄-], [+►], or numeric keys to set the time period required to delay the startup of network communications for the machine, then press [OK].

You can enter the value from 0 to 300 (seconds).

- **6.** Press [Stop/Reset] to return to the standby mode.
- 7. Restart the machine.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

11

Checking Network Settings

You can check the current network settings as follows.

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <SYSTEM SETTINGS>, then press [OK].

If the System Password has been set, enter the System Password using the numeric keys, then press [OK]. Press [◄—] or [+►] to select <NETWORK SETTINGS>, then press [OK].

- Press [◄-] or [+►] to select <NETWORK SETTINGS>, then press [OK].
- **4.** Press [◄—] or [+▶] to select <VIEW IP ADDRESS>, then press [OK].
- Press [◄-] or [+►] to select <IP ADDRESS>,
 <SUBNET MASK>, or <GATEWAY ADDRESS> for displaying the setting you want to check, then press [OK].
- **6.** Press [Stop/Reset] to return to the standby mode.

Table of Contents







Next

ТОР

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Machine Management

The machine enables you to use any of the following software to check the status and to specify the settings on your computer.

- Web browser (Remote UI)
- NetSpot Device Installer (Canon utility software included in the User Software CD)
- Machine Management Using Web Browser (Remote UI)

You can use Remote UI installed in the machine to manage it on a web browser.

For using Remote UI, see "Using the Remote UI," on p. 7-4.

Machine Management Using NetSpot Device Installer

NetSpot Device Installer is utility software for specifying the initial settings of Canon devices connected to a network. Available on the CD-ROM, NetSpot Device Installer can be accessed directly without installation, enabling network users to quickly and easily specify the initial settings of network devices.

For instructions on how to use NetSpot Device Installer, see the online help for NetSpot Device Installer.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

7 Remote UI

System Requirements		7-3
	note UI	
J	Starting the Remote UI	
Displaying De	evice Status and Information	7-6
Job Management		7-7
	Managing Print Jobs	
	Viewing the Activity Log	7-8
Managing the Address Book		7-9

Table of Contents









Before Using the Machine

Document and Paper

3

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

10

Appendix

11

Customizing System Settings		7-13
	Customizing System Information	7-13
mport/Export Fui	nction	7-16
	Saving the Address Book	7-16
	Loading an Address Book	7-17
Device Custom Se	ttings	7-19

Table of Contents







Before Using the

Document and Paper

Copying

Sending and Receiving

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

System Requirements

The Remote UI has been confirmed to work in the following system environments.

- OS
- Microsoft Windows 2000 Professional
- Microsoft Windows XP
- Microsoft Windows Vista
- Web Browser
- Microsoft Internet Explorer 5.01 SP4 or later (Internet Explorer 6 or later is recommended.)

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Annondiv

11

9

Using the Remote UI

The Remote UI software enables you to access and manage the machine connected to a network using a web browser.

- Check the machine status from a network computer
- Set and control the machine from a computer
- Starting the Remote UI



Before you start the Remote UI, select <VIEW IP ADDRESS> in <NETWORK SETTINGS> located in the <SYSTEM SETTINGS>, and verify the IP address of the machine. If you do not know the IP address, consult with your network administrator. (See "Checking Network Settings," on p. 6-18.)

- 1. Start the web browser.
- 2. Enter the IP address of the machine in [Address] or [Location] → press [Enter] on the keyboard.

The Remote UI screen appears.

3. Enter the required information.

- For [Administrator Mode], enter the System Manager password if required.
- For [End-User Mode], enter your user name.



For details on the System Manager password, see "Specifying the System Manager Settings," on p. 8-2.


Table of Contents







TOP



Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting


10

Appendix

11

4. Click [OK].

[Device] - [Status] page is displayed when you logon the Remote UI.



- A Device Displays the current status of the machine, etc.
- Takes you to the Remote UI top page.
- C Displays the online help for the Remote UI.
- D Displays the current status of print jobs, etc.
- E **T**akes you back to the top of a current page.
- Add.Func. Displays a list of settings for the machine, etc.
- Displays the Address Book data (one-touch speed dialing keys, etc.) registered on the machine.

Table of Contents



Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance


Troubleshooting

9

Displaying Device Status and Information

You can view the current status of the machine and also information about the administrator in charge of the machine, the installation location and various machine settings.

1. Click [Device] → select the item you want to display from the menu that appears under [Device].



[Status] Displays the current status of the

> machine and any error messages. To check details of errors, click [Error

Information].

[Information] Displays information related to the

> machine, such as the system manager's information and the location of the

machine.

[Features] Displays the functions that are available

with the current system configuration.

[Network] Displays information about the network

> interface and any network protocols that are enabled. If you are using

Administrator Mode, you can also adjust

these settings.

[Counter Check] Displays the total number of pages that

have been output for printing, copying,

and received job printing.



If you are changing the Network Settings, the machine must be restarted to enable the settings. Turn off the main power switch of the machine, wait at least 10 seconds, and turn the power back on.

Table of Contents



Previous

Next



Document and Paper

Copying

Sending and Receiving

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Job Management

The Remote UI enables you to manage print jobs. It also enables you to view the sending and receiving results of fax jobs.

Managing Print Jobs

You can use the Remote UI to manage print jobs that are being processed by the machine, or are held in the print queue.



If [Permit End-User's Job Operation] is not selected in [Register Password] in [Edit] in [System Settings] under [Add.Func.], you cannot delete any print jobs when the machine is in the End-User Mode. If [Permit End-User's Job Operation] is selected, you can delete print jobs for which you have owner privileges. (See "Customizing System Settings," on p. 7-13.)

1. Click [Job Status] → select [Print Job] from the menu that appears under [Job Status].

A list of print jobs being waiting or processed by the machine appears.




Table of Contents





Next





Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI


System Manager Settings

Maintenance

9

Troubleshooting

2. To delete a print job, click [Delete] next to the desired job.





You cannot recover the job once it is deleted.

Viewing the Activity Log

The Remote UI enables you to view the [Transmissions] of send jobs. The [Transmissions] shows up to 25 recent transactions.

1. Click [Job] → select [Transmissions] from the menu that appears under [Job].

The [Transmissions] appears displaying information about fax jobs that have already been processed by the machine.




Table of Contents







Next





Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting


Managing the Address Book

The Remote UI enables you to view and modify the Address Book data.



You can also access these setting menus from the operation panel of the machine. For details, see "Machine Settings," on p. 11-3.

1. Click [Address] → [One-touch Speed Dial] or [Coded Dial] from the menu that appears under [Address].



• To view/edit the registered addresses:

Click the number or the name to display the current address information.




Table of Contents





Next



Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9


Troubleshooting

10

Appendix


1

To edit the information, click [Edit] \rightarrow make the necessary changes on the Change Address screen \rightarrow click [OK].




To register a new address:

Click [None] or any number for which [None] is displayed as the name.



Click [Edit].



Select [Fax] or [Group] from the drop-down list, press [Select] \rightarrow enter the necessary information \rightarrow click [OK].




Table of Contents

Inde<u>x</u>







TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9


Troubleshooting

10.


Appendix

11

For group dialing, select [Group] from the drop-down list, press [Select] → enter a group name in [Group Name] → click [Address Book] under [Members List].



Select [One-touch Speed Dial] or [Coded Dial] from the drop-down list, press [Select] \rightarrow select the check box next to the number to register for the group dialing \rightarrow click [OK].



Make sure that the registered addresses are displayed in [Members List] \rightarrow click [OK].





Table of Contents









Document and Paper

3

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting


10

Appendix

11

• To delete the registered addresses:

Select the check box next to the number to delete \rightarrow click [Delete].





You cannot recover the address once it is deleted.

Table of Contents









Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Customizing System Settings


Customizing System Information

The Remote UI enables you to specify the machine's system settings.



You can also access the system settings from the operation panel of the machine. For details, see "Machine Settings," on p. 11-3.

1. Click [Add.Func.] → [System Settings] from the menu that appears under [Add.Func.] → click [Edit].



2. Enter the necessary information \rightarrow click [OK].




Table of Contents











Before Using the Machine

Document and Paper

3

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

4:-- --

Troubleshooting

<u> 10</u>


Appendix

1


9

● To restrict the Send Function:

Click [Restrict the Send Function].




Select the necessary settings \rightarrow click [OK].



• To set the System Manager password:

Click [Register Password].



Specify the necessary fields \rightarrow click [OK].




Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

....

Troubleshooting

Appendix

1

9

Set Password: Select this check box to set the

System Manager password.

System Manager Enter a number (seven digits

Password: maximum).

Confirm: Enter the password again. If the

number you enter here is different from the number entered for [System Manager Password], an error dialog box appears.

Permit End-User's Job Select this

Operation:

Select this check box to permit deleting print jobs for which you

have owner privileges when the machine is in the End-User Mode.

Table of Contents









Next



Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Import/Export Function

The Remote UI enables you to save the Address Book and other settings information, such as a file that can be loaded into the machine when needed. This function is useful when you want to use the same settings on another machine, and for backing up. The Import/Export function is intended for data exchange, and is available only through the Remote UI.

CAUTION

The Import/Export operation may take more than a few minutes to complete. Do not turn the machine's main power off until the operation is complete. Otherwise, the machine may malfunction.



- If the machine is in the Sleep mode, press [Energy Saver] on the operation panel to cancel the Sleep mode before performing an Import operation.
- During an Export operation, the screen display does not change until the operation is complete. Do not click [Start Export] while the hourglass or pointer indicates that the operation is still being processed.
- [Import/Export] is displayed only when you are in the Administrator Mode.

Saving the Address Book

You can store the Address Book as a file in your computer.

1. Click [Add.Func.] → select [Import/Export] from the menu that appears under [Add.Func.].




Table of Contents








Next





Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI


System Manager Settings

Maintenance

9

Troubleshooting

2. Click [Start Export].



3. Follow the instructions on the screen to specify the location where you want to save the file.

The file is saved in the specified location.

Loading an Address Book

You can load address books into the machine from saved files.



- When you register the contents of a new file, the currently registered addresses are overwritten by the new address list.
- You can register up to 108 addresses in the Address Book. Each address is treated as a separate item.
- You cannot import the group dialing information which contains another group dialing.
- **1.** Click [Add.Func.] → select [Import/Export] from the menu that appears under [Add.Func.].




Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9


Troubleshooting

10


Appendix

11

2. Click [Import...].



3. Click [Browse] → select the file to import → click [OK].





Do not import any files while the machine is executing other jobs.

Table of Contents



Previous

Next

TOP



Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting


Device Custom Settings

The Remote UI enables you to edit the machine's custom settings.




You can also access these setting menus from the Operation Panel of the machine. For details, see "Machine Settings," on p. 11-3.

1. Click [Add.Func.] → select [Custom Settings] from the menu that appears under [Add.Func.] → click the type of custom setting that you want to specify.



2. Specify all the necessary fields \rightarrow click [OK].



The above screen shot shows [Custom Settings].

Table of Contents







Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

. .

11

8 System Manager Settings

Specifying the System Manager Settings	
Restricting Access to Destinations	8-3
Confirming Entered Fax Numbers	8-3
Restricting Redial	8-4

Table of Contents







Next



Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Specifying the System Manager Settings

You can set a password for the System Manager. Once the System Password is set, restrictions can be placed on storing or changing the System Settings.



If you make a mistake when entering a number, press [Clear] to clear the entire number → enter the correct number.

- **Press [Additional Functions].**
- 2. Press [◄–] or [+►] to select <SYSTEM SETTINGS>, then press [OK].

If the System Password has been set, enter the System Password using the numeric keys, then press [OK].

- 3. Press [◄–] or [+►] to select <SYS. MANAGER INFO>, then press [OK].
- **4.** Press [◄–] or [+►] to select <SYSTEM PASSWORD>, then press [OK].

- 5. Use the numeric keys to enter a number, then press [OK].
- **6.** Press [Stop/Reset] to return to the standby mode.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and

Receiving Printing and

canning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Restricting Access to Destinations

You can set whether to confirm entered fax numbers and restrict the use of [Redial/Pause].

■ Confirming Entered Fax Numbers

You can specify whether or not to confirm the entered fax numbers each time you send a fax.

- The default setting is <OFF>.
- 2. Press [◄–] or [+►] to select <SYSTEM SETTINGS>, then press [OK].

Press [Additional Functions].

If the System Password has been set, enter the System Password using the numeric keys.

3. Press [◄–] or [+►] to select <ACCESS TO DEST.>, then press [OK].

- **4.** Press [◄–] or [+►] to select <CONFIRM FAX NO.>, then press [OK].
- Press [◄–] or [+►] to select <ON> or <OFF>, then press [OK].

<OFF>: The confirmation screen does not appear. <ON>: The confirmation screen appears when you enter a fax number using the numeric keys.

6. Press [Stop/Reset] to return to the standby mode.

Table of Contents



Back





TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

<u> 10</u>

Appendix

11

Restricting Redial

You can specify whether or not to allow using [Redial/Pause]. The default setting is <OFF>.

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <SYSTEM SETTINGS>, then press [OK].

If <SYSTEM PASSWORD> has been set, enter the System Manager password using the numeric keys.

- 3. Press [◄–] or [+►] to select <ACCESS TO DEST.>, then press [OK].
- **4.** Press [◄–] or [+►] to select <RESTRICT REDIAL>, then press [OK].
- 5. Press [◄-] or [+►] to select <ON> or <OFF>, then press [OK].
- **6.** Press [Stop/Reset] to return to the standby mode.

Table of Contents









Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

_____10

Appendix

11

9

9 Maintenance

Cleaning the Mac	:hine	9-2
-	Exterior	
	Interior	9-3
	Fuser Roller	9-7
	Scanning area	9-8
Replacing the Tor	ner Cartridge	9-11
	Redistributing Toner	9-11
	Replacing the Toner Cartridge with a New One	9-14
Recycling Used Ca	artridges	9-19
-	The Clean Earth Campaign	9-19
	U.S.A. PROGRAM	9-20
	CANADA PROGRAM-CANADA PROGRAMME	9-22
Transporting the	Machine	9-25

Table of Contents



Previous

TOP

Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Cleaning the Machine

Note the following before cleaning your machine:

- Make sure no document is stored in memory, then turn off the main power switch and disconnect the power cord.
- Use a soft cloth to avoid scratching the components.
- Do not use tissue paper, paper towels, or similar materials for cleaning; they can stick to the components or generate static charges.

CAUTION

Never use volatile liquids such as thinners, benzene, acetone, or any other chemical cleaner to clean the machine. These can damage the machine components.



When you turn off the main power switch, the documents stored in memory will be erased. To check the jobs stored in memory, see the following:

- "Checking and Deleting Sending Documents Stored in Memory," on
- "Checking and Deleting Print Jobs," on p. 5-8

Exterior

- 1. Turn off the main power switch and disconnect the power cord.
- 2. Wipe the machine's exterior with a clean, soft, lint-free cloth dampened with water or diluted dishwashing detergent solution.
- 3. Wait for the machine to dry, then reconnect the power cord and turn on the main power switch.

Table of Contents











Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10


Appendix

11


Interior

Clean the machine's print area periodically to prevent toner powder and paper dust from accumulating inside.

- 1. Turn off the main power switch and disconnect the power cord.
- 2. Hold the operation panel by the front side with both of your hand.



3. Lift the scanning platform until it is locked (A). (You will hear an audible "click.")



4. Open the toner cover (B), using the grip (A) on the right front side of the toner cover.




Table of Contents







Next

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI


System Manager Settings

Maintenance

9


Troubleshooting

5. Remove the toner cartridge.



A CAUTION

- Do not touch the rollers and parts which have labels "CAUTION! Hot surface avoid contact" on. They become very hot during use.
- To avoid exposing the toner cartridge to light, place it in its protective bag or wrap it in a thick cloth.



- Do not open the drum protective shutter (A) on the toner cartridge. Print quality may deteriorate if the drum surface is exposed to light or is damaged.




Always hold the toner cartridge by its handle.

6. Use a clean, soft, dry, lint-free cloth to remove any toner or paper debris from the machine's interior.



CAUTION

- Do not touch the fixing assembly (A) as it becomes very hot during use.
- Do not touch the transfer roller (B) as this can damage the machine.



- If loose toner comes into contact with your skin or clothing, wash with cold water. Warm water will set the toner.

Table of Contents











.

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

inting and anning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting


<u> 10</u>

Appendix


11

7. Hold the toner cartridge by its handle.


Hold the toner cartridge by its handle (A).



8. Insert the toner cartridge so that the protrusion on the right side of the toner cartridge (A) fits into the guide (B) located on the right side of the machine and slide it down parallel to the guide.



9. Push the toner cartridge to make sure it is properly set in the machine.



10. Close the toner cover using the grip.





Table of Contents









Document and Paper

Copying

Sending and Receiving

Remote UI


System Manager Settings

Maintenance

9

Troubleshooting

11. Lower the scanning platform.



CAUTION

- Be careful not to get your fingers caught.
- If you cannot close the toner cover, do not force it to close. Open the cover and make sure the toner cartridge is properly set in the machine.

12. Reconnect the power cord and turn on the main power switch.

Table of Contents







Next



Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting


Fuser Roller

If black streaks appear with printing, the fuser roller in the main unit may be dirty. Should this occur, clean the fusing roller in the following procedure. The roller should also be cleaned each time the toner cartridge is replaced. Load a sheet of blank LTR paper into the multi-purpose tray and start cleaning.



- Cleaning the roller takes approximately 130 seconds.
- When some jobs are stored in memory, this function is not available.
- **Press [Additional Functions].**
- 2. Press [◄–] or [+►] to select <ADJUST./ CLEANING>, then press [OK].

3. Load a sheet of blank LTR paper in the multipurpose tray.



4. Press [◄–] or [+▶] to select <FIX. UNIT CLEANING>, then press [OK].

Cleaning starts.



- Use standard paper as the cleaning paper.
- Throw away the cleaning paper after use.





Previous

Next

ТОР

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

<u>10</u>

Appendix


11

Scanning area


Keep the scanning area clean to avoid dirty copies or faxes to be sent.

Platen glass

1. Open the ADF.




2. Clean the platen glass and the underside of the ADF with a cloth dampened with water. Then, wipe the area with a soft, dry cloth.



NOTE

Do not dampen the cloth too much, as this may tear the document or damage the machine.

3. Close the ADF.



A CAUTION

Be careful not to get your fingers caught.

Table of Contents



Back





TOP

Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10


Appendix

11


ADF

If your documents have black streaks or appear dirty after copying them using the ADF, this may be caused by pencil lead rubbing off the documents and onto the roller. Clean the ADF scanning area and roller.

- 1. Turn off the main power switch and disconnect the power cord.
- 2. Open the ADF cover.



3. Clean the rollers (A) inside the ADF with a cloth dampened with water. Then wipe the area with a soft, dry cloth.





Do not dampen the cloth too much, as this may tear the document or damage the machine.

Table of Contents



Back





TOP

Before Using the

Document and Paper

Copying

Sending and Receiving

Remote UI


System Manager Settings

Maintenance

9

Troubleshooting

4. Close the ADF cover.





CAUTION

Be careful not to get your fingers caught.

5. Reconnect the power cord and turn on the main power switch.

Table of Contents











lovt

ТС

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

Replacing the Toner Cartridge

When the toner is running low, the message <TONER LOW/ PREPARE NEW TONER> appears on the LCD. We recommend that you prepare a new toner cartridge for future replacement with ease.

When the message <OUT OF TONER /CHANGE TONER> appears, redistribute toner in the toner cartridge. If the message persists, replace the toner cartridge with a new one. When toner empty error occurs while receiving fax, printing fax is interrupted and the received data will be stored in the memory. If you set <CONT. PRINTING> in <PRINTER SETTINGS> in <FAX SETTINGS> to <ON>, you can keep printing fax documents or reports without replacing the toner cartridge. The default setting for <CONT. PRINTING> is <OFF>. (See "CONT. PRINTING," on p. 11-13.)

A

CAUTION


- When <CONT. PRINTING> is set to <ON>, the printed documents may be light or blurred because of lack of toner. The data is erased when the documents are printed out, so you can not print the same documents again.
- Do not touch the rollers and parts which have labels "CAUTION! Hot surface avoid contact" on. They become very hot during use.



When the toner level is low by pressing [Toner Gauge], replace the toner cartridge.

Redistributing Toner

1. Hold the operation panel by the front side with both of your hand.



2. Lift the scanning platform until it is locked (A). (You will hear an audible "click.")




Table of Contents







Before Using the

Document and Paper

Copying

Sending and Receiving

Remote UI


System Manager Settings

Maintenance


Troubleshooting

9

3. Open the toner cover (B), using the grip (A) on the right front side of the toner cover.



4. Remove the toner cartridge.





CAUTION

Do not touch the rollers and parts which have labels "CAUTION! Hot surface avoid contact" on. They become very hot during use.

5. Gently rock the toner cartridge several times to evenly distribute toner inside.




Table of Contents









Next

Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Remote UI

System Manager Settings


Maintenance

9

Troubleshooting

6. Hold the toner cartridge by its handle.

Hold the toner cartridge by its handle (A).






CAUTION

Do not open the drum protective shutter on the toner cartridge. Print quality may deteriorate if the drum surface is exposed to light or is damaged.



Always hold the toner cartridge by its handle.

7. Insert the toner cartridge so that the protrusion on the right side of the toner cartridge (A) fits into the guide (B) located on the right side of the machine and slide it down parallel to the guide.



8. Push the toner cartridge to make sure it is properly set in the machine.




Table of Contents











Next

Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Remote UI


System Manager Settings

Maintenance


Troubleshooting

9

9. Close the toner cover using the grip.




10. Lower the scanning platform.



A CAUTION

- Be careful not to get your fingers caught.
- If you cannot close the toner cover, do not force it to close. Open the cover and make sure the toner cartridge is properly set in the machine.

- Replacing the Toner Cartridge with a New One
- 1. Hold the operation panel by the front side with both of your hand.



2. Lift the scanning platform until it is locked (A). (You will hear an audible "click.")




Table of Contents













Before Using the

Document and Paper

Copying

Sending and Receiving

Remote UI


System Manager Settings

Maintenance


9

Troubleshooting


3. Open the toner cover (B), using the grip (A) on the right front side of the toner cover.



Remove the toner cartridge.



5. Remove the new toner cartridge from the protective bag.





Save the protective bag. You may need it later when you remove the toner cartridge from the machine.



Do not open the drum protective shutter (A).




Table of Contents







Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Remote UI


System Manager Settings

Maintenance


9

Troubleshooting

6. Gently rock the toner cartridge several times to evenly distribute toner inside.




7. Place the toner cartridge on a flat surface and pull the seal completely out.





Do not pull the seal out at an angle.





- If toner is adhered on the removed seal, be careful that your hands or clothes do not get dirty from touching the toner.
- If your hands or clothes get dirty from touching the toner, wash them immediately in cold water. Do not use hot water. If you do, the toner may be set permanently.

Table of Contents









Next



Document and Paper

Copying

Sending and Receiving

Printing and

Remote UI

System Manager Settings


Maintenance

Troubleshooting

9

8. Hold the toner cartridge by its handle.

Hold the toner cartridge by its handle (A).




CAUTION

Do not open the drum protective shutter on the toner cartridge. Print quality may deteriorate if the drum surface is exposed to light or is damaged.



Always hold the toner cartridge by its handle.

9. Insert the toner cartridge so that the protrusion on the right side of the toner cartridge (A) fits into the guide (B) located on the right side of the machine and slide it down parallel to the guide.



10. Push the toner cartridge to make sure it is properly set in the machine.




Table of Contents



Back





TOP

Before Using the

Document and Paper

Copying

Sending and Receiving

Remote UI


System Manager Settings

Maintenance


Troubleshooting

9

11. Close the toner cover using the grip.



12. Lower the scanning platform.



A CAUTION

- Be careful not to get your fingers caught.
- If you cannot close the toner cover, do not force it to close. Open the cover and make sure the toner cartridge is properly set in the machine.

Table of Contents









Before Using the Machine '

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Recycling Used Cartridges



Canon has instituted a worldwide recycling program for cartridges called "The Clean Earth Campaign". This program preserves precious natural resources by utilizing a variety of materials found in the used cartridges that are of no further use, to remanufacture new cartridges which, at the same time, keeps the environment cleaner by reducing landfill waste. Complete details concerning this program are enclosed in each Cartridge box.

■ The Clean Earth Campaign

THE Canon CARTRIDGE RECYCLING PROGRAM

The Canon Cartridge Recycling Program fulfills the first initiative of Canon's Clean Earth Campaign, which supports four critical environmental areas:

- Recycling in the Workplace
- Conserving Environmental Resources
- Scientific Research and Education
- Encouraging Outdoors Appreciation

The remaining "Clean Earth" initiatives are supported in the U.S. through sponsorships of the National Park Foundation, the National Wildlife Federation, and The Nature Conservancy and in Canada through donations to the World Wildlife Fund Canada and The Nature Conservancy of Canada.

Since its inception, The Canon Cartridge Recycling Program has collected huge amount of cartridges that otherwise would have been discarded into landfills or similar facilities. Instead, this rapidly growing program returns used cartridges to the manufacturing process, thus conserving an array of resources.

Becoming a part of this worthwhile program is easy. When your cartridge is of no further use, simply follow the instructions detailed for U.S. or Canadian residents.

We appreciate your support of The Canon Cartridge Recycling Program.

Working together we can make a significant contribution to a cleaner planet.

Table of Contents



Back





ТОР

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

- Cartridges collected through this program are not refilled.
- You are not entitled to a tax deduction or rebate for the return of empty cartridges.
- This program may be modified or discontinued without notice.

The Clean Earth Campaign




■ U.S.A. PROGRAM

Packaging

Option A-1: Single Box Return

- Repackage the empty cartridge utilizing the wrapper and pulp mould end-blocks from the new cartridge's box.
- Place the empty cartridge in the box of your new cartridge. Seal the box.



Option B: Volume Box Return

We encourage you to use this option as a more efficient way to ship cartridges.

Table of Contents









Next

TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI


System Manager Settings

Maintenance

9

Troubleshooting


- Place as many cartridges as possible into one box. Carefully seal the box with tape; or
- Call **1-800-OK-Canon** to receive your free eight cartridge collection box.



Option A-2: Multiple Box Return

We encourage you to use this option as a more efficient way to ship cartridges.

- Complete Option A-1.
- Bundle multiple cartridge boxes together securely with tape.



Please be sure that the shipment does not exceed UPS specifications.

Back

Maximum weight = 70 lb. (31.8 kg)

Maximum length = 108 in. (2,743 mm)

Maximum girth (length $+ 2 \times width + 2 \times height$) = 130 in. (3,302) mm)

If your shipment exceeds the above limits, please call 1-800-OK-**Canon** for special shipping information.

Please Note:

Do not send defective cartridges for replacement.

Defective cartridges under warranty should be exchanged by an authorized dealer or service facility as provided in the warranty.

Shipping

Apply the UPS authorized returning label provided in this guide. Residents of Alaska and Hawaii: Do not use the UPS authorized returning label. For Alaska and Hawaii Canon set up alternative mail service with the U.S. Postal Service.

Please call **1-800-OK-Canon** to receive U.S. Postal Service merchandise returning label.

Table of Contents









ТОР

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Option: UPS Pick-up

 Give the shipment to your UPS driver when you receive your next regular delivery;

or

- Take the shipment to your local UPS receiving point.





CANADA PROGRAM-CANADA PROGRAMME

Option A: Single Box Return

- Repackage the empty cartridge utilizing the wrapper and pulp mould end-blocks from the new cartridge's box.
- Place the empty cartridge in the box of your new cartridge. Seal the box.
- Apply the Canon Canada Inc./Canada Post label provided in this brochure. Canon's labels are specially marked so that Canon pays the postage.
- Deposit your empty cartridge in any full size street mailbox or take it to your local Canada Post outlet or franchise.




Table of Contents



Back





TOP

Before Using the Machine

Document and Paper

Copying

_

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10


Appendix

11

Option B: Volume Box Return (eight or more cartridges)

We encourage you to use this option as a more efficient way to ship cartridges.

- Call 1-800-667-2666 to receive your free Canon collection box kit.
- The collection box can accommodate eight individual cartridge boxes.
- Place your eight individually packaged boxes of empty cartridges into the Canon collection box. Seal the box.
- Apply the Canon Canada Inc./Canada Post label provided in this brochure.
- Canon's labels are specially marked so that Canon pays the postage.
- Deliver to any local Canada Post outlet or franchise. Customers who hold a Commercial pick-up agreement with Canada Post may have their collection box picked up.





Working to preserve endangered species is a long-standing Canon interest.

To this end, for every cartridge collected, Canon Canada donates \$1, shared equally between World Wildlife Fund Canada and the Nature Conservancy of Canada. This donation is utilized in Canada.

Table of Contents







Before Using the

Document and Paper

Copying

3

Sending and Receiving

inting and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10.

Appendix

11

 For further information about The Clean Earth Campaign in Canada, please call or write to Canon.

1-800-667-2666

Canon Canada Inc. Corporate Customer Relations 6390 Dixie Road Mississauga, ON L5T 1P7

Table of Contents









Next



Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

. .


11

9


Transporting the Machine

Follow this procedure to avoid vibration damage to the machine when transporting it over a long distance.

- 1. Turn off the main power switch.
- 2. Disconnect the power cord and all the cables from the back of the machine.
- 3. If you are using the output tray extension, fold the paper stopper, and then push the output tray extension into the machine.



4. Hold the operation panel by the front side with both of your hand.



5. Lift the scanning platform until it is locked (A). (You will hear an audible "click.")




Table of Contents



Back





TOP

Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Remote UI


System Manager Settings

Maintenance


9

Troubleshooting

6. Open the toner cover (B), using the grip (A) on the right front side of the toner cover.



7. Remove the toner cartridge.





CAUTION

- To avoid exposing the toner cartridge to light, place it in its protective bag or wrap it in a thick cloth.
- Do not open the drum protective shutter on the toner cartridge. Print quality may deteriorate if the drum surface is exposed to light or is damaged.



MOTE

Always hold the toner cartridge by its handle.

Table of Contents







ТОР



Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9


Troubleshooting

10


Appendix

11

8. Close the toner cover using the grip.




9. Lower the scanning platform.



CAUTION

Be careful not to get your fingers caught.

10. Remove the dust cover from the paper cassette.



11. Open the front panel of the paper cassette.




Table of Contents










Next



Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI


System Manager Settings

Maintenance


Troubleshooting

9


12. Remove the paper from the paper cassette.



13. Remove the paper cassette by lifting up the front-end of the paper cassette and pulling it forward.



14. Detach the Document feeder tray.



- 15. Make sure all the covers are closed.
- 16. Grip the handles on both sides of the machine and lift it carefully, as shown in the illustration below.





CAUTION

- Do not lift the machine by any of its attachments. Dropping the machine can cause personal injury.
- If you have a back problem, make sure to check the weight of this machine before carrying. (See Chapter 13, "Appendix," in the Basic Operation Guide.)

Table of Contents









Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

_____1(

Appendix

11

9

10Troubleshooting

Clearing Jams	••••••••••	10-3
	Document Jams	10-2
	Paper Jams	10-6
LCD Messages	••••••••••	10-14
Error Codes	••••••	10-20
If <load correct="" paper=""> is displayed</load>		10-22
	Re-loading the Paper	10-22
	Changing the Paper Size Setting	10-22
General Problen	ns	10-24
Paper Feeding Problems		10-26

Table of Contents







Before Using the Machine	1
Document and Pa	per 2
Copying	3
Sending and Receiving	4
Printing and Scanning	5
Network	6
Remote UI	7
System Manager Settings	8
Maintenance	9
Troubleshooting	0

Fax Problems	•••••	10-27
	Sending Problems	10-27
	Receiving Problems	10-31
Copying Problems	•••••	10-37
Printing Problems	•••••	10-40
Telephone Problems	•••••	10-43
Network Problems	•••••	10-44
If a Power Failure Occ	urs	10-46
If You Cannot Solve a Problem		10-47
	Customer Support (U.S.A.)	10-47
	Customer Support (Canada)	10-47

Table of Contents







Before Using the Machine

Document and Paper

Copying

Printing and

Sending and

Receiving

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Clearing Jams

When <CHECK DOCUMENT>, <PAPER JAM> or <PAPER JAM/ OPEN REAR COVER> appears on the LCD display, remove jammed paper from the machine first, then from the paper cassette or multi-purpose tray if necessary. Check the following if you experience repeated paper jams:

- Fan and tap the paper stack on a flat surface before loading it in the machine.
- Check that the paper you are using meets the requirements for use. (See "Paper Requirements," on p. 2-7.)
- Make sure you have removed any scraps of paper from the inside of the machine.

A CAUTION

- When removing jammed documents or paper, take care not to cut your hands on the edges of the document or paper.
- When removing jammed paper or when inspecting the inside of the machine, do not allow necklaces, bracelets, or other metal objects to touch the inside of the machine, as this may result in burns or electrical shock.
- If you tear the paper, remove any torn pieces to avoid further jams.
- If loose toner comes into contact with your skin or clothing, wash with cold water. Warm water will set the toner.



Do not force a jammed document or paper out of the machine. Contact Canon Customer Care Center if needed.

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

Receiving

Printing and

Sending and

5

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

1

Appendix


11

9


Document Jams

When <CHECK DOCUMENT> appears on the LCD display, remove a jammed document from the ADF.

1. Open the ADF cover.




2. Hold both sides of any jammed documents and gently pull them out straight upward.




NOTE

Do not pull the document forcefully as it may tear.

3. Hold both sides of any jammed documents and gently pull them out.



4. Close the ADF cover.



A CAUTION

Be careful not to get your fingers caught.

Table of Contents







TOP



Document and Paper

Copying

Sending and Receiving

Remote UI


System Manager Settings

Maintenance


9

Troubleshooting

5. Open the ADF and then hold both sides of any jammed documents and gently pull them out.



6. Close the ADF.





Be careful not to get your fingers caught.

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10.


Appendix

11


Paper Jams

When <PAPER JAM> or <PAPER JAM/OPEN REAR COVER> appears on the LCD display, remove jammed paper from the inside of the machine first, then from the paper cassette or multi-purpose tray if necessary.

1. Hold the operation panel by the front side with both of your hand.



2. Lift the scanning platform until it is locked (A). (You will hear an audible "click.")



3. Open the toner cover (B), using the grip (A) on the right front side of the toner cover.




Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI


System Manager Settings

Maintenance

9

Troubleshooting

Remove the toner cartridge from the machine.




A CAUTION

- Do not touch the rollers and parts which have labels "CAUTION! Hot surface avoid contact" on. They become very hot during use.
- Remove watches and any bracelets or rings when touching the inside of the machine. These items might be damaged if they come into contact with the parts inside of the machine.
- To avoid exposing the toner cartridge to light, place it in its protective bag or wrap it in a thick cloth.
- Do not open the drum protective shutter on the toner cartridge. Print quality may deteriorate if the drum surface is exposed to light or is damaged.



M NOTE

Always hold the toner cartridge by its handle.



Back

CAUTION

- Do not touch the fixing assembly (A) as it becomes very hot during use.
- Do not touch the transfer roller (B) as this can damage the machine.

5. Hold both sides of the jammed paper and gently pull it out.




Table of Contents







TOP

Before Using the

Document and Paper

Copying

3

Sending and Receiving

rinting and canning

Network

Remote UI

System Manager Settings

Maintenance

9


Troubleshooting

10

Appendix

11

6. Gently pull the jammed paper between the fixing assembly (A) and transfer roller (B) until the leading edge emerges from the machine.





CAUTION

- Do not touch the fixing assembly (A) as it becomes very hot during use.
- Do not touch the transfer roller (B) as this can damage the machine.

7. Hold both sides of the jammed paper and carefully pull it out.




Table of Contents









Next



Document and Paper

Copying

Sending and Receiving

Printing and

Remote UI

System Manager Settings


Maintenance

Troubleshooting

9

8. Hold the toner cartridge by its handle.

Hold the toner cartridge by its handle (A).




CAUTION

Do not open the drum protective shutter on the toner cartridge. Print quality may deteriorate if the drum surface is exposed to light or is damaged.



Always hold the toner cartridge by its handle.

9. Insert the toner cartridge so that the protrusion on the right side of the toner cartridge (A) fits into the guide (B) located on the right side of the machine and slide it down parallel to the guide.



10. Push down the toner cartridge to make sure it is properly set in the machine.




Table of Contents








Next

TOP



Document and Paper

Copying

Sending and Receiving

Remote UI


System Manager Settings

Maintenance


9

Troubleshooting

11. Close the toner cover using the grip.




12. Lower the scanning platform.



A CAUTION

- Be careful not to get your fingers caught.
- If you cannot close the toner cover, do not force it to close. Open the cover and make sure the toner cartridge is properly set in the machine.

13. Remove the dust cover from the paper cassette.



14. Open the front panel of the paper cassette.



Table of Contents







TOP

Before Using the

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting


10

9

Appendix


11

15. Remove the paper in the paper cassette.




16. Hold both sides of the jammed paper and slowly pull it out in the direction of the arrow.

- When feeding paper from the paper cassette:



- When feeding paper from the multi-purpose tray:



17. Load the paper into the paper cassette.




Table of Contents







ТОР



Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9


Troubleshooting

10


Appendix

1

18. Close the front panel of the paper cassette.



19. Set the dust cover on the paper cassette.



20. Open the rear cover.

This operation is required only when <OPEN REAR COVER> appears on the LCD display.




Table of Contents







TOP

Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Remote UI

System Manager Settings


Maintenance

Troubleshooting


9

21. Hold both sides of the jammed paper and gently pull it out upward.

This operation is required only when <OPEN REAR COVER> appears on the LCD display.




If the jammed paper is badly folded, similar to the folds of an accordion, ease the jammed paper loose and then pull it out from the machine.



22. Close the rear cover.

This operation is required only when <OPEN REAR COVER> appears on the LCD display.





CAUTION

Be careful not to get your fingers caught.



To reset the machine, open the toner cover and then close it.

Table of Contents









TOP

Before Using the

Document and Paper

Copying

Sending and

Printing and

Network

Receiving

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

LCD Messages

See the following when the LCD displays error and status messages.

AVAILABLE MEMORY

nn%

Description

This message shows the percentage of the memory currently available.

Action

If you need more space, wait for the machine to send any documents in memory. Also print, send, or delete any documents stored in memory.

CANNOT PRINT RX DATA

Description

The machine temporarily received the fax in memory because an error of some kind has occurred in the machine.

This error message appears with one of the messages below.

- <CLOSE COVER/TONER COVER>
- <LOAD CORRECT PAPER>
- <REMOVE MP PAPER>
- <CHANGE REG'D SIZE/ → PAPER SETTINGS>
- <OUT OF TONER/CHANGE TONER>
- SET PAPER AGAIN/SET TONER AGAIN>
- <PAPER JAM>
- <PAPER JAM/OPEN REAR COVER>
- <LOAD PAPER>

Action

This error message appears with another message. When the error is resolved, the received data will be printed out. For how to solve the problem, see the action for the messages displayed with it.

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Annondiv

11

9

CHANGE REG'D SIZE → PAPER SETTINGS

Description

The paper size is not appropriate for your print jobs.

Action

- To print reports or received data, set the <CASSETTE> paper size to <LTR>, <LGL>, <A4>, <OFICIO>, <BRAZIL- OFICIO>, <MEXICO-OFICIO>, <FOLIO>, <GOVERNMENT-LETTER>, <GOVERNMENT-LEGAL>, or <FOOLSCAP>. For details, see "Setting Paper Size and Type," on p. 2-13.
- To print received data on both sides of paper, set the <CASSETTE> paper size to <LTR> or <A4>. For details, see "Setting Paper Size and Type," on p. 2-13.
- For two-sided copying, set the paper size to <LTR> or <A4>. For details, see "Setting Paper Size and Type," on p. 2-13.

CHECK DOCUMENT

Description

A document jam may have occurred in the ADF.

Action

Remove the jammed document.

CLOSE COVER TONER COVER

Description The toner cover is not closed completely.

Action Check the toner cover, and make sure that it is

completely closed.

HANG UP PHONE

Description The external telephone is off the hook.

Action Hang up the external telephone.

LIFT PANEL TO OPEN OPEN TONER COVER

Description

Appears alternately with other messages.

Action

Varies by the message that appears. For details, see the explanation for the message (i.e., <SET

PAPER AGAIN/SET TONER AGAIN>).

Table of Contents



Previous

Next

Before Using the

Document and Paper

3

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

LOAD CORRECT PAPER

Description The size of the paper in the paper cassette or

> multi-purpose tray is different from that of the paper specified in <CASSETTE> or <MP TRAY> of

the <PAPER SETTINGS> menu.

Action Load the correct size paper or change the paper

> size in <CASSETTE> or <MP TRAY> of the <PAPER SETTINGS> menu. For more information, see "If <LOAD CORRECT PAPER> is displayed," on

p. 10-22.

LOAD PAPER

No paper is loaded in the paper cassette or multi-Description

purpose tray when copying or printing.

Action Load paper correctly. Then press [OK] when

using the paper cassette.

Description No paper is loaded in the paper cassette or

multi-purpose tray when printing a received

document.

Or, when printing a report or list, this message appears if the paper size is not appropriate for printing a report or list even if paper is loaded. This error message appears with one of the

messages below.

<CHANGE REG'D SIZE/→PAPER SETTINGS>

<CANNOT PRINT RX DATA>

Action

Load paper correctly. Then press [OK] when

using the paper cassette.

For report or list, set the paper size to <LTR>, <LGL>, <A4>, <OFICIO>, <BRAZIL- OFICIO>, <MEXICO- OFICIO>, <FOLIO>, <GOVERNMENT-

LETTER>, < GOVERNMENT-LEGAL>, or

<FOOLSCAP>, and then load paper of the same

size.

LOST IMAGE

Description

The machine was turned off with documents

stored in the machine's memory.

Please note that any data stored in the memory, including received fax documents, will be deleted if you turn off the main power switch of

the machine.

Action

The error is automatically released after two seconds, and the machine automatically prints

out the lost report that shows the records still

existing in the activity report.

Table of Contents









Next

Before Using the Machine '

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

MEMORY FULL

Description The machine is full of jobs.

Print, send, or delete any documents stored in Action

memory.

Action Divide the document stack or data into a few

parts and try again one by one.

Action Send the document with low resolution.

Action When this message appears while using the ADF,

> the scanning document stops halfway. In this case, clear the paper jam from the ADF.

The number of TX/RX jobs that can be stored in Description

memory reached the maximum.

The machine memory can store up to 256 fax Action

> jobs including sending and receiving jobs. (Based on the condition that the other party sends the fax by the imageCLASS MF4270 with ITU-T Standard Chart No.1, standard mode.) Wait for the machine to send any faxes in memory. Also print or delete any documents in

memory.

NOT AVAILABLE

Description You pressed the one-touch speed dialing key

that has already been registered, when you are

registering group dialing.

You selected the group dialing that has already Description

been registered, when you are registering a one-

touch speed dialing key.

Register the one-touch speed dialing key that is **Action**

not used.

NOT REGISTERED

No recipient is registered for the one-touch Description

speed dialing key or coded speed dialing code

you pressed.

Action Register the recipients before using the Address

Book function.

OUT OF TONER CHANGE TONER

The toner ran out completely. Description

Action Replace the toner cartridge.

Table of Contents











Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

PAPER JAM

Description Paper jams have occurred in the machine.

<LIFT PANEL TO OPEN/OPEN TONER COVER>

appears alternately.

Clear the paper jam (See "Paper Jams," on **Action**

> p. 10-6.) and reload paper in the paper cassette or multi-purpose tray. The cover must be opened

and closed to resume the current job.

PAPER JAM OPEN REAR COVER

Paper jams have occurred in the machine. Description

<LIFT PANEL TO OPEN/OPEN TONER COVER>

appears alternately.

Clear the paper jam (See "Paper Jams," on **Action**

> p. 10-6.) and reload paper in the paper cassette or multi-purpose tray. The cover must be opened

and closed to resume the current job.

PLEASE WAIT

This message appears when turning on the main Description

power switch, or when the machine is not ready

for printing.

Action Wait until the message disappears.

REMOVE MP PAPER

Description

Paper is loaded in the multi-purpose tray.

Action

Remove the paper from the multi-purpose tray. The machine will not print faxes, reports, or lists when paper is loaded in the multi-purpose tray.

They will be stored in memory.

SET PAPER AGAIN SET TONER AGAIN

Description

Paper is not loaded properly, or the toner

cartridge is not set.

Action

Load paper properly. (For instructions on how to load paper in the paper cassette, see "Set Up the Machine" in the Starter Guide and to load paper in the multi-purpose tray, see "Loading Paper,"

on p. 2-10.)

Set the toner cartridge in the machine (see "Set

Up the Machine" in the Starter Guide).

SYSTEM ERROR **EXXX**

Description

Action

A system error has occurred. <XXX> will be a

three-digit code that indicates a particular type of error.

Turn off the main power switch, wait for more

than 5 seconds, then turn it on again. If the message persists, turn off the main power switch,

disconnect the power cord, and contact Canon

Customer Care Center.

Table of Contents

Index

10-18







Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

,

WRONG PASSWORD

Description The memory lock reception password or system

password you entered is incorrect.

Action Enter the correct password.

For details, see "Memory Lock Reception," on p. 4-26 or "Specifying the System Manager

Settings," on p. 8-2.

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

Sending and

Printing and

Receiving

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

1


Appendix

11

9

Error Codes

An error code is a four-digit code shown on an ERROR TX REPORT or an ERROR RX REPORT when an error occurs.



Error Code

For details on reports, see "Printing Reports Automatically," on p. 11-26.

See the following for individual error codes.

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

rinting and canning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

_____10

Appendix

11

9

00A0	
Description	Transmission was manually canceled on the machine.
Action	Resend the document if necessary.
00A1	
Description	There is a document jam.
Action	Clear the document jam.
00FF	
Description	All redialing attempts have failed.
Action	Check if the recipient's number is correct or the telephone cable is properly connected, and try again.
0001	
Description	The sender may not be using a G3 fax machine.
Action	Make sure the sender's machine is compatible with your machine.

0070	
Description	Reception was manually canceled on the machine.
Action	Ask the sender to resend the document if necessary.
0071	
Description	The machine's memory is full.
Action	Print, send, or delete any documents stored in memory.
0080	
Description	The recipient's machine did not respond within 35 seconds.
Action	Resend the document. Ask the other party to check their machine. If you are making an overseas call, add a pause to the number.
008D	
Description	The recipient's machine has run out of paper.
Action	Ask the recipient to make sure that paper is loaded in their machine.

Table of Contents







Next

TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

If <LOAD CORRECT PAPER> is displayed

When <LOAD CORRECT PAPER> appears on the LCD display, the size of the paper in the paper cassette or multi-purpose tray is different from that of the paper specified in <CASSETTE> or <MP TRAY> of the <PAPER SETTINGS> menu. You need to load the correct size paper or change the paper size in <CASSETTE> or <MP TRAY> of the <PAPER SETTINGS> menu.



For print jobs, you need to specify the paper size from your computer.

- Re-loading the Paper
- 1. Load the correct size paper as shown on the LCD display, then press [OK] to resume the job.

The machine re-starts printing.

- Changing the Paper Size Setting
- 1. Press [Additional Functions].



If <LOAD CORRECT PAPER> appears during a copy job, you cannot access the paper size setting through [Additional Functions]. In this case, cancel the job first, then press [Additional Functions] and change the paper size setting. For how to cancel copy jobs, see "Canceling Copy Jobs," on p. 3-11.

- 2. Press [◄–] or [+►] to select <PAPER SETTINGS>, then press [OK].
- 3. Press [◄–] or [+►] to select <CASSETTE> or <MP TRAY>, then press [OK].
- **4.** Press [◄–] or [+▶] to select <PAPER SIZE>, then press [OK].
- 5. Press [◄–] or [+►] to select the paper size same as paper loaded into the machine, then press [OK].

Table of Contents



6. Press [Stop/Reset] to return to the standby mode.

Now ready to copy your document. For a fax job or report printing, go to step 7.

7. Press [OK] to resume the job.

No further operation is required.

Before Using the Document and Paper Copying Sending and Receiving **Remote UI System Manager** Settings Maintenance 9 **Troubleshooting**

Table of Contents

Index

TOP

Next









Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

General Problems

The machine has no power.

Is the power cord plugged in securely?

Α

Check that the power cord is securely plugged into the machine and into the wall outlet. If the machine is plugged into a power strip, make sure the power strip is plugged in and turned on.

Q

Is the power cord supplying power?

Use a different power cord, or test the cord for continuity using a voltmeter.

Is the main power switch turned on?

Turn on the main power switch.

The Error indicator flashes.

Q

Does the machine feed paper correctly, or is there paper in the paper cassette or multi-purpose tray?

Α

Clear the paper jam, or load paper in the paper cassette or multi-purpose tray. (For instructions on clearing paper jam, See "Clearing Jams," on p. 10-3. For instructions on loading paper, see "Set Up the Machine," in the Starter Guide.)

Α

If the machine has no paper jam, or paper is loaded in the paper cassette or multi-purpose tray, turn off the main power switch and wait for more than 10 seconds, then turn it on again. If the problem is fixed, the Error indicator will turn off, and the LCD will return to the standby mode. If the Error indicator remains flashing, unplug the machine, and contact Canon Authorized Service Facilities or the Canon Customer Care Center.

Table of Contents







Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

11

9

Nothing appears in the LCD.

Α

Α

Q Is the power cord plugged in securely?

Check that the power cord is securely plugged into the machine and into the wall outlet. If the machine is plugged into a power strip, make sure the power strip is plugged in and turned on.

Q Is the main power switch turned on?

A Turn on the main power switch.

Q Is the machine in the Sleep mode?

Press [Energy Saver] on the operation panel to cancel the Sleep mode.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Paper Feeding Problems

Paper does not feed properly.

Α

Α

Α

Is the paper loaded correctly?

Make sure the paper is correctly loaded. (See "Set Up the Machine," in the Starter Guide.)

Does the machine contain too many sheets?

Α Make sure you load the correct quantity. (See "Paper Requirements," on p. 2-7.)

Multiple sheets feed together into the machine.

Is the paper loaded correctly? Q

> Make sure the paper is correctly loaded. (See "Set Up the Machine," in the Starter Guide.)

Does the machine contain too many sheets?

Make sure you load the correct quantity. (See "Paper Requirements," on p. 2-7.)

Are different types of paper loaded in the Q machine?

Load only one type of paper.

Make sure you load paper that meets the Α requirements for use. (See "Paper Requirements," on p. 2-7.)

Let the paper run out before refilling the machine. Α Avoid mixing new stock with paper already loaded.

Repeated paper jams occur.

Α

Is the correct type of paper loaded in the machine? Q

> Make sure you load paper that meets the requirements for use. (See "Paper Requirements," on p. 2-7.)

Table of Contents









Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager

Maintenance

Settings

Troubleshooting

9

Fax Problems

Sending Problems

Cannot send a fax.

Α

Α

Did you just turn on the main power switch? Q

> Wait for a while. After turning on the main power switch, the machine cannot scan documents immediately.

Q Is the machine set for the correct telephone line type?

Make sure the machine is set for the correct telephone Α line type. (See "Before FAX Setting," in the Starter Guide.)

Is your machine in the fax mode?

Press [FAX] to show the fax standby display.

Is the document loaded correctly?

Make sure the document is correctly loaded. (See Α "Loading Documents," on p. 2-4.)

Make sure the scanning platform and rear cover are fully closed. (See "Paper Jams," on p. 10-6.)

Q Is the one-touch speed dialing key or coded speed dialing code you entered registered correctly?

Check that the Address Book settings are registered Α correctly. (See "Storing/Editing Address Book," on p. 4-6.)

Did you dial the correct number?

Α

Check that you have the correct number.

Table of Contents



Before Using the Document and Paper Copying Sending and Receiving **Printing and** Network **Remote UI System Manager Settings** Maintenance 9 **Troubleshooting**

Q Is the machine in the Sleep mode?

Q

Α

Q

Α

The machine does not scan documents if it is in the Sleep mode. To take the machine out of the Sleep mode, press [Energy Saver] on the operation panel.

Is the recipient's machine out of paper?

Ask the recipient to make sure paper is loaded in the machine.

Are there other documents being sent from memory?

Allow time for the documents to finish sending.

Has an error occurred during transmission?

Check the LCD for an error message. (See "LCD Messages," on p. 10-14.)

Print an Activity Report and check for an error. (See "ACTIVITY REPORT," on p. 11-28.)

Q Is the telephone cable connected properly?

A Make sure the cable is connected properly. (See "Before FAX Setting," in the Starter Guide.)

Q Is the telephone line working properly?

Α

Α


Back

Make sure there is a dial tone when you press [Hook] or when you lift the handset of any external telephone connected to the machine. If there is no dial tone, contact your local telephone company.

Q Is the recipient's machine a G3 fax machine?

Make sure the recipient's machine is compatible with your machine.

Table of Contents



System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

Table of Contents

Index

Print, send, or delete any documents stored in

memory.







ТОР

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

Faxes sent from the machine are spotted or dirty.

Q Is the recipient's machine working properly?

Check the machine by making a copy. If the copy is clear, the problem may be in the recipient's machine. If the copy is spotted or dirty, clean the scanner components. (See "Scanning Area," on p. 2-3.)

Q Is the document loaded correctly?

A Make sure the document is correctly loaded. (See "Loading Documents," on p. 2-4.)

The documents you sent are too light.

Α

Q Is the density setting changed to be lighter?

A Adjust the density for light documents to be darker. (See "Density," on p. 4-5.)

Q Are the scanning components of the machine clean?

If the received document is spotted or dirty, clean the scanning components. (See "Scanning area," on p. 9-8.)

Sending of documents is too slow.

Q Is the resolution set to <FINE>, <PHOTO> or <SUPER FINE>?

A Setting the resolution to <STANDARD> reduces the sending time.

Errors occur frequently while sending.

Q Are the telephone lines in poor condition, or do you have a bad connection?

A Check if there is a device nearby that interferes with signal transmission (e.g., microwave oven).

Cannot redial with [Redial/Pause].

Α

Q Is <RESTRICT REDIAL> set to <ON>?

When <RESTRICT REDIAL> is set to <ON>, Redialing is not available. (See "Restricting Redial," on p. 8-4.)

Table of Contents







Before Using the Machine

Document and Paper

Copying

3

9

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

EIIUIA

Entering the fax number is required again after pressing [Start].

Q

Is <CONFIRM FAX NO.> set to <ON>?

Α

When <CONFIRM FAX NO.> is set to <ON>, you need to enter the fax number again after pressing [Start]. (See "Confirming Entered Fax Numbers," on p. 8-3.)

Receiving Problems

Cannot receive a fax automatically.

Q

Is the machine set to receive automatically?

Α

For the machine to receive faxes automatically, the receive mode must be set to <FaxOnly>, <FAX/TEL>, <AnsMode>, or <DRPD>. If you have set <AnsMode>, confirm that an external telephone with built in answering machine is connected to the machine and that it is turned on with an outgoing message properly recorded. (See "Basic Receiving Method," on p. 4-23.)

Q Are documents stored in memory, leaving little or no memory available?

A Print, send, or delete any documents stored in memory.

Q Has an error occurred during reception?

A Check the LCD for an error message. (See "LCD Messages," on p. 10-14.)

A Print an Activity Report and check for an error. (See "ACTIVITY REPORT," on p. 11-28.)

Q Is paper loaded in the machine?

Α

A Make sure paper is loaded in the machine. (See "Set Up the Machine," in the Starter Guide.)

Q Is the telephone cable connected properly?

Make sure the cable is connected properly. (See "Before FAX Setting," in the Starter Guide.)

Table of Contents



c Previous

Next

TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

No automatic switching between telephone and fax calls.

Is the machine set to switch automatically between telephone and fax calls?

For the machine to switch between fax and telephone calls automatically, the receive mode must be set to <FAX/TEL>, <AnsMode>, or <DRPD>. If you have set <AnsMode>, confirm that an answering machine is connected to the machine and that it is turned on with an outgoing message properly recorded. (See "Basic Receiving Method," on p. 4-23.)

Q Are documents stored in memory, leaving little or no memory available?

A Print, send, or delete any documents stored in memory.

Q Has an error occurred during reception?

A Check the LCD for an error message. (See "LCD Messages," on p. 10-14.)

A Print an Activity Report and check for an error. (See "ACTIVITY REPORT," on p. 11-28.)

Q Is paper loaded in the machine?

A Make sure paper is loaded in the machine. (See "Set Up the Machine," in the Starter Guide.)

Q Can the sender's machine send the CNG signal, which tells your machine that the incoming call is a fax call?

A Some machines cannot send this signal. In such cases, receive the fax manually.

Cannot receive a document manually.

Q Is the machine set to receive manually?

For the machine to receive faxes manually, the receive mode must be set to <MANUAL>. (See "Basic Receiving Method," on p. 4-23.)

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

Q Did you hang up the external telephone before pressing [Start] or dialing the remote reception ID?

Always press [Start] or dial the remote reception ID before hanging up. Otherwise you will disconnect the call.

Q Are documents set on the ADF?

After removing the document from the ADF, please attempt manual receiving again. If you press [Start] when documents are set on the ADF, it automatically switches to manual sending.

Print quality is poor.

Α

Α

Is the toner low or unevenly distributed?

Redistribute the toner inside the toner cartridge. If the problem persists, replace the toner cartridge. (See "Replacing the Toner Cartridge," on p. 9-11.) Q Is the correct type of paper loaded in the machine?

Make sure you load paper that meets the requirements for use. (See "Paper Requirements," on p. 2-7.)

Q Is the sender's machine functioning properly?

A Ask the sender to check that the scanning components of the machine are clean.

Q Is the machine in the toner saver mode?

A Set <TONER SAVER MODE> to <OFF>. (See "COMMON SETTINGS," on p. 11-7.)

Faxes do not print.

Α

Q Have you removed the plastic seal from the toner cartridge?

Make sure you remove the seal from the cartridge. (See "Set Up the Machine," in the Starter Guide.)

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

Q Is the toner cartridge installed properly?

Make sure the toner cartridge is installed properly. (See "Set Up the Machine," in the Starter Guide.)

Q Is the cartridge out of toner?

Replace the toner cartridge. (See "Replacing the Toner Cartridge," on p. 9-11.)

Q Is the correct size of paper loaded in the machine?

Make sure you load paper that meets the requirements for use. (See "Paper Requirements," on p. 2-7.)

A Change <PAPER SETTINGS>. (See "Setting Paper Size and Type," on p. 2-13.)

Received faxes print blotched or unevenly.

Α

Q Is the sender's machine functioning properly?

Ask the sender to check that the scanning components of the machine are clean.

Q Is the toner low or unevenly distributed?

Back

A Redistribute the toner inside the toner cartridge. If the problem persists, replace the toner cartridge. (See "Replacing the Toner Cartridge," p. 9-11.)

Part of the document you receive is cut off.

Q Are the slide guides of the paper cassette set to the size of the paper?

A Adjust the guides of the paper cassette to the size of the paper.

Q Have you specified the correct paper size for the paper cassette?

Specify the correct paper size for the paper cassette.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Α

Α

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

Q Is the toner low or unevenly distributed?

A Redistribute the toner inside the toner cartridge. If the problem persists, replace the toner cartridge. (See "Replacing the Toner Cartridge," on p. 9-11.)

Is the printing method for received documents set to <CUT>?

If you want to print a received document without cutting off the end, set the printing method to <ON> or <OFF>. (See "Received Image Reduction," on p. 4-31.)

Cannot receive using Error Correction Mode (ECM).

Q Does the sender's machine support ECM?

If the sender's machine does not support ECM, the document is received in normal mode without error checking.

Receiving of documents is too slow.

Q Is the resolution of the sender's machine set higher?

A Contact to the sender and make sure the resolution of the sender's machine has been set properly.

You cannot get documents from information services.

ls your machine set to the tone dialing type of the telephone line?

A Press [Tone] to set the tone dialing.

Q Do you receive messages from the information services such as to press [Start] after the beep to receive?

A When you hear the beep sound, press [Start].

Table of Contents







Before Using the Machine

Document and Paper

Copying

ر 3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appopdix

11

9

Errors occur frequently while receiving.

Q Are the telephone lines in poor condition, or do you have a bad connection?

A Check if there is a device nearby that interferes with signal reception (e.g., microwave oven).

Q Is the sender's machine functioning properly?

A Ask the sender to check that the machine is functioning properly.

Cannot print received documents on both sides of the paper.

Q Is <2-SIDED PRINT>, set to <ON>?

Α

Make sure that <2-SIDED PRINT> is set to <ON>. (See "Two-Sided Printing," on p. 4-30.)

Table of Contents









Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

Copying Problems

Blank paper comes out from the machine.

Α

Α

Q Have you removed the plastic seal from the toner cartridge?

Make sure you remove the seal from the cartridge.

(See "Set Up the Machine," in the Starter Guide.)

Q Is the toner cartridge installed properly?

Make sure the toner cartridge is installed properly.
(See "Set Up the Machine," in the Starter Guide.)

Q Is the cartridge out of toner?

Replace the toner cartridge. (See "Replacing the Toner Cartridge," on p. 9-11.)

Does the document meet the requirements for the machine?

Make sure you load documents that meet the requirements for use. (See "Document Requirements," on p. 2-2.)

Copy is too light or has uneven density.

Q Is the toner low or unevenly distributed?

Redistribute the toner inside the toner cartridge. If the problem persists, replace the toner cartridge. (See "Replacing the Toner Cartridge," on p. 9-11.)

Copy has vertical white streaks.

Is the toner low or unevenly distributed?

Redistribute the toner inside the toner cartridge. If the problem persists, replace the toner cartridge. (See "Replacing the Toner Cartridge," on p. 9-11.)

Copy is spotted or dirty.

Q

If the copy is spotted or dirty, clean the scanning components and machine's interior (See "Cleaning the Machine," on p. 9-2.)

Table of Contents









Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Paper jams occur.

Make sure the scanning platform and rear cover are Α fully closed. (See "Paper Jams," on p. 10-6.)

Is the paper loaded correctly?

Make sure the document is correctly loaded. (See "Set Up the Machine," in the Starter Guide.)

Is the correct type of paper loaded in the machine? Q

Α Make sure you load paper that meets the requirements for use. (See "Paper Requirements," on p. 2-7.)

Copy is skewed.

Is the paper loaded correctly?

Α Make sure the paper is correctly loaded in the machine. (See "Set Up the Machine," in the Starter Guide.)

Make sure the paper delivery slot is free of obstructions.

Copy is not clear.

Α

Is the correct type of paper loaded in the machine?

Α Make sure you load paper that meets the requirements for use. (See "Paper Requirements," on p. 2-7.)

Q Are you copying on the wrong side of the paper?


Some papers have a "right" side for copying. If the copy quality is not as clear as you think it should be, try copying on the other side of the paper.

Documents are copied in < CALENDAR TYPE> even if <BOOK TYPE> is selected (or vice versa).

Are you copying the landscape oriented documents?

> For the landscape oriented documents, the front and back sides of the copy will have the opposite topbottom orientation when <BOOK TYPE> is selected. When <CALENDAR TYPE> is selected, the front and back side of the copy will have the same top-bottom orientation. (See "Two-Sided Copy," on p. 3-8.)

Table of Contents



Sending and Receiving 4.

Remote UI

7

System Manager
Settings

8

Maintenance

9

Troubleshooting

Table of Contents









Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Printing Problems

Blank paper comes out from the machine.

Α

Α

Have you removed the plastic seal from the toner cartridge?

Make sure you remove the seal from the cartridge. (See "Set Up the Machine," in the Starter Guide.)

Is the toner cartridge installed properly?

Make sure the toner cartridge is installed properly. (See "Set Up the Machine," in the Starter Guide.)

Is the cartridge out of toner?

Replace the toner cartridge. (See "Replacing the Toner Cartridge," on p. 9-11.)

Printout is too light or has uneven density.

Is the toner low or unevenly distributed?

Redistribute the toner inside the toner cartridge. If the problem persists, replace the toner cartridge. (See "Replacing the Toner Cartridge," on p. 9-11.)

Printout has vertical white streaks.

Is the toner low or unevenly distributed?

Redistribute the toner inside the toner cartridge. If the problem persists, replace the toner cartridge. (See "Replacing the Toner Cartridge," on p. 9-11.)

Printout is spotted or dirty.

Q

Α

If the copy is spotted or dirty, clean the scanning components and machine's interior (See "Cleaning the Machine," on p. 9-2.)

Table of Contents



Previous



TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

Paper jams occur.

A Make sure the scanning platform and rear cover are fully closed. (See "Paper Jams," on p. 10-6.)

Q Is the document loaded correctly?

Make sure the document is correctly loaded. (See "Set Up the Machine," in the Starter Guide.)

Q Is the correct type of paper loaded in the machine?

Make sure you load paper that meets the requirements for use. (See "Paper Requirements," on p. 2-7.)

Printout is skewed.

Q Is the paper loaded correctly?

Make sure the paper is correctly loaded in the machine. (See "Set Up the Machine," in the Starter Guide.)

Make sure the Output tray is free of obstructions. (See "Machine Components," on p. 1-3.)

Printout is not clear.

Q Is the correct type of paper loaded in the machine?

Make sure you load paper that meets the requirements for use. (See "Paper Requirements," on p. 2-7.)

Q Are you printing on the wrong side of the paper?

A Some papers have a "right" side for printing. If the printout quality is not as clear as you think it should be, try printing on the other side of the paper

Cannot print two-sided documents

Is the printer driver settings correctly set for two-sided printing?

Make sure that the printer driver is correctly set. (See Online Help.)

Cannot print documents from a computer.

Α

Q Is the printer driver properly installed?

Make sure that the printer driver is properly installed.

Table of Contents



Previous Next

ТОР

Before Using the Machine

Document and Paper

Α

Α

0

Α

Q

Α

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

Q Are the printer driver settings (Paper Size, Output Size) correct?

Make sure that the printer driver settings (Paper Size, Output Size) are correct. (See Online Help.)

Is the USB cable properly connected to the machine and the computer?

Make sure that the USB cable is properly connected to the machine and the computer. Try a different USB cable.

Does the USB port you are using properly work?

Restart your computer and the machine. If the computer has other ports, connect the USB cable to others.

Are there any jobs remaining in the print queue?

A print job may be stuck in the print queue when it could not be finished due to an expected interruption. When this happens, follow this procedure to delete any remaining print jobs, and then print the documents again.

For Windows 2000/XP/Server 2003/Vista:

Back

- 1. Double-click the icon of the printer you installed.
 - For Windows Vista
 Click [Start] on the Windows task bar → [Control Panel] → [Printer] under [Hardware and Sound].
 - For Windows 2000:
 Click [Start] on the Windows task bar → [Settings]
 → [Printers].
 - For Windows XP Professional/Server 2003:
 Click [start] on the Windows task bar → [Printers and Faxes].
 - For Windows XP Home Edition:
 Click [start] on the Windows task bar → [Control Panel] → [Printers and Other Hardware] →
 [Printers and Faxes].
- 2. Delete the print job.
 - For deleting all the print jobs:
 Click [Printer] → [Cancel All Documents]
 - For the specified job:
 Right-click the specified print job → [Cancel]

Table of Contents









Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

Telephone Problems

Cannot dial.

Α

Α

Q Is the telephone cable connected properly?

A Make sure the cable is connected properly. (See "Before FAX Setting," in the Starter Guide.)

Q Is the power cord plugged in securely?

Check that the power cord is securely plugged into the machine and into the wall outlet. If the machine is plugged into a power strip, make sure the power strip is plugged in and turned on.

Q Is the main power switch turned on?

A Turn on the main power switch.

Is the machine set for the correct telephone line type?

Make sure the machine is set for the correct telephone line type. (See "Before FAX Setting," in the Starter Guide.)

Telephone disconnects while you are talking.

Q Is the telephone cable connected properly?

Make sure the cable is connected properly. (See "Before FAX Setting," in the Starter Guide.)

Q Is the telephone cable defective?

A Use another cord.

Calls do not connect, or the wrong number is dialed.

Q Did you confirm the dial tone before entering the telephone number?

Make sure to confirm the dial tone before entering a telephone number. If you enter the number before the dial tone can be heard, the call may not connect, or the wrong number may be dialed.

Table of Contents



Previous

Next

TOP

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

Network Problems

Unable to print from a TCP/IP network.

Α

Α

Α

Q Are the machine and cable properly connected?

Check that the machine is connected to the network using the proper cable, then restart the machine. (See "Software Settings with Computer," in the Starter Guide.)

Q Is the TCP/IP network properly set up?

Make sure the IP addresses are properly set up. If the IP addresses are set using DHCP, BOOTP, or RARP, make sure they are operating.

Is the computer that is printing properly set up?

Make sure the proper printer driver is installed. (See "Software Settings with Computer," in the Starter Guide.)

Make sure the correct machine is set as the output destination for the computer that is printing in [Printers and Faxes] or Print Manager.

Is the name of the file being printed too long?

Rename the file with a shorter name. Normally LPR (or the Microsoft TCP/IP Printer, if you are using Windows 2000/XP/Server 2003/Vista) sends jobs either under the name of the application software used for printing, or the file name. However, a job name longer than 255 bytes cannot be sent to the machine.

The printer port name is not displayed in [Print to the following port (s)].

Q Are the machine and cable properly connected?

Check that the machine is connected to the network using the proper cable, then restart the machine. (See "Software Settings with Computer," in the Starter Guide.)

Table of Contents







Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

11

9

Q

Is the computer that is printing properly set up?

Α

Make sure the proper printer driver is installed. (See "Software Settings with Computer," in the Starter Guide.)

Α

Make sure the correct machine is set as the output destination for the computer that is printing in [Printers and Faxes] or [Printers].

Detailed information concerning the machine cannot be set or browsed using the Remote UI or utility.

Q

Does the SNMP community name match?

Α

If you use an SNMP community name different from the one stored in the machine to access the machine from a utility, the utility will not detect the machine. In this case, check the SNMP community name. (See "SNMP" on p. 6-7.)

Table of Contents



Back





TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10.

Appendix

11

If a Power Failure Occurs

If a power failure occurs, machine functions will be limited as follows:

- Depending on your telephone, you may not be able to make telephone calls.
- You can receive telephone calls from the telephone connected to the machine.
- You cannot send, receive, or copy documents.

If power is suddenly lost due to a power failure or accidental unplugging, the machine may lose any data stored in the memory, including received fax documents. If this happens, the LCD displays <LOST IMAGE> when power is restored and automatically prints a Lost Report (unless the cartridge is empty or there is no paper in the machine) that lists the documents (received in the last 60 transactions) that were lost from memory as a result of the power cut.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Appendix

11

If You Cannot Solve a Problem

Customer Support (U.S.A.)

If you cannot solve the problem after having referred to the information in this chapter, contact Canon Customer Care Center at 1-800-828-4040 between the hours of 8:00 A.M. to 8:00 P.M. EST Monday through Friday and 10:00 A.M. to 8:00 P.M. on Saturday. Online support for 24 hours is also available at the website. http://www.canontechsupport.com/

Customer Support (Canada)

Canon Canada Inc., offers a full range of customer technical support options*:

- For step-by-step troubleshooting, e-mail technical support, the latest driver or document downloads, and answers to frequently asked questions, visit
 - http://www.canon.ca/
- Free live technical support 9 A.M. to 8 P.M. EST Monday through Friday (excluding holidays) for products still under warranty 1-800-652-2666
- For the location of the authorized service facility nearest you, visit http://www.canon.ca/ or 1-800-652-2666
- If the problem cannot be corrected by using one of the above technical support options, repair options are available at the time of your call to the live technical support number above or via the website at http://www.canon.ca/
- * Support program specifics are subject to change without notice.

Please have the following information ready when you contact Canon:

- Product name (imageCLASS MF4270)
- Serial number (On the label located at the back of the machine)
- Place of purchase
- Nature of problem
- Steps you have taken to solve the problem and the results



CAUTION

If the machine makes strange noises, emits smoke or odd odor, turn off the main power switch immediately, disconnect the power cord, and contact Canon Customer Care Center. Do not attempt to disassemble or repair the machine yourself.



Attempting to repair the machine yourself may void the limited warranty.

Table of Contents







Before Using the Machine

Document and Paper

3

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting 10

Appendix

11

11Appendix

Machine Settings	••••••	11-3
	Printing USER DATA LIST	11-3
	Accessing the Setting Menu	11-3
Setting Menu	••••••	11-5
-	PAPER SETTINGS	11-5
	VOLUME CONTROL	11-6
	BROADCAST	11-7
	COMMON SETTINGS	11-7
	COPY SETTINGS	11-8
	FAX SETTINGS	11-9
	ADDRESS BOOK SET	11-14
	PRINTER SETTINGS	11-15
	TIMER SETTINGS	11-16

Table of Contents









Before Using the Machine	
Document and Paper 2	
Copying 3	
Sending and Receiving 4	
Printing and Scanning 5	
Network 6	
Remote UI	
System Manager Settings	
Maintenance 9	
Troubleshooting 10	
Annendiv	

Glossary	11-31
Checking Remaining Memory	11-30
Printing Reports and Lists Manually	11-29
ACTIVITY REPORT	11-28
RX REPORT	
TX REPORT	11-26
Printing Reports Automatically	11-26
Summary of Reports and Lists	11-25
SYSTEM SETTINGS	11-20
REPORT SETTINGS	11-18
ADJUST./CLEANING	11-17

Table of Contents







Next



Before Using the Machine

Document and Paper

Copying

_

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

<u> 10</u>

Appendix

11

Machine Settings

You can adjust the machine settings from the Setting Menu to customize the way the machine works. To see the list of the current settings, print out USER DATA LIST.

- Printing USER DATA LIST
- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <REPORT SETTINGS>, then press [OK].
- Press [◄–] or [+►] to select <LIST PRINT>, then press [OK].
- **4.** Press [◄–] or [+►] to select <USER DATA LIST>, then press [OK].

Printing starts, and the screen automatically returns to the standby mode.

- Accessing the Setting Menu
- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select the menu you want to access, then press [OK].
 - <PAPER SETTINGS>
 - <VOLUME CONTROL>
 - <BROADCAST>
 - <COMMON SETTINGS>
 - <COPY SETTINGS>
 - <FAX SETTINGS>
 - <ADDRESS BOOK SET.>
 - <PRINTER SETTINGS>
 - <TIMER SETTINGS>
 - <ADJUST./CLEANING>
 - <REPORT SETTINGS>
 - <SYSTEM SETTINGS>



Back





ТОР

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

3. Press [◄–] or [+►] to select a submenu, then press [OK].



For details on the submenu, see "Setting Menu," on p. 11-5.

- 4. To register the settings or go to a submenu item, press [OK].
- **5.** When finished, press [Stop/Reset] to return to the standby mode.



- If you press [Stop/Reset] before pressing [OK], the setting will not be registered.
- Press [Additional Functions] to return to the previous display.

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

Sending and

Printing and Scanning

Network

Receiving

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Annendix

11

Setting Menu

The default settings are indicated in bold text.



Depending on the country of purchase, some settings may not be available.

PAPER SETTINGS	
Setting Item	Description
1. CASSETTE	Sets the paper size and type on the paper cassette. (See "Setting Paper Size and Type," on p. 2-13.)
1. PAPER SIZE	Sets the paper size from the following options: LTR, LGL, A4, B5, A5, EXECUTIVE, COM10, MONARCH, DL, ISO-C5, OFICIO, BRAZIL-OFICIO, MEXICO-OFICIO, FOLIO, GOVERNMENT-LETTER, GOVERNMENT-LEGAL, and FOOLSCAP
2. PAPER TYPE	Sets the paper type from the following options: PLAIN PAPER , PLAIN PAPER L, HEAVY PAPER, HEAVY PAPER H, and TRANSPARENCY
2. MP TRAY	Sets the paper size and type on the purpose tray. (See "Setting Paper Size and Type," on p. 2-13.)
1. PAPER SIZE	Sets the paper size from the following options: LTR, LGL, A4, B5, A5, EXECUTIVE, COM10, MONARCH, DL, ISO-C5, OFICIO, BRAZIL-OFICIO, MEXICO-OFICIO, FOLIO, GOVERNMENT-LETTER, GOVERNMENT-LEGAL, and FOOLSCAP
2. PAPER TYPE	Sets the paper type from the following options: PLAIN PAPER , PLAIN PAPER L, HEAVY PAPER, HEAVY PAPER H, and TRANSPARENCY

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

> Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

1

11

VOLUME CONTROL	
Setting Item	Description
1. MONITOR VOLUME	Sets the volume for monitor tone during the fax transmission. $(0-3 \ (2))$
2. CALLING TONE	Sets the volume of the ring produced when the machine detects a call. $(0-3 \ (2))$
3. ENTRY TONE	Beeps when pressing the keys on the operation panel. (0–3 (2))
4. ERROR TONE	Beeps when an error (e.g., TX error) occurs. (0–3 (2))

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

_____10

Appendix

11

9

BROADCAST	
Setting Item	Description
1. BROADCAST	Registers recipients for broadcasting. A maximum of 124 recipients can be specified at the same time. (See "Broadcasting" on p. 4-17.)

COMMON SETTINGS	
Setting Item	Description
1. INITIAL FUNCTION	Selects which standby display appears when turning on the power. - COPY - FAX - SCAN
2. TONER SAVER MODE	Sets whether to reduce toner consumption. - OFF - ON * This function is not effective for print jobs.
3. DISPLAY LANGUAGE	Selects the language on the display. (See Chapter 13, "Appendix," in the Basic Operation Guide.) - ENGLISH - FRENCH - SPANISH - PORTUGUESE

Table of Contents







Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

rinting and canning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

opendix 1

COPY SETTINGS	
Setting Item	Description
1. STANDARD SETTINGS	Sets the default setting for copying.
1. IMAGE QUALITY	Sets the document type for copying. - TEXT/PHOTO - TEXT - PHOTO - TEXT/PHOTO+
2. DENSITY	Sets the density for copying. - MANUAL (1–9 (5)) - AUTO
3. ZOOM RATIO	Sets the zoom ratio for copying.
PRESET RATIO	Selects the zoom from the preset ratios. (100%, 115% B5>A4, 122% A5>B5, 129% STMT>LTR, 141% A5>A4, 200% MAX., 50% MIN., 64%, 70% A4>A5, 78% LGL>LTR, 81% B5>A5, 86% A4>B5)
MANUAL	Enters the zoom ratio by 1% increments. (50%–200% (100%))
4. AUTO COLLATE	Sets whether to collate the copies automatically. - OFF - ON
5. 2-SIDED	Sets whether to make the two-sided copies automatically. – OFF – ON: CALENDAR TYPE, BOOK TYPE
2. PAPER SIZE GROUP	Selects a paper size group for your machine. - INCHES - A - AB

Table of Contents







Before Using the Machine

Document and Paper

3

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

1.

FAX SETTINGS	
Setting Item	Description
1. RX MODE	Selects the receive mode. (See "Set the Machine for Receiving Faxes," in the Starter Guide.) - FaxOnly - AnsMode - DRPD - FAX/TEL - MANUAL
2. USER SETTINGS	Specifies the basic operation settings in the fax mode.
1. UNIT TELEPHONE #	Registers your fax number (max. 20 characters, including spaces). (See "Set the Machine for Sending Faxes," in the Starter Guide.)
2. UNIT NAME	Registers your name/company name (max. 32 characters, including spaces). (See "Set the Machine for Sending Faxes," in the Starter Guide.)
3. TEL LINE TYPE	Selects the telephone line type. (See "Before FAX Setting," in the Starter Guide.) - TOUCH TONE - ROTARY PULSE
4. STANDARD SETTINGS	Sets the default setting for faxing.
1. DENSITY	Sets the default density for faxing (1–9 (5)).
2. IMAGE QUALITY	Sets the default image quality for faxing. - STANDARD - FINE - PHOTO - SUPER FINE

Table of Contents







ТОР

Before Using the Machine

Document and Paper

3

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

10

Appendix

11

9

FAX SETTINGS	
3. TX SETTINGS	Sets the transmission features.
1. AUTO REDIAL	Sets whether to redial automatically when the other line is busy or a transmission error occurs. (See "Redialing Automatically," on p. 4-20.)
ON	Customizes the redial operation.
1. REDIAL TIMES	Sets the number of retries. (1TIMES–10TIMES (2TIMES))
2. REDIAL INTERVAL	Sets period of time before redialing. (2MIN.–99MIN. (2MIN.))
OFF	After the first attempt at dialing fails, redialing is not attempted.
2. DIALING LINE CHCK	Sets whether to check the telephone line condition. - OFF - ON

Table of Contents







Before Using the Machine

Document and Paper

Copying

_

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

10

9

FAX SETTINGS	
4. RX SETTINGS	Sets the reception features.
1. FAX/TEL OPT. SET	Sets the optional items in the <fax tel=""> mode. (See "FAX/TEL: Optional Settings," on p. 4-24.)</fax>
1. RING START TIME	Sets the time the machine takes to check whether a call is a fax or a voice call. (4SEC–30SEC (6SEC))
2. F/T RING TIME	Selects the ring length for voice calls. (10SEC-45SEC (22SEC))
3. F/T SWITCH ACTION	Selects whether the machine switches to the receive mode after the ring time has elapsed, or whether if disconnects the call. - RECEIVE - DISCONNECT
2. DRPD:SELECT FAX	Selects the ring pattern for fax calls. - NORMAL RING - DOUBLE RING - SHORT-SHORT-LONG - SHORT-LONG-SHORT - OTHER RING TYPE
3. INCOMING RING	Sets whether the external telephone rings when the machine receives a fax. This function is only available when the <rx mode=""> is set to <faxonly> or <fax tel="">.</fax></faxonly></rx>
ON	The telephone rings when the machine receives a fax if an external telephone is connected.
RING COUNT	Sets the number of incoming rings before the machine answers. (1TIMES-16TIMES (2TIMES))
OFF	The telephone does not ring when the machine receives a fax. (In the Sleep mode, the telephone may ring one or two times.)

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and

Printing and

Vetwork

Receiving

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

10

9

FAX SETTINGS	
4. REMOTE RX	Sets whether to use remote receiving. (See "Remote Reception," on p. 4-28.)
ON	The machine enables remote receiving.
REMOTE RX ID	You can dial a code on remote extension to start receiving a document. A combination of two characters using 0 to 9. (default: 25)
OFF	The machine disables remote receiving.
5. RX PRINT	Sets whether to store all received pages in memory before printing them out or print each page as it is received. (See "Selecting the Receive Mode for Printing," on p. 4-29.)
MEMORY RX	Print after all the pages of the document are received.
PRINT RX	Print each page as it is received.
6. RX TERMINAL ID	Sets whether to insert the machine's fax number and the sender information on received faxes. - OFF - ON
7. RX RESTRICTION	You can reject faxes from senders with no fax/telephone number in their sender information. (See "Reception Restriction," on p. 4-30.)
OFF	All receptions are conducted.
ON	Receives the fax only from the sending fax machine that sends the TSI signal.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

_____10

Appendix

11

9

FAX SETTINGS	
5. PRINTER SETTINGS	Sets the printer functions.
1. RX REDUCTION	Sets whether to reduce or truncate the image when a faxed page is larger than the size of paper loaded. (See "Received Image Reduction," on p. 4-31.)
ON	Reduces the image to fit on the size of paper loaded.
OFF	Retains the original size of the image.
CUT	The image that is larger than 1-page record area is cut and not recorded.
2. 2-SIDED PRINT	Sets the type of two-sided printing for faxing. (See "Two-Sided Printing," on p. 4-30.) - OFF - ON
3. CONT. PRINTING	Sets whether to continue printing when toner has run out. This function is only for printing fax documents and reports. (See "Replacing the Toner Cartridge," on p. 9-11.) - OFF - ON

Table of Contents







Before Using the Machine

Document and Paper

Copying

_

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

11

10

9

ADDRESS BOOK SET.	
Setting Item	Description
1. 1-TOUCH SPD DIAL	Registers recipients on one-touch speed dialing keys. Up to 8 recipients can be registered. (See "Storing/Editing One-Touch Speed Dialing Keys/Coded Speed Dialing Codes," on p. 4-7.)
1. NAME	Registers the recipient's name (max. 20 characters, including spaces).
2. TEL NUMBER ENTRY	Registers the recipient's fax/telephone number (max. 50 digits, including spaces).
2. CODED DIAL	Registers recipients for coded speed dialing codes. Up to 100 recipients can be registered. (See "Storing/Editing One-Touch Speed Dialing Keys/Coded Speed Dialing Codes," on p. 4-7.)
1. NAME	Registers the recipient's name (max. 20 characters, including spaces).
2. TEL NUMBER ENTRY	Registers the recipient's fax/telephone number (max. 50 digits, including spaces).
3. GROUP DIAL	Registers recipients in group dialing. Up to 8 groups can be registered. (See "Storing/Editing Recipients for Group Dialing," on p. 4-9.)
NAME	Registers the group name (max. 20 characters, including spaces).
NO.0##=	Registers the recipient's fax/telephone numbers stored under the one-touch speed dialing keys or coded speed dialing codes. Up to 50 recipients can be registered in a group.

Table of Contents







Before Using the Machine

Document and Paper

3

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

PRINTER SETTINGS	
Setting Item	Description
1. ERROR TIME OUT	Sets the length of time before the machine returns an error when no data is received from the computer.
ON	Sets the error time out period. (5SEC–300SEC (15SEC))
OFF	The error time out is off.

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting 10

Appondix

11

TIMER SETTINGS	
Setting Item	Description
1. DATE&TIME SETTING	Sets the current date and time. (See "Set Up the Machine," in the Starter Guide.)
2. DATE TYPE SELECT	Sets the date format. - MM/DD/YYYY - DD/MM YYYY - YYYY MM/DD
3. AUTO SLEEP	Sets the auto sleep mode when the machine remains idle for a certain period of time. (3MIN.–30MIN. (5MIN.)) (See "Setting the Sleep Mode," on p. 1-15.) ON OFF
4. DAYLIGHT SV.TIME	Sets the daylight saving time mode. (See "Setting the Daylight Saving Time," on p. 1-16.)
OFF	Deactivates the daylight saving time mode.
ON	Activates the daylight saving time mode.
1. START DATE/TIME	Sets the start date. - 1. MONTH (MARCH) - 2. WEEK (SECOND WEEK) - 3. DAY (SUNDAY)
2. END DATE/TIME	Sets the end date. - 1. MONTH (NOVEMBER) - 2. WEEK (FIRST WEEK) - 3. DAY (SUNDAY)

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting 10

Annondiv

11

ADJUST./CLEANING	
Setting Item	Description
1. FIX.UNIT CLEANING	Cleans the fuser roller. (See "Fuser Roller," on p. 9-7.)
2. SPECIAL MODE T	Sets whether to prevent blur from appearing on the printouts for copying, receiving info, and reports. When this setting is set to <on>, the density of printouts may become light. OFF ON</on>
3. SPECIAL MODE U	Select to improve print quality in high temperature and high humidity conditions or in low temperature and low humidity conditions.
OFF	Select in normal condition.
MODE1	Select to improve print quality in low temperature and low humidity conditions, or when using thick paper or an envelope.
MODE2	Select to improve print quality in high temperature and high humidity conditions.
4. SPECIAL MODE V	Sets whether to prevent small size paper (B5, A5, EXECUTIVE, etc) from being curled. – OFF – ON
5. SPECIAL MODE Y	Sets to enhance the fixing characteristics of toner under the conditions of a low temperature environment. When this setting is set to <on>, first copy time and the time to resume from the sleep mode may take longer. OFF ON</on>

Table of Contents







Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

11

REPORT SETTINGS	
Setting Item	Description
1. SETTINGS	Sets the report functions. (See "Printing Reports Automatically," on p. 11-26.)
1. TX REPORT	Sets whether the transmission report prints out.
PRINT ERROR ONLY	Prints a report only when a transmission error occurs.
OUTPUT NO	No report is printed.
OUTPUT YES	Prints a report every time you send a document.
2. RX REPORT	Sets whether the reception report prints out. - OUTPUT NO - OUTPUT YES - PRINT ERROR ONLY
3. ACTIVITY REPORT	Sets whether an activity report is printed automatically every 60 transactions. - OUTPUT YES - OUTPUT NO

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

_

Sending and Receiving

rinting and canning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

REPORT SETTINGS	
2. LIST PRINT	Prints reports/lists.
1. TX REPORT	Prints the fax transmission report manually.
2. RX REPORT	Prints the fax reception report manually.
3. ACTIVITY REPORT	Prints the fax transaction report manually.
4. MEMORY DATA LIST	Prints the list of the reserved jobs in memory.
5. MEMORY IMAGE PRNT	Prints the information and image of the first page of the reserved job.
6. 1-TOUCH LIST	Prints the list of fax/telephone numbers and names registered for one-touch speed dialing.
7. CODED DIAL LIST	Prints the list of fax/telephone numbers and names registered for coded speed dialing.
8. GROUP DIAL LIST	Prints the list of groups registered for group dialing.
9. USER DATA LIST	Prints the setting list registered in the menu. (See "Printing USER DATA LIST," on p. 11-3.)

Table of Contents









Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

10

9

SYSTEM SETTINGS	
Setting Item	Description
1. SYS. MANAGER INFO	Sets the system manager information to protect the contents of <system settings="">. Once the system password is set, they must be entered every time you access the <system settings=""> menu.</system></system>
1. SYSTEM PASSWORD	Sets the system manager password (seven digits).
2. NETWORK SETTINGS	Sets the network setting. (See Chapter 6, "Network.")
1. TCP/IP SETTINGS	Sets TCP/IP network.
1. IP ADDRESS AUTO.	Sets whether to automatically set an IP address.
ON	Enables an IP address to the machine automatically. - 1. DHCP (ON /OFF) - 2. BOOTP (OFF /ON) - 3. RARP (OFF /ON)
OFF	Allocates an IP address to the machine manually.
2. IP ADDRESS	Registers a fixed IP address to the machine. (See "IP Address Setting," on p. 6-4.) (000.000.000)
3. SUBNET MASK	Registers a fixed subnet mask to the machine. (000.000.000)
4. GATEWAY ADDRESS	Registers a fixed gateway address to the machine. (000.000.000)

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Vetwork

Remote UI

System Manager Settings

Maintenance

Troubleshooting

_____10

Appendix

11

9

SYSTEM SETTINGS	
5. LPD PRINT	Sets whether to use LPD as the print application. - ON - OFF
6. RAW PRINT	Sets whether to use RAW as the print application.
ON	Enables to use RAW.
OFF	Disables to use RAW.
7. USE HTTP	Sets whether to activate HTTP (HyperText Transfer Protocol) for the Remote UI. ON OFF
8. PORT NO. SET.	Sets the port number settings.
1. LPD	0–65535 (default: 515)
2. RAW	0–65535 (default: 9100)
3. HTTP	0–65535 (default: 80)
4. SNMP	0–65535 (default: 161)

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and

3

Receiving Printing and

Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

10

Appendix

11

9

SYSTEM SETTINGS	
2. SNMP SETTINGS	Sets detailed information about SNMP.
1. USE SNMP	Sets whether to activate SNMP. - ON - OFF
2. COMMUNITY NAME 1	Sets SNMP community name 1 (default: public).
3. COMMUNITY NAME 2	Sets SNMP community name 2.
4. SNMP WRITABLE 1	Enables computers on the network to access the machine and modify its settings. - ON - OFF
5. SNMP WRITABLE 2	Enables computers on the network to access the machine and modify its settings. - OFF - ON

Table of Contents







Before Using the Machine

Document and Paper

Copying

3

Sending and Receiving

rinting and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

SYSTEM SETTINGS	
3. ETHERNET DRIVER	Specifies the type of network connection.
1. AUTO DETECT	Selects the detection method of Ethernet driver.
AUTO	Sets the machine to determine the communication mode (Half duplex/Full duplex) and Ethernet type (10Base-T/100Base-TX) automatically.
MANUAL	Sets the communication mode and Ethernet type manually.
1. COMMUNICATN MODE	Selects the communication mode. - FULL DUPLEX - HALF DUPLEX
2. ETHERNET TYPE	Selects the Ethernet type. - 100 BASE-TX - 10 BASE-T
2. MAC ADDRESS	Displays the twelve-digit MAC address of the machine.
4. VIEW IP ADDRESS	Checks the current network settings.
1. IP ADDRESS	Checks the IP address.
2. SUBNET MASK	Checks the subnet mask.
3. GATEWAY ADDRESS	Checks the gateway address.
5. STARTUP TIME SET.	Sets the time period required to delay the startup of network communications for the machine (0SEC–300SEC (60SEC)).

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

10

9

SYSTEM SETTINGS	
3. COMMUNICATIONS	Specifies the fax settings.
1. MEMORY LOCK	Sets whether to receive and store all documents in memory and not to print automatically. (See "Memory Lock Reception," on p. 4-26.)
OFF	Disables memory lock reception.
ON	Enables memory lock reception.
1. PASSWORD	Registers the password that protects the authority for accessing to memory.
2. MEMORY RX TIME	Sets whether to set a period for memory lock reception.
OFF	Disables setting a period of memory lock reception.
ON	Enables setting a period of memory lock reception. – 1. MEM RX START TIME – 2. MEM. RX END TIME
4. ACCESS TO DEST.	Sets restriction of the access to destinations.
1. RESTRICT REDIAL	Sets whether to disable the redial function of the [Redial/Pause] key. - OFF - ON
2. CONFIRM FAX NO.	Sets whether to confirm the entered fax numbers each time you send a fax. - OFF - ON
5. UPDATE FIRMWARE	This function is used only when the machine firmware needs to be updated.

Table of Contents





Previous

Next

TOP

Before Using the

Document and Paper

Copying

Sending and Receiving

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Summary of Reports and Lists

The machine can generate the following reports and lists.

Report/List	Description
1-TOUCH LIST	Lists the names and fax numbers of recipients registered under one-touch speed dialing keys.
CODED DIAL LIST	Lists the names and fax numbers of recipients registered in coded speed dialing codes.
GROUP DIAL LIST	Lists the names and fax numbers of recipients registered in each group dialing group.
USER DATA LIST	Lists all the current settings and registered sender information.
TX REPORT	Shows the transmission result. Can be set to print automatically.
RX REPORT	Shows the reception result. Can be set to print automatically.
ACTIVITY REPORT	Shows the last 60 transactions performed by the machine.
MEMORY DATA LIST	Lists reserved jobs stored in memory.
MEMORY IMAGE PRNT	Shows information and the first page of a reserved job.
LOST REPORT	Lists received documents that were lost from the memory due to power cut. Cannot be manually printed out.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Printing Reports Automatically

TX REPORT, RX REPORT, and ACTIVITY REPORT can be set to print automatically.

TX REPORT

The default setting is <PRINT ERROR ONLY>.

- **Press [Additional Functions].**
- 2. Press [◄–] or [+►] to select <REPORT SETTINGS>, then press [OK].
- 3. Press [◄–] or [+►] to select <SETTINGS>, then press [OK].
- Press [◄–] or [+▶] to select <TX REPORT>, then press [OK].
- 5. Press [◄–] or [+►] to select the setting you want, then press [OK].

<PRINT ERROR ONLY>: Prints a report only when a transmission error occurs.

<OUTPUT NO>: Does not print a report.

<OUTPUT YES>: Prints a report every time you send a document.

6. Press [Stop/Reset] to return to the standby mode.

Report Items

The following items are displayed in the Transmission Report:

- JOB NO.: Job number
- MODE: Mode of transaction (G3 or ECM)
- NO.: Sequence number
- DESTINATION TEL/ID: Name and number of recipient
- START TIME: Date and time of transaction
- PAGE: Number of pages sent
- RESULT: Result of transaction
- OK: Transmission successful
- NG: Transmission failed
- STOP: Transmission manually canceled before completion
- NO ANSWER: Call not answered
- PAPER JAM: ADF jam occurs during Manual TX
- Error code: For descriptions of error codes, See "Error Codes," on p. 10-20.

Table of Contents



Back





ТОР

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

RX REPORT

The default setting is <OUTPUT NO>.

- 1. Press [Additional Functions].
- 2. Press [◄—] or [+▶] to select <REPORT SETTINGS>, then press [OK].
- Press [◄–] or [+►] to select <SETTINGS>, then press [OK].
- **4.** Press [◄–] or [+►] to select <RX REPORT>, then press [OK].
- 5. Press [◄–] or [+►] to select the setting you want, then press [OK].

<OUTPUT NO>: Does not print a report. <OUTPUT YES>: Prints a report every time you receive a document. <PRINT ERROR ONLY>: Prints a report only when a reception error occurs.

6. Press [Stop/Reset] to return to the standby mode.

Report Items

The following items are displayed in the Reception Report:

- JOB NO.: Job number
- MODE: Mode of transaction (G3 or ECM)
- NO.: Sequence number
- DESTINATION TEL/ID: Number of the sending machine (displayed only if registered in their machine)
- START TIME: Date and time of transaction
- PAGE: Number of pages received
- RESULT: Result of transaction
- OK: Reception successful
- NG: Reception failed
- STOP: Reception manually canceled before completion
- MEM.FULL: Memory became full during reception.
- Error code: For descriptions of error codes, see "Error Codes," on p. 10-20.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

ACTIVITY REPORT

The default setting is <OUTPUT YES>.

- 1. Press [Additional Functions].
- 2. Press [◄–] or [+►] to select <REPORT SETTINGS>, then press [OK].
- Press [◄–] or [+►] to select <SETTINGS>, then press [OK].
- **4.** Press [◄—] or [+▶] to select <ACTIVITY REPORT>, then press [OK].
- 5. Press [◄–] or [+►] to select the setting you want, then press [OK].

<OUTPUT YES>: Prints a report after every 60 transactions. <OUTPUT NO>: Does not print a report.

6. Press [Stop/Reset] to return to the standby mode.

Report Items

The following items are displayed in the Activity Report:

- NO.: Transaction number (01 to 60)
- JOB NO.: Job number
- START TIME: Date and time of transaction
- MODE: Mode of transaction (G3 or ECM)
- DESTINATION TEL/ID: Name and number of recipient
- PAGE: Number of pages sent or received
- RESULT: Result of transaction, transaction duration
- OK: Transaction successful
- NG: Transaction failed
- Error code: For descriptions of error codes, see "Error Codes," on p. 10-19.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and

Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

. .

11

9

Printing Reports and Lists Manually

You can print the following reports and lists manually.

- TX REPORT
- RX REPORT
- ACTIVITY REPORT
- MEMORY DATA LIST
- MEMORY IMAGE PRNT
- 1-TOUCH LIST
- CODED DIAL LIST
- GROUP DIAL LIST
- USER DATA LIST
 If no relevant data is stored in memory, <NO DATA> is displayed.



- For information on each report or list, see "Summary of Reports and Lists," on p. 11-25.
- For information on the supported paper size for printing reports or lists, see "LCD Messages," on p. 10-14.

- 1. Press [Additional Functions].
- 2. Press [◄—] or [+▶] to select <REPORT SETTINGS>, then press [OK].
- 3. Press [◄–] or [+►] to select <LIST PRINT>, then press [OK].
- **4.** Press [◄–] or [+►] to select a desired report or list, then press [OK].

Printing starts, and the screen automatically returns to the standby mode.

Table of Contents









Before Using the

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Checking Remaining Memory

You can check the remaining memory according to the status of the machine.

- Press [System Monitor].
- 2. Press [◄–] or [+►] to select <AVAILABLE MEMORY>, then press [OK] to confirm the remaining memory.

AVAILABLE MEMORY 75%

Press [Stop/Reset] to return to the standby mode.

Table of Contents







TOP

Before Using the Machine '

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Glossary

Numeric

10Base-T

The Ethernet standard supporting data transfer rates a maximum of 10 Mbps, which utilizes a twisted-pair cable.

100B-TX

The Ethernet standard supporting data transfer rates a maximum of 100 Mbps, which utilizes two pairs of high grade twisted-pair cables.

Α

Activity Report

A journal of the machine's transactions, both sent and received.

Address Book

The Address Book is a feature used for storing recipients. The Address Book is divided into one-touch speed dialing keys and coded speed dialing codes. You can register multiple recipients in a group, and assign a one-touch speed dialing key to this group. Registering a recipient in the Address Book saves you the effort of entering that fax number each time you send a fax.

ASCII code

ASCII (American Standard Code for Information Interchange) is a set of standardized codes used to represent letters, numbers, punctuation marks, a few symbols, and control characters. A seven digit (or seven bit) binary number can represent one of 128 distinct codes.

Automatic Document Feeder (ADF)

The device included in the machine that feeds the document being sent or copied, or scanned into the machine.

Automatic redialing

When the recipient's machine is busy or does not answer, or when an error occurs while sending, the machine waits a specified time and then automatically redials the number. If the receiving fax is still busy or does not answer, the machine waits the specified time and dials again.

В

bps

Bits per second. Refers to the speed with which a fax machine sends and receives data.

Table of Contents







Next

TOP

Before Using the Machine

Document and Paper

Copying

Sending and

Printing and

Receiving

Remote UI

Network

System Manager

Settings

Maintenance

Troubleshooting

1

9

BOOTP

BOOTstrap Protocol. A protocol that enables a client machine to automatically obtain network setup information from a server over a TCP/IP network. BOOTP enables a client to automatically locate such information as the host name, domain name, and IP address, so that it is not necessary to create these items manually.

Broadcasting

Transmitting documents to more than one location (through the machine's memory).

C

CNG

Calling Tone. This is a signal sent by fax machines to identify the call as an incoming document. When the receiving fax detects this signal, it automatically starts to receive the fax transmission. The majority of fax machines in use today can send and detect CNG signals.

Coded Speed Dialing Codes

A method to specify a recipient registered in Address Book. Press [Coded Dial] and a two-digit code using the numeric keys.

Community Name

An identification keyword for SNMP (Simple Network Management Protocol).

Cookie

A file left on a user's computer when the user visits a web site. A cookie allows the web site to recognize the user on subsequent visits. Cookies are generally used to enable a user to automatically sign on to certain web sites and to customize the features offered by such sites.

Cursor

The underline symbol you see on the LCD when you register numbers and names in the machine.

D

DHCP

Dynamic Host Configuration Protocol. A protocol that automatically specifies the network settings of a client on a TCP/IP network. Many of the settings required to set up TCP/IP, which is the standard protocol of the Internet, can be made automatically.

DNS

Domain Name System. The system that associates the IP address assigned to a computer with the domain name.

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

11

DNS server

Domain Name System server. A server which maintains a database that translates the domain names of Internet servers, such as www. w3.org, into Internet Protocol (IP) addresses, such as "18.176.0.26". This enables clients to connect to a server with a host name rather than a numeric IP address.

Document

The sheet of paper containing the data that you send to, or receive from a machine.

Domain

A management concept that divides large scale networks into groups for identifying individual computers and users. The internet is managed by classifying domains according to geographical location or type (business, organization, educational institution, etc.).

dpi

Dots per inch. A machine of measurement for indicating a machine's resolution.

DRPD

This receive mode allows the machine to distinguish fax and voice calls depending on the distinctive ring patterns assigned to different numbers. Subscription to a DRPD service offered by some telephone companies is required.

E

ECM

Error Correction Mode. The ability of your machine to reduce system and line errors when sending or receiving from another fax with ECM capability. ECM is most effective in areas where the telephone lines are in poor condition or there is frequent interference on the line.

Ethernet

An industry-standard local area network (LAN) system for connecting together multiple computers. Data is sent from one computer to another by breaking it into packets, and a packet reaches its recipient smoothly without any collision with other packets.

Extension

A telephone connected to the machine that is used in place of the handset. You can use the extension telephone to activate incoming reception of documents manually.

F

FAX/TEL switching

This option allows you to set the machine to automatically detect whether a call is from a fax or telephone. If the call is from another fax, the transmission is automatically received. If the call is from a telephone, the machine rings to let you know, so you can pick up the handset of the external telephone. With this feature, one telephone line can be shared by both the telephone and the fax.

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

<u> 10</u>

Appendix

11

File formats

File formats are used to save image data (e.g. JPEG, PDF, TIFF).

FINE

The resolution setting for documents with very small characters and lines.

G

G3, Group 3 fax machine

Defined by CCITT/ITU-T. Uses encoding schemes to transmit image data while reducing the amount of data that needs to be transmitted, thus reducing transmission time. G3 fax machines can transmit one page in less than one minute. Encoding schemes for G3 fax machines are Modified Huffman (MH), Modified READ (MR), Modified Modified READ (MMR), and Joint Bi-level Image expert Group (JBIG)*.

* This machine does not support JBIG compression.

Gateway Address

The default address of a network or Web site. It provides a single domain name and point of entry to the site.

Group dialing

A method of specifying recipients that enables you to specify multiple recipients registered in Address Book as a group. This means that you can press just a single one-touch speed dialing key or coded speed dialing code to specify recipients when sending the same document to many recipients.

Н

HP-GL/2

A graphics language that allows computer applications to draw graphic images using printers. Images in HP-GL/2 are represented as vector graphics. Vector objects describe an image in terms of geometric shapes, such as lines and polygons, and fills. HP-GL/2 is supported by your Canon machine.

HTTP

Hypertext Transfer Protocol. The client-server TCP/IP protocol used on the World Wide Web for the transfer of HTML (Hypertext Markup Language) documents across the Internet.

П

Interface

The connection between two devices that makes it possible for them to communicate with each other. The machine features a USB interface, which makes it compatible with IBM and similar personal computers.

Interface cable

The cable used to create the interface between a printer and a computer.

Interface port

The machine comes with one USB port, located on the back of the machine. You attach the cable that connects your computer and machine to this port.

Table of Contents







Next



Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

11

9

Internet Protocol (IP)

The underlying set of networking rules that describes how data is transmitted across the Internet. Internet Protocol allows data from one computer to be split into packets to be sent to another computer with a specific IP address.

IP address

Internet Protocol address. A 32-bit numeric address used by IP (internet protocol) to specify a computer on the Internet. The IP address is usually written as four numbers separated by periods. An example is 128.121.4.5.

ITU-T

A committee created to set international standards for telecommunications.

L

LAN

Local Area Network. It is a network system formed by linking a server, workstations, and computers, which are all located in the same building or some other relatively limited area.

Log in

Entering a password as a means of user authentication to start a computer session or access to a service.

LPD

Line Printer Daemon. A daemon is a program that runs, without human intervention, to accomplish a given task. The Line Printer Daemon controls the flow of print jobs to a printer.

LPR

Line Printer Remote. A UNIX command used to print a file via a TCP/IP network.

M

MAC address

Media Access Control address. The hardware address of the network adapter of a computer connected to a local area network.

Manual receiving

A method of receiving faxes in which you answer all incoming calls using the external telephone. If you hear a slow beep it indicates an incoming fax transmission from another machine. Just press [Start] to receive the incoming fax.

Modem

A device that converts (MOdulates) digital data for transmission over telephone lines. At the receiving end, this device converts the modulated data (DEModulates) to digital format that the computer understands.

Table of Contents



Previous

Next



Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

Appendix

11

Ν

NetSpot

Network management software that enables the setup and management of multiple printers connected to a network from one central location. A network manager can monitor conditions of network printers, ascertain online/offline status, error status, the amount of paper in paper cassette, verify information on mounted fonts, and other readings. All the functions that are conventionally conducted through the operation panel of the respective machines can be performed from one location.

Numeric keys

The round, numbered keys on the operation panel marked the same as a standard telephone keypad.

Press them to perform regular dialing. You also use the numeric keys to enter characters and numbers during registration, and for entering coded speed dialing codes.

0

One-Touch Speed Dialing keys

The numbered keys on the operation panel that may be registered as single or a group of recipients. Once a number or group is registered, you press one key to dial the entire number or group.

P

Paper feed

Refers to guiding a sheet of paper into the machine's paper path.

Paper feeder

The device in the machine that feeds recording media into the machine for printing copied or sent documents.

Pause

A timing entry required for registering certain long distance numbers and for dialing out through some telephone systems or switchboards. Pressing [Pause] enters a pause between digits of a telephone number.

PDF

Portable Document Format. The page description language used in Adobe Systems' Acrobat document exchange system, which is restricted neither by device nor resolution. PDF displays documents in a way that is independent of the original application software, hardware, and operating system used to create those documents. A PDF document can contain any combination of text, graphics, and images.

PHOTO

The document setting you use for sending or copying documents with intermediate tones, such as photographs.

Protocol

A set of rules that govern the transmission of data across a network. Examples of protocols are FTP, DHCP, BOOTP, RARP, and TCP/IP.

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appendix

11

9

Proxy server

A server that provides a cache of files available on remote servers that are slow or expensive to access. The term "proxy server" normally refers to a World Wide Web server that, on receiving a URL, tries to supply the requested file from its cache. If it cannot locate the file there, the proxy server would bring it from the remote server and also save a copy in its cache so that the next request can be obtained locally.

Pulse

See Rotary pulse.

R

RARP

Reverse Address Resolution Protocol. A protocol that associates a network adapter address (MAC address) with an Internet Protocol (IP) address.

Raster

Raster graphics describes an image as a pattern of dots, compared to vector graphics which represents an image as a geometrical formula. Each row of color dots in the mosaic of color dots constitutes one raster graphic. In a printer, a raster graphic is used as the master image from which a page is printed, because the image can be transferred to paper by printing one raster at a time.

Raw

This is a print application used with Windows 2000/XP/Server 2003/ Vista. It can print at higher speeds than LPD.

Receiving

Receiving transmission is also defined as RX or Reception. The machine can be customized to receive fax documents in several ways.

Reception

See Receiving.

Redialing-automatic

See Automatic redialing.

Registering

A process by which you place recipient's information (such as the name, fax number, etc.) in the machine's memory, so that you save time specifying recipients you send documents frequently.

Regular dialing

Pressing the individual numeric keys to dial a fax or telephone number.

Remote reception ID

The two-digit code that enables you to manually activate fax reception using an external telephone.

Remote reception

Activating fax reception by answering an external telephone that is not located near the machine. You need to dial a remote receiving ID number to start remote reception.

Table of Contents







TOP

Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

Appondix

11

9

Remote UI

Remote User Interface (UI) allows you to remotely perform machine functions from a computer connected to the network using web browser software. Many functions that are done physically at the Canon machine's operation panel can be done via software at a networked computer using a web browser, such as Microsoft Internet Explorer.

Report

A document printed by the machine and containing information about the documents it has sent or received.

Resolution

The density of dots for any given output device. Expressed in terms of dots per inch (dpi). Low resolution causes font characters and graphics to have a jagged appearance. Higher resolution means smoother curves and angles as well as a better match to traditional typeface designs. Resolution values are represented by horizontal data and vertical data, for example, 600 x 600 dpi.

RIP (Raster Image Processor)

The hardware and/or software functions of a printer that convert vector graphic descriptions from a computer into raster graphic images that can be printed.

Rotary pulse

A telephone dialing system where a dial is rotated to send pulses to the telephone switching system. In pulse dialing, you hear clicks. In touch-tone dialing, the most common dialing system, you hear tones. Rotary pulse dialing requires certain setting adjustments.

RX

See Receiving.

S

Sending

Sending documents is also defined as TX or Transmit. The machine can scan and send documents via fax.

Sending speed

The rate at which faxes are transmitted through the phone line. See also bps (bits per seconds).

SMB

Server Message Block. A protocol that provides file and printer sharing over a network for Windows computers.

SNMP

Simple Network Management Protocol. The network management protocol of TCP/IP.

In SNMP, agents, which can be hardware as well as software, monitor the activity of the various devices on the network and report to the network console workstation.

Spool

Simultaneous Peripheral Operations On-Line. Spooling means putting jobs in a buffer, which is a special area in memory or on a disk. Because devices access data at different rates, the buffer provides a waiting station where the data can wait until the device for which it is meant is ready to access it.

Standby

The mode in which the machine is on and ready to use.

Table of Contents







ТОР

Before Using the Machine

Document and Paper

Copying

Printing and

Sending and

Receiving

5

Network

Remote UI

System Manager Settings

Maintenance

9

Troubleshooting

10

Appendix

11

Subnet

A portion of a network, which may be a physically independent network segment, that shares a network address with other portions of the network, and is distinguished by a subnet number.

For example, all devices with IP addresses that start with 100.100.100. would be part of the same subnet.

Subnet Mask

SUBNETwork mask. The method used to determine which subgroup, or subnet, an IP address belongs to on TCP/IP networks, all devices whose IP addresses have the same prefix would belong to the same subnet. Dividing a network into subnets is useful for both security and performance reasons.

Switching hub

A network connection box to which a number of computers can be connected. The switching hub forwards a data packet from the network to the appropriate computer according to the packet's address. Conventional hubs simply send every packet to every connected computer. Since a switching hub forwards packets only to their intended recipients, it provides greater efficiency.

Т

TCP/IP

Acronym for Transmission Control Protocol/Internet Protocol. The protocol used to connect to the Internet and to wide-area networks.

Tone

A key that allows you to temporarily switch to touch-tone from pulse dialing. In some countries, on-line data services may require that you use tone dialing.

Tone/pulse setting

The ability to set the machine to match the telephone dialing system your telephone line uses: touch-tone or rotary pulse.

Toner

A black, resin coated powder contained in the toner cartridge. The machine applies the toner to the surface of the photosensitive drum inside the machine via an electrophotographic mechanism.

Toner saver

The feature that extends cartridge life by reducing toner consumption rate at a slight decrease in print quality.

Transmit

See Sending.

TX

See Sending.

Table of Contents







Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and Scanning

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

11

9

U

URL

Uniform Resource Locator. A standard way of specifying the location of an object, usually a web page, on the Internet. The URL for a web page would look something like this:

"http://www.w3.org/default.html". Here, "http:" indicates that a web page is being accessed, "http://www.w3.org" is the address of the server containing the web page, and "default.html" is the file name under which the web page is stored on the server.

V

Vector Graphics

See Raster.

W

WAN

Wide Area Network. A geographically widespread network. A WAN can be one large network, or it can consist of a number of linked LANs (Local Area Networks).

Table of Contents













Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Table of Contents

Index

Index

Symbols & Numerics

1-TOUCH LIST 11-25 2-Sided key 1-6 2 on 1 combination 3-7, 5-4

Α

Accessing the setting menu 11-3 **ACTIVITY REPORT 11-25** Printing automatically 11-28 Add. Func. button 7-5 Additional Functions key 1-6 Additional network settings 6-15

Deleting an address 7-12 Editing and address 7-9 Fax numbers 4-7 Registering an address 7-10 Storing/Editing 4-6 Viewing an address 7-9 Address Book key 1-9 ADDRESS BOOK SET, 11-14

Address button 7-5

ADF 1-3, 2-5

Address Book

ADJUST./CLEANING 11-17

Advanced printing features 5-3 Advanced sending features 4-17

AnsMode 4-23

Automatic document feeder 1-3

В

Basic network settings 6-4 Basic receiving method 4-23 Basic sending method 4-4 Before using the machine 1-1 **BROADCAST 11-7 Broadcasting 4-17**

C

Canceling Copy job 3-11 Scan job 5-7 TX/RX job 4-32 **CHECK DOCUMENT message 10-3**

Checking

Documents stored in memory 4-33 Print job 5-8 Reception result 4-33 Transmission result 4-33 Checking dialing line 4-21 Checking network settings 6-18 Checking print and scan counts 5-8

Clean Earth Campaign 9-19 Cleaning machine

Exterior 9-2 Fuser roller 9-7 Interior 9-3 Scanning area 9-8 Clearing jams 10-3

Document jams 10-4 Paper jams 10-6

Clear key 1-8

Coded Dial key 1-9, 4-13

Using 4-13

CODED DIAL LIST 11-25

Coded speed dialing codes

Deleting 4-8 Registering 4-7 Storing/Editing 4-7

Collate/2 on 1 key 1-7

Collate copy 3-6

Collate printing 5-3

COMMON SETTINGS 11-7

Components 1-3

Copying 3-1

Copy job

Canceling 3-11

COPY key 1-6

Copy mode 1-10

COPY SETTINGS 11-8

Customer support

Canada 10-47 U.S.A. 10-47







Next

Before Using the Machine **Document and Paper Copying** Sending and Receiving **Printing and** Network **Remote UI System Manager Settings** Maintenance 9 **Troubleshooting**

Daylight saving time 1-16 Deleting Documents stored in memory 4-33 Print job 5-8 Density Copying 3-3 Sending 4-5 Density key 1-7 Device button 7-5 Document Jams 10-4 Loading 2-4 Printing 5-2 Receiving 4-1 Requirements 2-2 Scanning area 2-3 Sending 4-1 Document and paper 2-1 Document delivery tray 1-3 Document feeder tray 1-3 Document requirements 2-2 Documents stored in memory Checking 4-33 Deleting 4-33 **DRPD 4-25** Dust cover 1-4 E Energy Saver key 1-7 Enlarge/Reduce key 1-7 **Envelopes 2-10** Error codes 10-20

D

Error indicator 1-7 Ethernet port 1-5 External device jack 1-5 F FAX/TFI 4-24 Fax dialing features 4-19 FAX key 1-6 FAX MODF 1-10 Fax numbers Registering in Address Book 4-7 FaxOnly 4-23 Fax operation panel 1-9 G Glossary 11-31 Group dialing Adding recipients 4-10 Changing name 4-11 Deleting group 4-11 Deleting recipients 4-10 Registering group 4-9 Using 4-14 **GROUP DIAL LIST 11-25** н Help button 7-5 Hook key 1-9, 4-16 If a power failure occurs 10-46 If you cannot solve a problem 10-47

Image quality Copying 3-3 Faxes 4-5 Image Quality key 1-7 Import/Export function About the Import/Export function 7-16 Exporting the Address Book 7-16 Importing the Address Book 7-17 Jams Document 10-4 Paper 10-6 Job management About the job management 7-7 Activity log 7-8 Print jobs 7-7 Job Status button 7-5 L LCD Display 1-8 Messages 10-14 Standby mode 1-10 Legal 2-7 Letter 2-7 Loading Document 2-4 **Envelopes 2-10** Paper 2-10 LOST REPORT 11-25

Table of Contents











Next

Before Using the Machine **Document and Paper Copying** 3 Sending and Receiving **Printing and** Network **Remote UI System Manager Settings** Maintenance 9 **Troubleshooting**

Table of Contents

M Machine Checking status 7-6 Customizing settings 7-19 Machine components 1-3 Machine management 6-19 Machine settings 11-3 Main operation panel 1-6 Main power switch 1-4 Maintaining the toner cartridge 1-12 Maintenance 9-1 Manual reception 4-25 Manual sending 4-16 **MEMORY DATA LIST 11-25** MEMORY IMAGE PRINT 11-25 Memory lock reception 4-26 Memory reception 4-26 Menu Accessing 11-3 Setting 11-5 Multi-purpose tray 1-4, 2-10 Ν Network 6-1 Numeric keys 1-7

0 OK kev 1-8 One-Touch Speed Dialing key 1-9 Deleting 4-8 Editing 4-7 Registering 4-7 Storina/Editina 4-7 Using 4-12 Operation panel 1-3, 1-6 Main operation panel 1-6 Output tray 1-3 Output tray extension 1-4 Overseas number 4-22 Page top button 7-5 Paper Jams 10-6 Loading 2-10 Printable area 2-9 Requirements 2-7 Size and type 2-13 Paper cassette 1-3 Paper guide rail 1-4 PAPER JAM message 10-6 Paper requirements 2-7 PAPER SETTINGS 11-5 Paper stopper 1-4 PC faxing 4-18 Platen glass 1-4, 2-4 Power failure 10-46 Power socket 1-5 Printable area 2-9

PRINTER SETTINGS 11-15 Printing 5-1 **Printing lists** Manually 11-29 **USER DATA LIST 11-3** Printing reports **ACTIVITY REPORT 11-28** Manually 11-29 RX RFPORT 11-27 TX RFPORT 11-26 Print job Checking 5-8 Deleting 5-8 Processing/Data indicator 1-7 Pulse dialing 4-19 R Rear cover 1-5 Received image reduction 4-31 Receive mode AnsMode 4-23 **DRPD 4-25** FAX/TEL 4-24 FaxOnly 4-23 MANUAL 4-25 Receive mode for printing 4-29 Receiving documents Basic receiving method 4-23 Receiving features 4-24 Receiving features 4-24 Reception restriction 4-30 Recycling cartridge 9-19 **CANADA PROGRAM 9-22** U.S.A. PROGRAM 9-20











Document and Paper

Copying

Sending and Receiving

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Redial/Pause key 1-9

Redistributing toner 9-11

Remote reception 4-28

Remote reception ID 4-28

Remote UI 7-1, 11-38

Replacing the toner cartridge 9-11

Reports and lists 11-25

REPORT SETTINGS 11-18

Restricting access to destinations

Confirm entered fax numbers 8-3

Job Recall 8-4

RX REPORT 11-25

Printing automatically 11-27

S

SCAN key 1-6

Scan mode 1-10

Scanning 5-1

Scanning area 1-4, 2-3

Scanning documents

Computer 5-6

Scanning platform 1-4

Scan settings

Copying 3-3

Fax 4-5

Sending and receiving 4-1

Sending documents Address Book 4-6

Advanced sending features 4-17

Basic sending method 4-4

Fax dialing features 4-19

Manual sending 4-16

PC faxing 4-18

Scan settings 4-5

Specifying recipients 4-12

Setting menu

ADDRESS BOOK SET. 11-14

ADJUST./CLEANING 11-17

BROADCAST 11-7

COMMON SETTINGS 11-7

COPY SETTINGS 11-8

FAX SETTINGS 11-9

PAPER SETTINGS 11-5

PRINTER SETTINGS 11-15

REPORT SETTINGS 11-18

SYSTEM SETTINGS 11-20 **TIMER SETTINGS 11-16**

VOLUME CONTROL 11-6

Setting paper size and type 2-13

Setting up a computer for printing/sending a fax

6-10

Sleep mode 1-15

Slide guides 1-3, 2-5

Slide guides for multi-purpose tray 1-4

Specifying recipients 4-12

Standby mode

Copy 1-10

Fax 1-10

Scan 1-10

Starting Remote UI 7-4

Start key 1-7

Stop/Reset key 1-7

Storing/Editing

Address Book 4-6

Coded speed dialing codes 4-7

Previous

Group dialing 4-9

One-touch speed dialing keys 4-7

System Manager settings 8-1

System monitor 4-33, 5-8

System Monitor key 1-6

System requirements

Network 6-3

Remote UI 7-3

SYSTEM SETTINGS 11-20

System settings

Customizing 7-13

Т

Telephone line jack 1-5

TIMER SETTINGS 1-15, 11-16

Tone dialing 4-19

Tone key 1-8, 4-19

Toner cartridge 1-11

Checking the toner level 1-13

Maintaining 1-12 Recycling 9-19

Redistributing 9-11


Replacing 9-14 Toner Gauge key 1-8

Toner level 1-13

To Top page button 7-5

Transporting the machine 9-25

Table of Contents



V

View Settings key 1-6 VOLUME CONTROL 11-6

Ζ

Zoom ratio
Preset zoom 3-4
Zoom designation 3-5

Table of Contents

Index

TOP

Back

Previous

Next









Before Using the Machine

Document and Paper

Copying

Sending and Receiving

Printing and

Network

Remote UI

System Manager Settings

Maintenance

Troubleshooting

9

Table of Contents

Canon

CANON INC.

30-2, Shimomaruko 3-chome, Ohta-ku, Tokyo 146-8501, Japan

CANON U.S.A., INC.

One Canon Plaza, Lake Success, NY 11042, U.S.A.

CANON CANADA INC.

6390 Dixie Road Mississauga, Ontario L5T 1P7, Canada

CANON EUROPA N.V.

Bovenkerkerweg 59-61 1185 XB Amstelveen, The Netherlands

CANON FRANCE S.A.S.

17, quai du Président Paul Doumer 92414 Courbevoie Cedex, France

CANON COMMUNICATION & IMAGE FRANCE S.A.S.

12, rue de l'Industrie 92414 Courbevoie Cedex, France

CANON (U.K.) LTD.

Woodhatch, Reigate, Surrey, RH2 8BF, United Kingdom

CANON DEUTSCHLAND GmbH

Europark Fichtenhain A10, 47807 Krefeld, Germany

CANON ITALIA S.p.A.

Via Milano, 8 20097 San Donato Milanese (MI) Italy

CANON ESPAÑA, S.A.

c/ Joaquín Costa 41, 28002 Madrid, Spain

CANON LATIN AMERICA, INC.

703 Waterford Way Suite 400, Miami, Florida 33126 U.S.A.

CANON AUSTRALIA PTY. LTD.

1 Thomas Holt Drive, North Ryde, Sydney, N.S.W. 2113, Australia

CANON CHINA CO., LTD.

15F Jinbao Building No.89 Jinbao Street, Dongcheng District, Beijing 100005, China

CANON SINGAPORE PTE. LTD.

1 HarbourFront Avenue #04-01 Keppel Bay Tower, Singapore 098632

CANON HONGKONG CO., LTD.

19/F., The Metropolis Tower, 10 Metropolis Drive, Hunghom, Kowloon, Hong Kong

USRM1-2039-00

© CANON INC. 2007

120V