

Installing the Macintosh PPD File (for Mac OS 9)

1.

Insert the CD-ROM into your Macintosh' s CD-ROM drive.

2.

Double-click on the CD-ROM icon, then open the PS_PPD, us_eng, MacOS9 and <your printer name> folders.

3.

Copy the PPD file "CNRxxxU1.PPD" to the Printer Descriptions folder in the Extensions folder of the System Folder.

NOTE

- If you are using QuarkXPress for Macintosh, also copy the PPD file "CNRxxxU1QX.PPD" to the Printer Descriptions folder.
- When using QuarkXPress, please make sure that both the PPD selected in the Chooser and that for "Printer Description: " when printing from QuarkXPress are CNRxxxU1QX.PPD.

4.

Select the Chooser from the Apple menu, then select a PS printer driver and select your printer name from the list of available printers.

5.

Click the Setup button to set-up the settings so you can print from your Macintosh.

- Depending on the printer you are using, "No Installable Options" may be displayed when you click [Configure]. If this occurs, all of the functions of the printer (including those that can only be used when the options have been installed and printer settings have been changed) are selectable when printing. Be sure to select only those functions that are supported by an available for the printer you are using.

Also, be sure to not select a combination of printer features that conflict, as this will lead to printing problems.

- If a VM error occurs during printing when QuarkXPress is used, select "Generic" as PPD. The VM error may be avoided.

NOTE

- "xxx" in the file names above identifies your printer model. Replace it with the characters appropriate to the printer you are using, for example:
 - iR C6870: C687
 - iR 6870C: 687C
 - iR 105: A5
- Perfect Binding

You cannot set the Finishing Size to the same size as the Content Page Size. If an incorrect size is set, the print job will be cancelled. Set a correct size, referring to the documentation provided with the printer.

In addition, the paper type for content pages is plain paper, regardless of the paper type selected under Paper Type.
- Use Secure Watermark Function of Device/Use Secure Printing Function of Device

The following settings are required beforehand in order to utilize the [Use Secure Watermark Function of Device]/[Use Secure Printing Function of Device] function. If you cannot select the [Use Secure Watermarks Function of Device]/[Use Secure Printing Function of Device] feature when printing after performing step 1 below, perform step 2.

 1. Install the option(s) that supports the secure watermark function/secure printing function in the printer, and enable the secure watermark function/secure printing function from the printer driver.
 2. In above step 5, select the option(s) that support the secure watermark function/secure printing function.
- Grayscale Conversion/Device Link Profile

If you are using an application that is capable of setting colors in a document, in order to use the [Grayscale Conversion]/[Device Link Profile] feature you must set the color mode of the document to RGB or CMYK and set the color profile of the document to a RGB-based or CMYK-based profile in the application.

Trademarks

Apple, Mac, Mac OS, and Macintosh are trademarks of Apple Inc., registered in the U.S. and other countries.

Other product and company names herein may be the trademarks of their respective owners.

Copyright 2012 CANON INC.