



AirPrint and Printer Firmware Setup Guide

Check If the Airprint Firmware Update is necessary

PIXMA MX892

AirPrint and Printer Firmware Setup Guide

•Checking the Firmware version

What to do before performing the Firmware Update Procedure

Check to see if you need to perform the Firmware Update. This can be determined by printing the nozzle check pattern.

Printing the Nozzle Check Pattern to Check Firmware Version

Note

•If the remaining ink level is low, the nozzle check pattern will not be printed correctly. Replace the ink cartridge whose ink is low.

You need to prepare: a sheet of A4 or Letter-sized plain paper

1. Make sure that the power is turned on.
2. Make sure that one or more sheets of A4 or Letter-sized plain paper are loaded in the cassette.
3. Open the output tray extension, open the paper output tray, then extend the paper output support.


AirPrint and Printer Firmware Setup Guide

•Checking the Firmware version

4. Print the nozzle check pattern.

(1) Press the Menu button. Select  **Setup**, then press the **OK** button.

The setup menu screen will appear.

(2) Select  **Maintenance**, then press the **OK** button.

The **Maintenance** screen will appear.

(3) Select **Print nozzle check pattern**, then press the **OK** button.



The confirmation screen will appear.


(4) Select **Yes**, then press the **OK** button.

The nozzle check pattern will be printed and two pattern confirmation screens will appear on the LCD.

AirPrint and Printer Firmware Setup Guide

•Checking the Firmware version

5. Examine the nozzle check pattern (printout) for firmware version.



If the printed firmware version is **“3.010” or higher**, it is not necessary to install the firmware update. Press the **Menu** button to return . For basic instruction on using AirPrint with your Canon printer, [click here](#).

If firmware version is **not** printed **or is lower than “3.010”** the firmware update will be necessary to use AirPrint with your printer. Be sure of the following before proceeding:

- The printer is connected via USB cable to a computer (**not** a tablet, iPad, etc) with the drivers already installed.
- The operating system is **Mac OS X version 10.4.11 or later** on Macintosh computers
- The operating system is **Windows XP, Windows Vista or Windows 7** on Windows computers.

6. After verifying the above information proceed to the next step, "[Downloading the Printer Update Utility](#)"