



## How to Use Google Cloud Print

Check If the Firmware Update is necessary


# How to Use Google Cloud Print


## •Checking the Firmware version

### Print the Nozzle Check Pattern to Check Firmware Version

You need to prepare: a sheet of A4 or Letter-sized plain paper

1. Make sure that the power is turned on.
2. Make sure that one or more sheets of A4 or Letter-sized plain paper are loaded in the cassette.
3. Open the paper output tray gently, and open the output tray extension.
4. Print the nozzle check pattern.

(1) Press the Menu button and select Setup (MX892 only) or select  Setup on the HOME screen. The setup menu screen will appear.

(2) Select  Maintenance, then press the OK button. The Maintenance screen will appear.

(3) Select Print nozzle check pattern, then press the OK button.




The confirmation screen will appear.

(4) Select Yes, then press the OK button.

# How to Use Google Cloud Print

## •Checking the Firmware version

5. Examine the nozzle check pattern (printout) for firmware version.



\*Examples from PIXMA MG6220 nozzle test. Number of color bars varies by model. The version number will print in same location as in the example.

If the version is “Ver. 3.000” or later you do not need to update the firmware.

If the version is earlier than “Ver. 3.000” or no version is printed, you need to update the firmware.