


Setting Up Your MX860 In Default Mode (Tel Priority Mode) Without An Answering Machine


Connecting The Phone Lines

Fax to Phone Line Connection

Before




After




Fax to Phone Line Connection

- Plug the provided phone cord into the wall jack




Fax to Phone Line Connection

- Plug the provided phone cord into the “L” jack located on the rear of the multifunction




Fax to Phone Line Connection

- Remove the white plug (D) from the upper jack.




Fax to Phone Line Connection

- Plug the second phone cord into the “telephone” jack located on the rear of the multifunction



Fax to Phone Line Connection


- Plug the second phone cord into the phone



Setting Up The Receive Mode

Step 1

Turn on the MX860 by pressing the **ON** button.




Step 2

Press the **FAX** button.




Step 3

The fax standby screen will appear.




Step 4

Press the **MENU** button.




Step 5

The FAX menu screen will appear.



Step 6

Press the center **Left or Right** button to select “Receive mode settings”.



Step 7

Ensure “Receive mode settings” is selected.




Step 8

Press the center **OK** button.




Step 9

The Receive mode settings screen will appear.




Step 10

Use the **UP** or **DOWN** button to select "TEL priority mode".




Step 11

Ensure that “TEL priority mode” is highlighted.




Step 12

Press the **OK** button.




Step 13

A confirmation screen will appear briefly.



Step 14

The "Receive mode settings" screen will reappear.




Step 15

Press the **FAX** button.



Step 16

Your MX860 is now set to Tel priority mode. Notice that the mode is listed on the fax standby screen.



Receiving A Fax

To receive a fax when you are home you will:

- Pick up the handset on the phone connected to the MX860.
- Listen for fax tones.
- When the tones stop hang up the handset.
- The MX860 will receive the fax document.

To receive a fax while you are away:

- The answering machine will answer the call.
- If fax tones are heard by the MX860 it will take over the call and receive the fax document.

IMPORTANT: In order to receive a fax, you must either pick up the handset on a phone that is connected to the MX860 or let your answering machine answer the call.

