

Installing the Printer to Your Wireless Network

imagePROGRAF PRO - 1000

Windows

Setup and Installation


Setup and Installation

The instructions contained in this document apply equally to first-time installations, adding the printer to additional computers in the Wireless Network and for re-installations after a Router or Network change.


To use the machine wirelessly with a computer, the printer must be connected to the Wireless LAN and software including the drivers needs to be copied (installed) to the computer's hard disk. Installation time varies depending on the computer environment or the number of application software to be installed.

IMPORTANT


- Log on as the administrator (or a member of the Administrators group).
- Quit all running applications before software installation.
- Do not switch users during the installation process.
- Internet connection may be required during the installation. Connection fees may apply. Consult the internet service provider.
- It may be necessary to restart your computer during the installation process. Follow the on-screen instructions.
- . The installation resumes once your computer has restarted.
- If the firewall function of your security software is turned on, a warning message may appear that Canon software is attempting to access the network. If such a warning message appears, set the security software to always allow access.



1. From the **Home** screen, press the up or down arrows until **LAN settings** appears. Then press the **OK** button.



2. Use the down arrow to select **Wireless LAN setup** and press the **OK** button.



3. Use the arrows to select **Cableless setup** and press the **OK** button.



4. Press the **OK** button when this message appears.

Follow the instructions on the computer or smartphone, etc. to perform the operation.

5. When this screen appears, the printer is waiting to receive the information on the wireless network. Go to the computer.

Insert the Setup CD-ROM into your computer.*

Click [Run Msetup4.exe] on the AutoPlay screen, then click [Yes] or [Continue] on the User Account Control dialog box.

If the CD-ROM does not autorun: Double-click [(My) Computer] > CDROM icon > [MSETUP4.EXE.]




*If you don't have or cannot use the Setup CD-ROM, follow the steps below to start the setup.


- Download the software (click the link to download)
- Double-click the downloaded .exe file (win-pro_1000-1_0-jucd.exe)

If the **User Account Control** dialog box appears during the setup, click **Yes** or **Continue**.


Click **Start Setup** on the initial screen.




Continue following on-screen instructions to select country, License Agreement, etc. until the **Select Connection Method** screen appears. Be sure to select **Wireless LAN Connection**, then click **Next**..




Select Connect via wireless router (recommended) then click Next.




Click **Next** on the **Check Power** screen.



On the **Select Printer** screen verify your printer is selected by checking the listing in the **Serial Number(Last 5 Digits)** column. This will show the last 5 digits of the printer's serial number. The serial number is found on a sticker on the back of the printer near the bottom right. Click **Next**.




Click **Next** on the **Connection Completed** screen.




Installing the Drivers & Software

Continue to follow on-screen instructions. Click **Next** on the **Setup Complete** screen.



Installing the Drivers & Software

Continue to follow the on-screen instructions. On the **Software Installation List**, select any of the optional software to install and click **Next**.



Installing the Drivers & Software

At this point the connection has been established and Drivers and Software has been installed. Please follow any remaining instructions to finish and exit the setup. Click **Exit** when the **Installation completed successfully** screen appears.

