


Installing Your Multifunction to Additional Computers on Your Network PIXMA MG2920

Windows OS

Preparing to Connect to the Network

Network Requirements


Before connecting the machine to the network, make sure that configuration of the computer and access point or router is complete, and that the computer is connected to the network.



Wireless Connection

Before connecting the machine to the network, the computer needs to be connected to the network. Make sure that configuration of the computer and access point or router is complete.

Preparing to Connect to the Network



Notes on Network Connection

• The configuration, router functions, setup procedures and security settings of the network device vary depending on your system environment. For details, refer to your device's instruction manual or contact its manufacturer.

- In an office setup, consult your network administrator
- If you connect to a network that is not protected with security measures, there is a risk of disclosing data such as your personal information to a third party.
- Place the machine and computer on the same network segment.

Software Installation

To use the machine by connecting it to a computer, software including the drivers needs to be copied (installed) to the computer's hard disk. Installation time varies depending on the computer environment or the number of application software to be installed.

IMPORTANT

- Log on as the administrator (or a member of the Administrators group).
- Quit all running applications before installation.
- Do not switch users during the installation process.
- Internet connection may be required during the installation. Connection fees may apply. Consult the internet service provider.

• If the firewall function of your security software is turned on, a warning message may appear that Canon software is attempting to access the network. If such a warning message appears, set the security software to always allow access.


If your MG2920 has already been set up for on your wireless network, it is only necessary to install the software on the additional computer(s). The printer does not have to be reset and no additional settings need to be made.

To begin the setup procedure, insert the Setup CD-ROM into your computer.* Setup will start automatically.

*If you don't have or cannot use the Setup CD-ROM, follow the steps below to start the setup.

- Download the software (click the link to download)
- Double-click the downloaded .exe file (Win-MG2900-1_0-ucd.exe)

Click Next on the initial screen



Continue following on-screen instructions. On the **Printers on Network List**, select your printer (its serial number will be listed in the **Serial Number** column) and click **Next**.

100040045	MAC Address	IP Address
ABCD12345	00:11:22:33:44:55	100.200.4.3
number can be found on the bac	e tound on the list of one from the above printers list, and then click [Nex k of the printer or the Letter of Guarantee. ad on the above list, turn on the printer and click [Upd select [Setting printer could not be found on the list], a	date].


Continue following on-screen instructions. On the **Software Installation List**, select *software to install and click **Next**.

***MP Drivers** is required and cannot be deselected. We recommend installing **My Image Garden** and **Quick Menu** to take full advantage of the printer's features.

The selected software will be installed. Make s Aick [Next].	ure that the software you want to	install is selected, and the
 MP Drivers User's Manual My Printer My Image Garden Quick Menu Easy-WebPrint EX XPS Driver 	245 MB 10 MB 14 MB 705 MB 40 MB 110 MB 130 MB	Drive C: 63200 MB free space Total used space: 1124 MB
		Select All

Continue following on-screen instructions.

When the Setup Completion dialog box appears, click Complete.



At this point, setup of the printer and network is complete. Continue to follow any remaining on-screen instructions to finish and exit the setup program.