



Installing Your Multifunction to Additional Computers on Your Network

PIXMA MX512

Windows OS

Installing Your Multifunction to Additional Computers on Your Network


PIXMA MX512
Windows OS

Preparing to Connect Your Multifunction to the Network	3
Network Requirements	3
Notes on Wireless Connection	4
Installing the Drivers	5

Preparing to Connect the Multifunction To the Network

Network Requirements

Before connecting the machine to the network, make sure that configuration of the computer and access point or router is complete, and that the computer is connected to the network.




Wireless Connection

Before connecting the machine to the network, the computer needs to be connected to the network. Make sure that configuration of the computer and access point or router is complete.

Preparing to Connect Your Multifunction To the Network

[<< Previous](#)

[Next >>](#)



An "Ad-hoc connection," which establishes a direct connection to the computer over a wireless connection without using an access point, is not supported.

A wireless access point or router is required to use your printer on a wireless LAN.

Notes on Network Connection

- The configuration, router functions, setup procedures and security settings of the network device vary depending on your system environment. For details, refer to your device's instruction manual or contact its manufacturer.
- In an office setup, consult your network administrator
- If you connect to a network that is not protected with security measures, there is a risk of disclosing data such as your personal information to a third party.
- Place the machine and computer on the same network segment.

Installing the Drivers & Software

Software Installation

To use the machine by connecting it to a computer, software including the drivers needs to be copied (installed) to the computer's hard disk. (The installation time varies depending on the computer environment or the number of application software to be installed.)

IMPORTANT

- Log on as the administrator (or a member of the Administrators group).
- Quit all running applications before installation.
- Do not switch users during the installation process.
- Internet connection may be required during the installation. Connection fees may apply. Consult the internet service provider.
- It may be necessary to restart your computer during the installation process. Follow the on-screen instructions and do not remove the Setup CD-ROM during restarting. The installation resumes once your computer has restarted.
- If the firewall function of your security software is turned on, a warning message may appear that Canon software is attempting to access the network. If such a warning message appears, set the security software to always allow access.

Installing the Drivers & Software

Installing the PIXMA MX512 to additional Windows computers on your Wireless Network

If your MX512 has already been set up on your wireless network, it is only necessary to install the software on the additional computer(s). No additional settings need to be made on the printer. Network connection will be confirmed automatically.

Simply insert the Setup CD-ROM that came with your printer into your CD-ROM drive and proceed through the easy to follow instructions.

1. Insert the CD-ROM into the computer*.



*If you don't have or cannot use your Setup CD-ROM, you can still install the printer on your computer using drivers available on our web site. [Click here for information](#)

When the **Software Installation List** screen appears, select any software to be installed. **MP Drivers** is required for the printer to be able to print and scan and cannot be de-selected. **MP Navigator EX** and **Easy-PhotoPrint EX** are highly recommended to take full advantage of your printer's features. Click **Next** after selecting the software.

Software Installation List

The selected software will be installed. Make sure that the software you want to install is selected, and then click [Next].

<input checked="" type="checkbox"/> MP Drivers	250 MB	Drive C: 5476 MB free space
<input checked="" type="checkbox"/> On-screen Manual	40 MB	
<input checked="" type="checkbox"/> My Printer	10 MB	Total used space: 706 MB
<input checked="" type="checkbox"/> MP Navigator EX	80 MB	
<input checked="" type="checkbox"/> Speed Dial Utility	10 MB	
<input checked="" type="checkbox"/> Easy-PhotoPrint EX	270 MB	
<input checked="" type="checkbox"/> Solution Menu EX	20 MB	
<input checked="" type="checkbox"/> Adobe RGB (1998)	1 MB	
<input checked="" type="checkbox"/> Easy-WebPrint EX	25 MB	

Estimated installation time: 10 to 20 minutes

***Note :** If you are using the downloaded **Mini Master Setup** file to install the MX512, only the **MP Drivers** will be installed.

You can download the additional software applications in the **Software** section of the [Drivers & Software](#) page on the web site. This is the same page where you downloaded the **Mini Master Setup** file.

Continue to follow any remaining instructions to finish and exit the setup program.

Installing the PIXMA MX512 on Your Wireless Network

If you can't find your CD-ROM, you may download the **MX510 series Mini Master Setup**, which includes the same step-by-step installation as the CD-ROM, by following the instructions below:

1. [Click here to access the MX512 Drivers & Software page.](#)
2. Select the operating system and version of your computer (see example below).
3. Expand the 'Drivers' section, if necessary, by clicking the red triangle.
4. Click on '**MX510 series Mini Master Setup**' .
5. After reading the details and disclaimer, click 'I Agree – Begin Download' and save the file to your computer.
6. Once the download is complete, double-click the file from its download location to begin the installation.

The screenshot shows a webpage titled "Drivers & Software". It contains instructions to select an operating system and version from a drop-down menu. Two drop-down menus are highlighted with red boxes: the first is set to "Windows" and the second is set to "Windows 7 (x64)". Below these are radio buttons for "Select Language" with "English" selected. A "Show All" link is present. A table with a "Drivers" section is shown, sorted by "Most Recent". The first row in the table is highlighted with a red box and contains the text "MX510 series Mini Master Setup (Windows 8/8 x64...".

File Description	Da
MX510 series Mini Master Setup (Windows 8/8 x64...	10
MX510 series MP Driver Ver. 1.01 (Windows 8/8 x...	10
MX510 series XPS Printer Driver Ver. 5.55a (Win...	10

[Return to Setup instructions](#)