





Connecting to a Smartphone

Connecting to a Smartphone

Once you have connected to a smartphone initially via Wi-Fi by pressing the  button, you can simply press the  button after that to connect again and view and save camera images on connected devices.

Installing CameraWindow on a Smartphone

Before connecting your camera to a smartphone, first install the free dedicated application, CameraWindow, on your smartphone.



1 Connect the smartphone to a network.



2 Install CameraWindow.

- For an iPhone, iPad, or iPod touch, download and install CameraWindow from the Mac App Store.
- For an Android device, download and install CameraWindow from Google Play.



3 Register the smartphone name.

- On the smartphone, start CameraWindow and enter a name for the smartphone that will be displayed on the camera.



- For details on this application (supported smartphones and included functions), refer to the Canon website.


Establishing the Smartphone Connection

When establishing a Wi-Fi connection with a smartphone, you can either use the camera as an access point or use another access point. Follow these instructions when using the camera as an access point. When using another access point, see “Connecting to Access Points in the List” (📖 96).

Note that only one smartphone can be assigned to the <📱> button.



1 Press the <📱> button.





2 Register a nickname.

- Touch inside the frame shown at left to display the keyboard. Enter a nickname (📖 88). (This nickname is displayed on the screen of target devices.)
- Up to 16 characters can be used.



3 Confirm the details, and touch [OK].



- ▶ The camera's SSID and encryption key are displayed on the screen.

4 Use the smartphone to connect to the network displayed on the camera screen.

- Choose the displayed SSID (network name) from the smartphone's Wi-Fi setting menu.
- Enter the encryption key displayed on the camera screen into the password field on the smartphone.

5 Start CameraWindow on the smartphone.

- ▶ Once the smartphone is recognized on the camera, the device connection screen will be displayed on the camera.

6 Choose a smartphone to connect to.

- Touch the name of the smartphone you want to connect to.



- ▶ After a connection is established with the smartphone, the smartphone name is displayed on the camera. (This screen will close in about one minute.)




7 Import images.

- Use the smartphone to import images from the camera to the smartphone.
- Use the smartphone to end the connection; the camera will automatically turn off.




- When you are in the vicinity of an access point that you have previously connected to, the camera will automatically connect to it in step 3. To change access points, select [Switch Network] from the screen that will be displayed when the connection is being established, and follow steps 4 – 6 in “Adding a Computer” (📖 95).





- To control the camera manually, either end the connection from the smartphone or restart the camera after pressing the power button to turn it off momentarily.
- Once a connection has been established with a smartphone, you can automatically reconnect to the registered device by simply pressing the  button, even if the camera has been turned off.
- The image quality level for movies that can be sent may differ depending on the smartphone. Refer to the instruction manual provided with your smartphone for details.
- To remove a registered smartphone, touch [FUNC.] and then [MENU], and on the [🔼] tab, choose [Mobile Device Connect Button]. After the confirmation message, touch [OK].
- If the date and time have not been set, the [Date/Time] screen will be displayed in step 2. Set them following the steps in “Setting the Date and Time” (📖 13).


■ Adding Other Smartphones


Only one smartphone can be assigned to the  button.

- To assign a different one, clear the current assignment. Touch [FUNC.] and then [MENU], and on the [↑] tab, choose [Mobile Device Connect Button]. After the confirmation message, touch [OK], and then assign the new smartphone to the button.
- When registering multiple smartphones, add them to your list of devices to connect to in the Wi-Fi menu (📖 87).

■ Adding a Smartphone Using the Wi-Fi Menu

You can also add a smartphone by touching [] in Playback mode and then touching , which is displayed in the Wi-Fi menu.

The procedure for adding a smartphone through the Wi-Fi menu varies from the  button approach as follows:

- The connection is established through the Wi-Fi menu (📖 88). You cannot connect to a smartphone by pressing the  button.
- The camera will remain on, even after you have disconnected from the smartphone.
- You can operate the camera to send images to the smartphone.
- Multiple smartphones can be added.
- After selecting a smartphone in step 6 of “Establishing the Smartphone Connection” (📖 86), the privacy settings screen (where you decide whether to allow images on the camera to be displayed on the smartphone) is displayed. If you select [No], images on the camera will not be displayed on the smartphone.



- To change privacy settings for registered smartphones, choose the smartphone in [Edit a Device] (📖 102), and then choose [View Settings].
- When a connection destination is set using the Touch Actions setting (📖 76), you can automatically access the function to connect to the last connected destination from the next time by just dragging on the screen without needing to perform the connection operation.