



Page yield may vary depending on texts/photos printed, applications software used, print mode, a combination of the ink tank /ink cartridge size and type of paper used.

When you use the Canon printer for the first time right after you install the provided ink tanks, the Canon printer consumes ink in the amount to enable printing by filling the nozzles of the Print Head with ink. For this reason, the number of sheets that can be printed with the first ink tanks is fewer than the succeeding ink tanks.

The page yield is based on the consumption data from the succeeding ink tank /ink cartridge but not the first ink tank /ink cartridge.

<i>Product</i>	<i>Ink Sku</i>	<i>Page Yield per Document Type</i>	<i>Type of Document</i>	<i>Paper Size</i>	<i>Type of Paper</i>	<i>Driver Application</i>	<i>Print Mode</i>	<i>Test Method</i>	<i>Pattern</i>	<i>Image Sample</i>
PIXMA TR4520	PG-243 CL-244 PG-245 CL-246 PG-245XL CL-246XL	100 100 180 180 300 300	Mixed text and graphics document	A4/Letter	Plain Paper	Canon printer driver for Windows 7 Adobe Reader 11	Default	ISO/IEC 24711	ISO/IEC 24712	
	PG-243 CL-244 PG-245 CL-246 PG-245XL CL-246XL	995 (Estimated) 32 1,915 (Estimated) 55 3,575 (Estimated) 90	Color Photo Sets	4" x 6"	Photo Paper Plus Glossy II	Canon printer driver for Windows 7 Adobe Reader 10	Default	ISO/IEC 29102	ISO/IEC 29103	
	PG-243 CL-244 PG-245 CL-246 PG-245XL CL-246XL	100 4,670 (Estimated) 180 8,640 (Estimated) 300 14,475 (Estimated)	Monochrome Document	A4/Letter	Plain Paper	Canon printer driver for Windows 7 Adobe Reader 10	Default	ISO/IEC 24711	ISO/IEC 19752	