


Safety guide



PRISMAsync iPR C1000VP-A1

Canon

Copyright

© 2015, Océ

All rights reserved. No part of this work may be reproduced, copied, adapted, or transmitted in any form or by any means without written permission from Océ.

Océ makes no representation or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose.

Further, Océ reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation to notify any person of such revision or changes.

Contents

Chapter 1	
Safety information	5
Safety information (all countries).....	6
Chapter 2	
Regulation notices	11
Regulation notices.....	12
Chapter 3	
General information	17
General information.....	18
Chapter 4	
Miscellaneous	19
Online support for your product.....	20

Chapter 1

Safety information

Safety information (all countries)

Introduction

All the products have been tested in accordance with the strictest international safety standards. Please read the following sections before you connect the machine to the power supply. These sections contain important information with regard to the user safety and the prevention of equipment problems. Make sure that you observe the safety rules hereinafter. This helps to assure that you can work with the product/system safely. Make sure that you observe all the precautions mentioned below.



NOTE

Safety Regulations require the product's name to be registered. In some regions where this product is sold the following commercial name(s) may be registered as a model number in () instead.

- Canon PRISMAsync iPR C10000VP-A1
- Canon PRISMAsync iPR C10000VP-A1 for Canon imagePRESS C10000VP
- Canon PRISMAsync iPR C10000VP-A1 for Canon imagePRESS C8000VP

Depending on the context, the terms; system, machine, and equipment used in the user documentation means the product for which this user documentation is applicable. Some parts of the contents of this section may not be applicable to your product. Please refer to the corresponding Safety Data Sheets for specific safety information. You can download the Safety Data Sheets from the support site of your product at "<http://downloads.oce.com/>".

Warning and caution indicators (manual)

The following indicators are used in the manuals to categorize the level of the seriousness of hazard:



WARNING

Indicates a warning concerning operations that may lead to death or injury to persons if not performed correctly. To use the machine safely, always pay attention to these warnings.



CAUTION

Indicates a caution concerning operations that may lead to injury to persons if not performed correctly. To use the machine safely, always pay attention to these cautions.



IMPORTANT

Indicates operational requirements and restrictions. Be sure to read these items carefully to operate the machine correctly, and avoid damage to the machine or property.



NOTE

Indicates a clarification of an operation, or contains additional explanations for a procedure. Reading these notes is highly recommended.



NOTICE: Indicates an operation that must not be performed. Read these items carefully, and make sure not to perform the described operations

Warning and caution indicators (machine)

The following indicators are used in the machine to warn the user for possible safety risks:



WARNING

Whenever this label is applied on parts of the machine that are accessible to the user, a remark can be found in the user documentation, explaining the potential hazard for which the user is warned or cautioned. The user is urged to consult the user documentation in order to understand the safety-risk and learn how to avoid damage or injury.



CAUTION

Ignoring this "Caution Hot" symbol could cause injury to skin; see also section "Actions in response to troubles".

Persons

• Instructed person

This safety manual describes safeguards for the protection of an instructed person. Instructed person is a term applied to persons who have been instructed and trained by a skilled person, or who are supervised by a skilled person, to identify energy sources that may cause pain and to take precautions to avoid unintentional contact with or exposure to those energy sources.

Disassemble and modification



WARNING

- Do not remove covers and panels which are fixed to the machine. Some machines have a high-voltage component or a laser beam source inside that could cause an electrical shock or blindness.
- Do not modify this machine, because this could cause a fire, electrical shock or breakdown. If the machine contains a laser, the laser beam source could cause blindness.
- Do not carry out maintenance activities for other components and maintenance materials than the components and materials that are mentioned in the user manual.
- To avoid any risk, only properly qualified and trained service technicians are allowed to modify the machine.



IMPORTANT

- Do not bridge any mechanical or electrical circuit breakers.

Power cord



WARNING

- Do not scratch, abrade, heat, twist, bend, place a heavy object on or cause any other damage to the power cord. The use of a damaged power cord (exposed core wire, broken wire, for example) could result in a fire or breakdown. If you find any of these conditions, immediately turn OFF the power switch and unplug the power cord from the power outlet. Then call your authorised service representative.
- Only use the mains connector cable that was supplied with the machine.
- Do not use any power cable other than the one provided. Never use the power cable with any other electrical device.

Power source



WARNING

- Put the power plug directly into a wall socket that has the same configuration as the plug. The use of an adapter leads can result in an inadequate power supply. If a proper wall outlet is not available, ask a qualified electrician to carry out the installation.
 - Do not use a multiple outlet adapter or an extension lead. Contact your authorised service representative if an extension lead is required. The use of an extension cord may result in fire or electrical shock.
-



IMPORTANT

- Do not connect the machine to a mains voltage that differs from the value as stated on the power marking label.
-

Power plug



WARNING

- For machines that are connected via a wall socket: Place the machine close to a wall socket that is easily accessible. The power plug is intended to serve as a disconnect device.
-

Grounding



WARNING

- Connect the power cord to an electrical outlet (wall socket) that is equipped with a grounding terminal.
 - This equipment has not been designed for connection to an IT power system. An IT power system is a voltage network in which the neutral wire is not connected to earth.
-

Installation



WARNING

- It is recommended to connect only copy-control products (or other products) which meet the (inter)national product safety and radio frequency interference standards. Only use an attachment cable as specified by the manufacturer.
 - Make sure that the machine is placed on a level, horizontal surface of sufficient strength.
 - Do not place this machine on an unstable or tilted surface.
 - Do not place this machine in a location that is subject to lots of vibrations and shocks.
 - Do not use flammable sprays, liquids or gases near this product, because this could cause a fire.
-

Ventilation



IMPORTANT

- Do not block the ventilation openings of the machine.
 - Be sure to allow a clearance of 60 mm or more at the back of this machine for the ventilation duct.
-

Actions in response to troubles

**WARNING**

- When a piece of metal, water or any other similar foreign matter gets inside the machine, immediately turn OFF the power switch and unplug the power cord from the power outlet. Then call your authorised service representative.
 - Immediately stop using the machine if the machine becomes excessively hot, emits smoke, or produces unusual odours or noises. Immediately turn OFF the power switch and unplug the power cord from the power outlet. Then call your authorised service representative.
 - Stop using the machine if the machine was dropped or a cover was damaged. Immediately turn OFF the power switch and unplug the power cord from the power outlet. Then call your authorised service representative.
-

**CAUTION**

- LCD display. Do not rub, press or touch the display surface with hard material, because the polariser at the surface can be easily scratched. The LCD module consists of glass. Therefore, the LCD module can damage when you drop, pinch strongly or punch the module. When glass breaks, be careful that you do not get injured by glass pieces. Call Customer Service.
-

Moving the machine

**WARNING**

- Make sure that you disconnect the power cord and other cables before you move the machine.
 - Make sure that you check the documentation for the correct machine location before you move the machine.
 - Make sure that whenever the machine is moved, this is done by properly qualified people who have received adequate instructions.
-

General use

**WARNING**

- Do not lean, lie or stand on any part of the machine, including any unit that can be pulled outward (e.g. paper drawers).
 - Do not touch or ingest fluids from a broken LCD; Liquid Crystal Display. When clothes or skin come into contact with the fluid, immediately clean the clothes and skin with soap or alcohol. After eye contact, immediately wash the eyes with a washing lotion for at least 15 minutes and consult a physician.
-

**IMPORTANT**

- Unplug the product when you will not use the product for a long period of time.
-

Chapter 2

Regulation notices

Regulation notices

Grounding (Finland; FI, Norway; NO, Sweden; SE and Denmark; DK)

- FI: Laite on liitettävä suojakoskettimilla varustettuun pistorasiaan.
- NO: Apparatet må tilkoples jordet stikkontakt.
- SE: Apparatens skall anslutas till jordat uttag.
- DK: Apparatets stikprop skal tilsluttes en stikkontakt med jord, som giver forbindelse til stikproppens jord.

Translation: The machine must be connected to a grounded power outlet.

Radio Interference suppression (all countries except USA)

- Warning: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

FCC approval (USA)

- This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate, radio frequency energy and, if not installed and used in accordance with the Operator's Manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.
- Use of shielded cables are required to comply with Class A limits in Subpart B of Part 15 of the FCC Rules.
- Do not make any changes or modifications to the equipment unless otherwise specified in the manual. If you make such changes or modifications, you could be required to stop operation of the equipment .

ICES-003; Interference-causing equipment (Canada)

- This Class A digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

VCCI (Japan)

- **Class A ITE**

<p>この装置は、クラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。</p> <p>VCCI-A</p>

Translation: This is a Class A product based on the standard of the VCCI Council. If this equipment is used in a domestic environment, radio interference may occur, in which case the user may be required to take corrective actions.

EAC (Russia, Kazakhstan and Belarus)



The following information about this product can be found on the rear side of the machine:

- Model number
- Mains specifications
- Manufacturer
- Country of origin
- Production date <YYYY-MM-DD>
- EAC Marking

Battery labelling (EEA and Switzerland)

- This product contains a battery. Please do not remove the battery. If the battery needs replacement, this should be done only by skilled service technicians who are aware of the removal instructions provided by Canon.
- This product contains (a) Button Cell(s). It (They) is (are) located in (a) printed circuit board(s) that is (are) essential for the continuous error-free functioning of the product. The button cell(s) should be removed only by skilled service technicians who are aware of the removal instructions provided by Canon.




Button Cell Location	Button Cell Capacity [Ah]	Contains the following substances (if applicable)
Motherboard	0.22 Ah	Lithium



CAUTION

Canon does not accept any liability for any damage or consequences, if the batteries are removed by persons other than Canon service personnel.

Battery labelling (Taiwan)



Translation: Waste Batteries, Please Recycle

End of Life; WEEE (EEA and Switzerland)

- This symbol indicates that this product is not to be disposed of with your household waste, according to the WEEE Directive (2012/19/EU) and your national law. This product should be handed over to a designated collection point, e.g., on an authorized one-for-one basis when you buy a new similar product or to an authorized collection site for recycling waste electrical and electronic equipment (EEE). Improper handling of this type of waste could have a possible negative impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. At the same time, your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, waste authority, approved WEEE scheme or your household waste disposal service. For more information regarding return and recycling of WEEE products, please visit "<http://www.canon-europe.com/environment>". Reference: Directive 2012/19/EU.



End of Life; WEEE (India)

- This product is not to be disposed of with your household waste, according to the e-waste (Management and Handling) Rules, 2011. This product should be handed over to a designated collection point, e.g., to an authorized collection site for recycling waste electrical and electronic equipment (EEE). Improper handling of this type of waste could have a possible negative impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. At the same time, your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information regarding return and recycling of WEEE products, please visit "<http://www.canon.co.in/environment>". Also, this product complies with the "India E-waste Rule 2011" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 % by weight and 0.01 % by weight for Cadmium, except for the exemptions set in Schedule II of the Rule.



RoHS (China)

- The Environmental Protection Use Period (EPUP) applicable for the printing system designated for deliveries to the Peoples Republic of China is 20 years. This EPUP, which does not include consumables or expendables, does not affect any warranty that is provided for the system and may not be construed or interpreted as a separate guarantee for the printing system.



Energy consumption (all countries)

- In order to limit energy consumption during times of non-use the PRISMAsync iPR C10000VP-A1 has a Sleep mode during which the power level is reduced. The value for the Sleep mode is listed in the Product Safety Data Sheet.
- Power Modes and Delay Times
The energy consumption and efficiency are influenced both by the product technology and by the settings chosen by the user, especially the delay times that are selected to enter reduced power states. The following delay times have been pre-set.

Operational mode	Default Delay Time [minutes]
Low Power	20 minutes (range 0 - 30 minutes)
Sleep	40 minutes (range 1 - 240 minutes)

The modes above are automatically entered after the Default Delay Time has elapsed; counting from the moment the last print has been produced. These settings are recommended and for most users ensure both ease of use and low energy consumption. Between brackets are the minimum and maximum values. The Delay Times can be changed. Shorter delay times will lower the energy consumption even further, but may cause longer recovery times. In some cases longer delay times may prove to be more convenient, but it should be noted that this may cause an increase in energy consumption. Therefore, from an energy preservation point-of-view, longer delay times are not recommended.

Automatic duplex

- Using both sides of paper reduces paper costs, energy consumption and the amount of paper in the waste disposal process. Therefore, the PRISMAsync iPR C10000VP-A1 is default set for automatic duplex copying and printing.

Standby Power (Federal Energy Management Programme) (all countries)

- This product meets the following criteria for the United States Federal Energy Management Programme (FEMP):
 - In Standby this product consumes < 1 W. After shutting down all systems properly, the Standby-mode as defined by FEMP is reached by switching the Main Switch to "0".
 - This product has a hard-off switch.
 - This product meets the ENERGY STAR® Guidelines for energy efficiency.



Chapter 3

General information

General information

Caution labels and notations (all countries)

- You can find the power-marking label at the bottom of the controller. If connection to a different mains voltage is required, contact Customer Service.
- Do not remove caution labels or caution notations. If a label or notation is soiled, please clean the label or notation. If you cannot make label or notation legible, or if the label or notation is damaged, please contact your service representative.

Space requirements and operation precautions (all countries)

- The required operating space of this product will be communicated to each customer by the local sales representative during the Site Survey.

Operating environment (all countries)

- The environmental requirements for correct operation of the machine are as follows:
Operating temperature (T): 10 °C (50 °F) - 32 °C (96 °F)
Relative Humidity (RH): 20% - 90%

Deployment area: below 2000m altitude and non tropical (China):



‘仅适用于海拔2000m以下地区安全使用’

Translation: Can only be safely used lower than 2,000 metres altitude.



‘仅适用于非热带气候条件下安全使用’

Translation: Can only be safely used in non tropical weather.

Chapter 4

Miscellaneous

Online support for your product

Downloads

User guides, printer drivers and other resources can change without prior notice. To stay up-to-date, you are advised to download the latest resources from:

["http://downloads.oce.com"](http://downloads.oce.com)

Before you use your product, you must always download the latest safety information for your product: make sure that you read and understand all safety information in the manual entitled '**Safety Guide**' .

Support

For support information please contact your Canon local representative.

Find your local contact for support from:

["http://www.canon.com/support/"](http://www.canon.com/support/)

Canon

Canon Inc.

www.canon.com

Canon U.S.A., Inc.

www.usa.canon.com

Canon Canada Inc.

www.canon.ca

Canon Europa Inc.

www.canon-europe.com

Canon Latin America Inc.

www.cla.canon.com

Canon Australia PTY. Ltd

www.canon.com.au

Canon China Co., Ltd

www.canon.com.cn

Canon Singapore PTE. Ltd

www.canon.com.sg

Canon Hongkong Co., Ltd

www.canon.com.hk